

Network Working Group
Internet-Draft
Expires: November 27, 2005

C. Sikes
Paradyne Networks, Inc.
B. Ray
PESA Switching Systems, Inc.
R. Abbi
Alcatel USA
May 26, 2005

Definitions of Managed Objects for High Bit-Rate DSL - 2nd generation
(HDSL2) and Single-Pair High-Speed Digital Subscriber Line (SHDSL) Lines
[draft-ietf-adslmib-gshdslbis-11.txt](#)

Status of this Memo

By submitting this Internet-Draft, each author represents that any applicable patent or other IPR claims of which he or she is aware have been or will be disclosed, and any of which he or she becomes aware will be disclosed, in accordance with [Section 6 of BCP 79](#).

Internet-Drafts are working documents of the Internet Engineering Task Force (IETF), its areas, and its working groups. Note that other groups may also distribute working documents as Internet-Drafts.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet-Drafts as reference material or to cite them other than as "work in progress."

The list of current Internet-Drafts can be accessed at
<http://www.ietf.org/ietf/1id-abstracts.txt>.

The list of Internet-Draft Shadow Directories can be accessed at
<http://www.ietf.org/shadow.html>.

This Internet-Draft will expire on November 27, 2005.

Copyright Notice

Copyright (C) The Internet Society (2005).

Abstract

This document defines a Management Information Base (MIB) module for use with network management protocols in the Internet community. In particular, it describes objects used for managing High Bit-Rate Digital Subscriber Line (DSL) - 2nd generation (HDSL2) and Single-

Pair High-Speed Digital Subscriber Line (SHDSL) interfaces. This document introduces extensions to several objects and textual conventions defined in HDSL2-SHDSL-Line MIB ([RFC 3276](#)). This document obsoletes [RFC 3276](#).

Table of Contents

1.	The Internet-Standard Management Framework	3
2.	Overview	3
2.1	Relationship to other MIBs	3
2.2	IANA Considerations	5
2.3	Conventions used in the MIB Module	6
2.4	Structure	7
2.5	Line Topology	10
2.6	Counters, Interval Buckets and Thresholds	11
2.7	Profiles	11
2.8	Notifications	12
3.	Definitions	14
4.	Implementation Analysis	66
5.	Security Considerations	67
6.	Acknowledgments	71
7.	References	72
7.1	Normative References	72
7.2	Informative References	73
	Authors' Addresses	74
	Intellectual Property and Copyright Statements	75

1. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to [Section 7 of RFC 3410](#) [[RFC3410](#)].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIV2, which is described in STD 58, [RFC 2578](#) [[RFC2578](#)], STD 58, [RFC 2579](#) [[RFC2579](#)] and STD 58, [RFC 2580](#) [[RFC2580](#)].

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC 2119](#) [[RFC2119](#)].

2. Overview

This document defines a Management Information Base (MIB) module for use with network management protocols in the Internet community for the purpose of managing HDSL2/SHDSL Lines.

The MIB module described in [RFC 3276](#) [[RFC3276](#)] describes objects used for managing High Bit-Rate DSL - 2nd generation (HDSL2) [[T1E1.4](#)] and Single-Pair High-Speed Digital Subscriber Line (SHDSL) interfaces [[G.991.2](#)]. These object descriptions are based upon the specifications for the HDSL2 and SHDSL Embedded Operations Channel (EOC) as defined in American National Standards Institute (ANSI) T1E1.4/2000-006 [[T1E1.4](#)] and International Telecommunication Union (ITU) G.991.2 [[G.991.2](#)].

This document obsoletes [RFC 3276](#) [[RFC3276](#)] which supports G.shdsl in that the MIB module described herein supports G.shdsl.bis as described in the G.991.2 [[G.991.2](#)]. In addition, objects have been added to improve the management of SHDSL lines.

The MIB module is located in the MIB tree under MIB 2 transmission, as discussed in the MIB-2 Integration ([RFC 2863](#) [[RFC2863](#)]) section of this document.

2.1 Relationship to other MIBs

This section outlines the relationship of this MIB module with other MIB modules described in RFCs. Specifically, IF-MIB as presented in [RFC 2863](#) [[RFC2863](#)] is discussed.

[2.1.1.1](#) General IF-MIB Integration ([RFC 2863](#))

The HDSL2/SHDSL Line MIB specifies the detailed attributes of a data interface. As such, it needs to integrate with [RFC 2863](#) [[RFC2863](#)]. The IANA has assigned the following ifTypes to HDSL2 and SHDSL:

```
IANAifType ::= TEXTUAL-CONVENTION
    ...
    SYNTAX INTEGER {
        ...
        hdsl2 (168), -- High Bit-Rate DSL, 2nd generation
        shdsl (169), -- Multirate HDSL2
        ...
    }
```

Note that the ifFixedLengthGroup from [RFC 2863](#) [[RFC2863](#)] MUST be supported and that the ifRcvAddressGroup does not apply to this MIB module.

[2.1.1.2](#) Usage of ifTable

The MIB branch identified by this ifType contains tables appropriate for this interface type. Most such tables extend the ifEntry table, and are indexed by ifIndex. For interfaces in systems implementing this MIB module, those table entries indexed by ifIndex MUST be persistent.

The following attributes are part of the mandatory ifGeneralInformationGroup in [RFC 2863](#) [[RFC2863](#)], and are not duplicated in the HDSL2/SHDSL Line MIB.

=====	
ifIndex	Interface index.
ifDescr	See interfaces MIB [RFC2863].
ifType	hdsl2(168) or shdsl(169).
ifSpeed	Set as appropriate. (This is fixed at 1552000 for HDSL2 lines)
ifPhysAddress	This object MUST have an octet string with zero length.
ifAdminStatus	See interfaces MIB [RFC2863].
ifOperStatus	See interfaces MIB [RFC2863].
ifLastChange	See interfaces MIB [RFC2863].
ifName	See interfaces MIB [RFC2863].
ifAlias	See interfaces MIB [RFC2863].
ifLinkUpDownTrapEnable	Default to enabled(1).
ifHighSpeed	Set as appropriate. (For HDSL2 lines, this is fixed at 2)
ifConnectorPresent	Set as appropriate.
=====	

Figure 1: Use of ifTable Objects

2.2 IANA Considerations

The HDSL2-SHDSL-LINE-MIB module requires the allocation of a single object identifier for its MODULE-IDENTITY. The IANA has allocated this object identifier in the transmission subtree (48), defined in the SNMPv2-SMI MIB module.

The assignment was in fact done when [RFC 3276](#) was published, and this revision of the RFC does not require any new action from IANA.

2.3 Conventions used in the MIB Module

2.3.1 Naming Conventions

- A. xtuC refers to a central site terminal unit;
H2TU-C for HDSL2, or STU-C for SHDSL.
- B. xtuR refers to a remote site terminal unit;
H2TU-R for HDSL2, or STU-R for SHDSL.
- C. xtu refers to a terminal unit; either an xtuC or xtuR.
- D. xru refer to a regenerator unit;
H2RU for HDSL2, or SRU for SHDSL.
- E. xU refers to any HDSL2/SHDSL unit; either an xtu or xru.
- F. CRC is cyclic redundancy check [[G.991.2](#)].
- G. ES means errored second [[G.991.2](#)].
- J. LOSW means loss of sync word [[G.991.2](#)].
- I. LOSWS means LOSW seconds [[G.991.2](#)].
- J. SES means severely errored second [[G.991.2](#)].
- K. SNR means signal-to-noise ratio [[G.991.2](#)].
- L. UAS means unavailable second [[G.991.2](#)].

2.3.2 Textual Conventions

The following textual conventions are defined to reflect the line topology in the MIB module (further discussed in the following section) and to define the behavior of the statistics to be maintained by an agent.

o Hdsl2ShdslUnitId:

Attributes with this syntax uniquely identify each unit in a HDSL2/SHDSL span. It mirrors the EOC addressing mechanism:

xtuC(1)	- central office (CO) terminal unit
xtuR(2)	- customer premises equipment (CPE) terminal unit
xru1(3) .. xru8(10)	- regenerators, numbered from central office side

o Hdsl2ShdslUnitSide:

Attributes with this syntax reference the two sides of a unit:

networkSide(1)	- N in figure 2, below
customerSide(2)	- C in figure 2, below

o Hdsl2ShdslWirePair:

Attributes with this syntax reference the wire pairs connecting

the units:

- wirePair1(1) - First pair for HDSL2/SHDSL.
- wirePair2(2) - Optional second pair for SHDSL only.
- wirePair3(3) - Optional third pair for SHDSL.bis only.
- wirePair4(4) - Optional fourth pair for SHDSL.bis only.

o Hdsl2ShdslTransmissionModeType:

Attributes with this syntax specify the regional setting for a SHDSL line. Specified as a BITS construct, the two mode types are:

- region1 - ITU-T G.991.2 Annex A
- region2 - ITU-T G.991.2 Annex B

o Hdsl2ShdslPerfCurrDayCount:

Attributes with this syntax define the behavior of the 1-day (24 hour) gauges found in the MIB module.

o Hdsl2Shdsl1DayIntervalCount:

Attributes with this syntax define the behavior of the 1-day (24 hour) interval counters found in the MIB module.

o Hdsl2ShdslPerfTimeElapsed:

Attributes with this syntax define the behavior of the elapsed time counters found in the MIB module.

o Hdsl2ShdslPerfIntervalThreshold:

Attributes with this syntax define the behavior of the alarm thresholds found in the MIB module.

o Hdsl2ShdslClockReferenceType:

Attributes with this syntax define the clock references for the HDSL2/SHDSL span.

2.4 Structure

The MIB module is structured into following MIB groups:

o Span Configuration Group:

This group supports MIB objects for configuring parameters for the

HDSL2/SHDSL span. It contains the following table:

- hds12ShdslSpanConfTable

o Span Status Group:

This group supports MIB objects for retrieving span status information. It contains the following table:

- hds12ShdslSpanStatusTable

o Unit Inventory Group:

This group supports MIB objects for retrieving unit inventory information about units in HDSL2/SHDSL lines via the EOC. It contains the following table:

- hds12ShdslInventoryTable

o Segment Endpoint Configuration Group:

This group supports MIB objects for configuring parameters for the HDSL2/SHDSL segment endpoints. It contains the following table:

- hds12ShdslEndpointConfTable

o Segment Endpoint Current Status/Performance Group:

This group supports MIB objects that provide the current status/performance information relating to segment endpoints. It contains the following table:

- hds12ShdslEndpointCurrTable

o Segment Endpoint 15-Minute Interval Status/Performance Group:

This group supports MIB objects that provide historic status/performance information relating to segment endpoints in 15-minute intervals. It contains the following table:

- hds12Shdsl15MinIntervalTable

o Segment Endpoint 1-Day Interval Status/Performance Group:

This group supports MIB objects that provide historic status/performance information relating to segment endpoints in 1-day intervals. It contains the following table:

- hds12Shds11DayIntervalTable

- o Maintenance Group:

This group supports MIB objects for performing maintenance operations such as loopbacks for HDSL2/SHDSL lines. It contains the following table(s):

- hds12Shds1EndpointMaintTable
- hds12Shds1UnitMaintTable

- o Span Configuration Profile Group:

This group supports MIB objects for defining configuration profiles for HDSL2/SHDSL Spans. It contains the following table:

- hds12Shds1SpanConfProfileTable

- o Segment Endpoint Alarm Configuration Profile Group:

This group supports MIB objects for defining alarm configuration profiles for HDSL2/SHDSL Segment Endpoints. It contains the following table:

- hds12Shds1EndpointAlarmConfProfileTable

- o Notifications Group:

This group defines the notifications supported for HDSL2/SHDSL lines:

- hds12Shds1LoopAttenCrossing
- hds12Shds1SNRMarginCrossing
- hds12Shds1PerfESThresh
- hds12Shds1PerfSESThresh
- hds12Shds1PerfCRCAnomaliesThresh
- hds12Shds1PerfLOSSThresh
- hds12Shds1PerfUASThresh
- hds12Shds1SpanInvalidNumRepeaters
- hds12Shds1LoopbackFailure
- hds12Shds1powerBackoff
- hds12Shds1deviceFault
- hds12Shds1dcContinuityFault
- hds12Shds1configInitFailure
- hds12Shds1protocolInitFailure
- hds12Shds1noNeighborPresent
- hds12Shds1LocalPowerLoss

o SHDSL Wire Pair Group:

This group supports MIB objects which provide status of the SHDSL-specific wire pairs.

- hds12ShdslEndpointCurrTipRingReversal
- hds12ShdslEndpointCurrActivationState

o Payload Group:

This group supports MIB objects for retrieving payload rates which excludes any framing overhead.

- hds12ShdslStatusMaxAttainablePayloadRate
- hds12ShdslStatusActualPayloadRate

2.5 Line Topology

An HDSL2/SHDSL Line consists of a minimum of two units - xtuC (the central termination unit) and an xtuR (the remote termination unit). The line may optionally support up to 8 repeater/regenerator units (xru) as shown in the figure below.




Figure 2: General topology for an HDSL2/SHDSL Line

2.6 Counters, Interval Buckets and Thresholds

For SNR Margin, Loop Attenuation, ES, SES, CRC anomalies, LOSW, and UAS, there are event counters, current 15-minute and 0 to 96 15-minute history bucket(s) of "interval-counters", as well as current and 0 to 30 previous 1-day interval-counter(s). Each current 15-minute event bucket has an associated threshold notification.

Unlike [RFC 3593](#) [[RFC3593](#)] and [RFC 2662](#) [[RFC2662](#)], there is no representation in the MIB module for invalid buckets. In those cases where the data for an interval is suspect or known to be invalid, the agent MUST NOT report the interval. If the current 15-minute event bucket is determined to be invalid, notifications based upon the value of the event bucket MUST NOT be generated.

Not reporting an interval will result in holes in the associated table. For example, the table, `hds12Shdsl15MinIntervalTable`, is indexed by { `ifIndex`, `hds12ShdslInvIndex`, `hds12ShdslEndpointSide`, `hds12ShdslEndpointWirePair`, `hds12Shdsl15MinIntervalNumber`}. If interval 12 is determined to be invalid but intervals 11 and 13 are valid, a Get Next operation on the indices `.1.1.1.1.11` would return indices `.1.1.1.1.13`.

There is no requirement for an agent to ensure a fixed relationship between the start of a fifteen minute interval and any wall clock; however some implementations may align the fifteen minute intervals with quarter hours. Likewise, an implementation may choose to align one day intervals with the start of a day.

Counters are not reset when an xU is reinitialized, only when the agent is reset or reinitialized (or under specific request outside the scope of this MIB module).

2.7 Profiles

As a managed node can handle a large number of xUs, (e.g., hundreds or perhaps thousands of lines), provisioning every parameter on every xU may become burdensome. Moreover, most lines are provisioned identically with the same set of parameters. To simplify the provisioning process, this MIB module makes use of profiles. A profile is a set of parameters that can be shared by multiple lines using the same configuration.

The following profiles are used in this MIB module:

- o Span Configuration Profiles - Span configuration profiles contain parameters for configuring HDSL2/SHDSL spans. They are defined in the `hds12ShdslSpanConfProfileTable`. Since span configuration

parameters are only applicable for SHDSL, the support for span configuration profiles are optional for HDSL2 interfaces.

Note that the configuration of the span dictates the behavior for each individual segment endpoint in the span. If a different configuration is provisioned for any given segment endpoint within the span, the new configuration for this segment endpoint will override the span configuration for this segment endpoint only.

- o Segment Endpoint Alarm Configuration Profiles - These profiles contain parameters for configuring alarm thresholds for HDSL2/SHDSL segment endpoints. These profiles are defined in the `hds12ShdslEndpointAlarmConfProfileTable`.

The index value for this profile is a locally-unique administratively assigned name for the profile having the textual convention 'SnmpAdminString' ([RFC 3411](#) [[RFC3411](#)]).

One or more lines may be configured to share parameters of a single profile (e.g., `hds12ShdslEndpointAlarmConfProfile` = 'silver') by setting its `hds12ShdslEndpointAlarmConfProfile` objects to the value of this profile. If a change is made to the profile, all lines that refer to it will be reconfigured to the changed parameters. Before a profile can be deleted or taken out of service it must be first unreferenced from all associated lines.

Implementations MUST provide a default profile whose name is 'DEFVAL' for each profile type. The values of the associated parameters will be vendor specific unless otherwise indicated in this document. Before a line's profiles have been set, these profiles will be automatically used by setting `hds12ShdslEndpointAlarmConfProfile` and `hds12ShdslSpanConfProfile` to 'DEFVAL' where appropriate. This default profile name, 'DEFVAL', is considered reserved in the context of profiles defined in this MIB module.

Profiles are created, assigned, and deleted dynamically using the profile name and profile row status in each of the four profile tables.

Profile changes MUST take effect immediately. These changes MAY result in a restart (hard reset or soft restart) of the units on the line.

2.8 Notifications

The ability to generate the SNMP notifications `coldStart`/`WarmStart` (per [[RFC3418](#)]) which are per agent (e.g., per Digital Subscriber Line Access Multiplexer, or DSLAM, in such a device), and `linkUp`/

linkDown (per [[RFC2863](#)]) which are per interface (i.e., HDSL2/SHDSL line) is required.

A linkDown notification MAY be generated whenever any of ES, SES, CRC Anomaly, LOSW, or UAS event occurs. The corresponding linkUp notification MAY be sent when all link failure conditions are cleared.

The notifications defined in this MIB module are for initialization failure and for the threshold crossings associated with the following events: ES, SES, CRC Anomaly, LOSW, and UAS. Each threshold has its own enable/threshold value. When that value is 0, the notification is disabled.

The hds12ShdslEndpointCurrStatus is a bitmask representing all outstanding error conditions associated with a particular Segment Endpoint. Note that since status of remote endpoints is obtained via the EOC, this information may be unavailable for units that are unreachable via EOC during a line error condition. Therefore, not all conditions may always be included in its current status. Notifications corresponding to the bit fields in this object are defined.

Two alarm conditions, SNR Margin Alarm and Loop Attenuation Alarm, are organized in a manner slightly different from that implied in the EOC specifications. In the MIB module, these alarm conditions are tied to the two thresholds hds12ShdslEndpointThreshSNRMargin and hds12ShdslEndpointThreshLoopAttenuation found in the hds12ShdslEndpointAlarmConfProfileTable. In the EOC, the alarm conditions associated with these thresholds are per-unit. In the MIB module, these alarm conditions are per-endpoint. For terminal units, this has no impact. For repeaters, this implies an implementation variance where the agent in the terminal unit is responsible for detecting a threshold crossing. As the reporting of a repeater detected alarm condition to the polling terminal unit occurs in the same EOC message as the reporting of the current SNR Margin and Loop Attenuation values, it is anticipated that this will have very little impact on agent implementation.

A threshold notification occurs whenever the corresponding current 15-minute interval error counter becomes equal to, or exceeds the threshold value. Only one notification SHOULD be sent per interval per interface. Since the current 15-minute counter is reset to 0 every 15 minutes, and if the condition persists, the notification may recur as often as every 15 minutes. For example, to get a notification whenever a "loss of" event occurs (but at most once every 15 minutes), set the corresponding threshold to 1. The agent will generate a notification when the event originally occurs.

Notifications, other than the threshold notifications listed above, SHOULD be rate limited (throttled) such that there is at least a one-minute gap between the generation of consecutive notification of the same event. When notifications are rate limited, they are dropped and not queued for sending at a future time. This is intended to be a general rate-limiting statement for notifications that have no explicit rate limiting assertions in this document otherwise.

Note that the Network Management System, or NMS, may receive a linkDown notification, as well, if enabled (via ifLinkUpDownTrapEnable [[RFC2863](#)]). At the beginning of the next 15 minute interval, the counter is reset. When the first second goes by and the event occurs, the current interval bucket will be 1, which equals the threshold, and the notification will be sent again.

A hds12ShdslSpanInvalidNumRepeaters notification may be generated following completion of the discovery phase if the number of repeaters discovered on the line differs from the number of repeaters specified in hds12ShdslSpanConfNumRepeaters. For those conditions where the number of provisioned repeaters is greater than those encountered during span discovery, all table entries associated with the nonexistent repeaters are to be discarded. For those conditions where the number of provisioned repeaters is less than those encountered during span discovery, additional table entries are to be created using the default span configuration profile.

3. Definitions

HDSL2-SHDSL-LINE-MIB DEFINITIONS ::= BEGIN

IMPORTS

MODULE-IDENTITY,
OBJECT-TYPE,
Counter32,
Unsigned32,
Gauge32,
NOTIFICATION-TYPE,
Integer32,
transmission
FROM SNMPv2-SMI
RowStatus,
TEXTUAL-CONVENTION
FROM SNMPv2-TC
ifIndex
FROM IF-MIB
PerfCurrentCount,
PerfIntervalCount
FROM PerfHist-TC-MIB

SnmpAdminString
FROM SNMP-FRAMEWORK-MIB
MODULE-COMPLIANCE,
OBJECT-GROUP,
NOTIFICATION-GROUP
FROM SNMPv2-CONF;

hds12ShdslMIB MODULE-IDENTITY

LAST-UPDATED "200505260000Z" -- May 26, 2005

ORGANIZATION "ADSLMIB Working Group"

CONTACT-INFO "WG-email: adslmib@ietf.org

WG-URL:

<http://www.ietf.org/html.charters/adslmib-charter.html>

Info: <https://www1.ietf.org/mailman/listinfo/adslmib>

Chair: Mike Sneed

Postal: P.O. Box 37324
Raleigh NC 27627-7324 USA
Email: sneedmike@hotmail.com

Co-Chair Bob Ray
PESA Switching Systems, Inc.
Postal 330-A Wynn Drive
Huntsville, AL 35805 USA
Phone +1 256 726 9200 ext. 142

Co-editor: Clay Sikes
Paradyne Networks, Inc.
Postal: 8545 126th Ave. N.
Largo, FL 33772 USA
Email: csikes@paradyne.com
Phone: +1 727 530 8257

Co-editor: Bob Ray
PESA Switching Systems, Inc.
Postal: 330-A Wynn Drive
Huntsville, AL 35805 USA
Email: rray@pesa.com
Phone: +1 256 726 9200 ext. 142

Co-editor: Rajesh Abbi
Alcatel USA
Postal: 2912 Wake Forest Road
Raleigh, NC 27609-7860 USA
Email: Rajesh.Abbi@alcatel.com
Phone: +1 919 850 6194"

DESCRIPTION

"This MIB module defines a collection of objects for managing HDSL2/SHDSL lines. An agent may reside at either end of the line, however the MIB module is designed to require no management communication between the modems beyond that inherent in the low-level EOC line protocol as defined in ANSI T1E1.4/2000-006 (for HDSL2 lines), or in ITU G.991.2 (for SHDSL lines).

Copyright (C) The Internet Society (2005). This version of this MIB module is part of RFC xxxx; see the RFC itself for full legal notices."

REVISION "200505260000Z" -- May 26, 2005

DESCRIPTION "This version, published as RFC xxxx.

The following changes have been made in this version:

1. Added a 3rd and 4th wire pair.
2. Modified all rates such that their rates are only constrained by an unsigned 32-bit value and not by what today's perceived technology limitations are.
3. Clarified that the rates from [RFC 3276](#) include payload and any applicable framing and added objects for payload-only rates.
4. Added an object to indicate whether or not the tip and ring are reversed on a wire pair.
5. Added an object to display the activation state of a wire pair.
6. Added references as necessary for clarification.
7. Added display hints to textual conventions as necessary.
8. Updated conformance statements as necessary.
9. Some changes were due to IETF requirements and RFC generation tools."

REVISION "200205090000Z" -- May 9, 2002

DESCRIPTION "Initial version, published as [RFC 3276](#)."

::= { transmission 48 }

hds12ShdslMibObjects OBJECT IDENTIFIER ::= { hds12ShdslMIB 1 }

-- Textual Conventions used in this MIB module

--

Hds12ShdslPerfCurrDayCount ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d"

STATUS current

DESCRIPTION

"A gauge associated with interface performance measurements in

a current 1-day (24 hour) measurement interval.

The value of this gauge starts at zero at the beginning of an interval and is increased when associated events occur, until the end of the 1-day interval. At that time the value of the gauge is stored in the previous 1-day history interval, as defined in a companion object of type `Hdsl2Shdsl1DayIntervalCount`, and the current interval gauge is restarted at zero.

In the case where the agent has no valid data available for this interval the corresponding object instance is not available and upon a retrieval request a corresponding error message shall be returned to indicate that this instance does not exist. Please note that zero is a valid value."

SYNTAX Gauge32

`Hdsl2Shdsl1DayIntervalCount` ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d"

STATUS current

DESCRIPTION

"A counter associated with interface performance measurements during the most previous 1-day (24 hour) measurement interval. The value of this gauge is equal to the value of the current day gauge, as defined in a companion object of type `Hdsl2ShdslPerfCurrDayCount`, at the end of its most recent interval.

In the case where the agent has no valid data available for this interval the corresponding object instance is not available and upon a retrieval request a corresponding error message shall be returned to indicate that this instance does not exist."

SYNTAX Gauge32

`Hdsl2ShdslPerfTimeElapsed` ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d"

STATUS current

DESCRIPTION

"The number of seconds that have elapsed since the beginning of the current measurement period. If, for some reason, such as an adjustment in the system's time-of-day clock or the addition of a leap second, the current interval exceeds the maximum value, the agent will return the maximum value.

For 15 minute intervals, the range is limited to (0..899).

For 24 hour intervals, the range is limited to (0..86399)."

SYNTAX Unsigned32(0..86399)

Hdsl2ShdslPerfIntervalThreshold ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d"

STATUS current

DESCRIPTION

"This convention defines a range of values that may be set in a fault threshold alarm control. As the number of seconds in a 15-minute interval numbers at most 900, objects of this type may have a range of 0...900, where the value of 0 disables the alarm."

SYNTAX Unsigned32(0..900)

Hdsl2ShdslUnitId ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This is the unique identification for all units in a HDSL2/SHDSL Span. It is based on the EOC unit addressing scheme with reference to the xtuC."

SYNTAX INTEGER

```
{
    xtuC(1),
    xtuR(2),
    xru1(3),
    xru2(4),
    xru3(5),
    xru4(6),
    xru5(7),
    xru6(8),
    xru7(9),
    xru8(10)
}
```

Hdsl2ShdslUnitSide ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This is the referenced side of a HDSL2/SHDSL unit - Network or Customer side. The side facing the Network is the Network side, while the side facing the Customer is the Customer side."

SYNTAX INTEGER

```
{
    networkSide(1),
    customerSide(2)
}
```

Hdsl2ShdslWirePair ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This is the referenced pair of wires in a HDSL2/SHDSL Segment. HDSL2 only supports a single pair (wirePair1 or two wire),

SHDSL lines support an optional second pair (wirePair2 or four wire), and G.shdsl.bis support an optional third pair (wirePair3 or six wire) and an optional fourth pair (wirePair4 or eight wire)."

```
SYNTAX      INTEGER
    {
        wirePair1(1),    -- two wire
        wirePair2(2),    -- four wire
        wirePair3(3),    -- six wire
        wirePair4(4)     -- eight wire
    }
```

Hdsl2ShdslTransmissionModeType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Contains the regional setting of the HDSL2/SHDSL span, represented as a bit-map of possible settings. The various bit positions are:

Bit	Meaning	Description
1	region 1	Indicates ITU-T G.991.2 Annex A.
2	region 2	Indicates ITU-T G.991.2 Annex B."

```
SYNTAX      BITS
    {
        region1(0),
        region2(1)
    }
```

Hdsl2ShdslClockReferenceType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The various STU-C symbol clock references for the HDSL2/SHDSL span, represented as an enumeration."

```
SYNTAX      INTEGER
    {
        localClk(1),      -- Mode-1 per G991.2
        networkClk(2),    -- Mode-2 per G991.2
        dataOrNetworkClk(3), -- Mode-3a per G991.2
        dataClk(4)        -- Mode-3b per G991.2
    }
```

-- Span Configuration Group

--

hdlsl2ShdslSpanConfTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hdsl2ShdslSpanConfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table supports overall configuration of HDSL2/SHDSL Spans. Entries in this table MUST be maintained in a persistent manner."

::= { hds12Shds1MibObjects 1 }

hds12Shds1SpanConfEntry OBJECT-TYPE

SYNTAX Hds12Shds1SpanConfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shds1SpanConfTable. Each entry represents the complete Span in a single HDSL2/SHDSL line. It is indexed by the ifIndex of the associated HDSL2/SHDSL line."

INDEX { ifIndex }

::= { hds12Shds1SpanConfTable 1 }

Hds12Shds1SpanConfEntry ::=

SEQUENCE

```
{
  hds12Shds1SpanConfNumRepeaters      Unsigned32,
  hds12Shds1SpanConfProfile           SnmpAdminString,
  hds12Shds1SpanConfAlarmProfile      SnmpAdminString
}
```

hds12Shds1SpanConfNumRepeaters OBJECT-TYPE

SYNTAX Unsigned32(0..8)

UNITS "repeaters"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provisions the number of repeaters/regenerators in this HDSL2/SHDSL Span."

::= { hds12Shds1SpanConfEntry 1 }

hds12Shds1SpanConfProfile OBJECT-TYPE

SYNTAX SnmpAdminString (SIZE(1..32))

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object is a pointer to a span configuration profile in the hds12Shds1SpanConfProfileTable, which applies to this span. The value of this object is the index of the referenced profile in the hds12Shds1SpanConfProfileTable. Note that span configuration profiles are only applicable to SHDSL lines.

HDSL2 lines MUST reference the default profile, 'DEFVAL'.

By default, this object will have the value 'DEFVAL'
(the index of the default profile).

Any attempt to set this object to a value that is not the value
of the index for an active entry in the profile table,
hds12Shds1SpanConfProfileTable, MUST be rejected."
::= { hds12Shds1SpanConfEntry 2 }

hds12Shds1SpanConfAlarmProfile OBJECT-TYPE

SYNTAX SnmpAdminString (SIZE(1..32))

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object is a pointer to an Alarm configuration profile in
the hds12Shds1EndpointAlarmConfProfileTable. The value of
this object is the index of the referenced profile in the
hds12Shds1EndpointAlarmConfProfileTable. The alarm
threshold configuration in the referenced profile will be
used by default for all segment endpoints in this span.
Individual endpoints may override this profile by explicitly
specifying some other profile in the
hds12Shds1EndpointConfTable. By default, this object will
have the value 'DEFVAL' (the index of the default
profile).

Any attempt to set this object to a value that is not the value
of the index for an active entry in the profile table,
hds12Shds1EndpointAlarmConfProfileTable, MUST be rejected."
::= { hds12Shds1SpanConfEntry 3 }

-- Span Status Group

--

hds12Shds1SpanStatusTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12Shds1SpanStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table provides overall status information of
HDSL2/SHDSL spans. This table contains live data from
equipment. As such, it is NOT persistent."

::= { hds12Shds1MibObjects 2 }

hds12Shds1SpanStatusEntry OBJECT-TYPE

SYNTAX Hds12Shds1SpanStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shds1SpanStatusTable. Each entry represents the complete span in a single HDSL2/SHDSL line. It is indexed by the ifIndex of the associated HDSL2/SHDSL line."

```
INDEX { ifIndex }  
 ::= { hds12Shds1SpanStatusTable 1 }
```

```
Hds12Shds1SpanStatusEntry ::=  
  SEQUENCE  
  {  
    hds12Shds1StatusNumAvailRepeaters      Unsigned32,  
    hds12Shds1StatusMaxAttainableLineRate  Unsigned32,  
    hds12Shds1StatusActualLineRate        Unsigned32,  
    hds12Shds1StatusTransmissionModeCurrent  
                                           Hds12Shds1TransmissionModeType,  
    hds12Shds1StatusMaxAttainablePayloadRate Unsigned32,  
    hds12Shds1StatusActualPayloadRate      Unsigned32  
  }
```

```
hds12Shds1StatusNumAvailRepeaters OBJECT-TYPE  
  SYNTAX      Unsigned32(0..8)  
  MAX-ACCESS  read-only  
  STATUS      current  
  DESCRIPTION  
    "Contains the actual number of repeaters/regenerators  
    discovered in this HDSL2/SHDSL span."  
  ::= { hds12Shds1SpanStatusEntry 1 }
```

```
hds12Shds1StatusMaxAttainableLineRate OBJECT-TYPE  
  SYNTAX      Unsigned32(0..4294967295)  
  UNITS       "bps"  
  MAX-ACCESS  read-only  
  STATUS      current  
  DESCRIPTION  
    "Contains the maximum attainable line rate in this HDSL2/SHDSL  
    span. This object provides the maximum rate the line is  
    capable of achieving. This is based upon measurements made  
    during line probing. This rate includes payload (user data)  
    and any applicable framing overhead."  
  ::= { hds12Shds1SpanStatusEntry 2 }
```

```
hds12Shds1StatusActualLineRate OBJECT-TYPE  
  SYNTAX      Unsigned32(0..4294967295)  
  UNITS       "bps"  
  MAX-ACCESS  read-only  
  STATUS      current  
  DESCRIPTION  
    "Contains the actual line rate in this HDSL2/SHDSL span. This
```


SHOULD equal ifSpeed. This rate includes payload (user data)
and any applicable framing overhead"
::= { hds12ShdslSpanStatusEntry 3 }

hds12ShdslStatusTransmissionModeCurrent OBJECT-TYPE

SYNTAX Hds12ShdslTransmissionModeType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Contains the current Power Spectral Density (PSD) regional
setting of the HDSL2/SHDSL span."

::= { hds12ShdslSpanStatusEntry 4 }

hds12ShdslStatusMaxAttainablePayloadRate OBJECT-TYPE

SYNTAX Unsigned32(0..4294967295)

UNITS "bps"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Contains the maximum attainable payload (user data)
line rate in this HDSL2/SHDSL span. This object provides
the maximum rate the line is capable of achieving. This
is based upon measurements made during line probing. Any
framing overhead is not included."

::= { hds12ShdslSpanStatusEntry 5 }

hds12ShdslStatusActualPayloadRate OBJECT-TYPE

SYNTAX Unsigned32(0..4294967295)

UNITS "bps"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Contains the actual line rate in this HDSL2/SHDSL span. Any
framing overhead is not included."

::= { hds12ShdslSpanStatusEntry 6 }

-- Unit Inventory Group

--

hds12ShdslInventoryTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12ShdslInventoryEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table supports retrieval of unit inventory information
available via the EOC from units in a HDSL2/SHDSL line.

Entries in this table are dynamically created during the

line discovery process. The life cycle for these entries is as follows:

- xtu discovers a device, either a far-end xtu or an xru
- an inventory table entry is created for the device
- the line goes down for whatever reason
- inventory table entries for unreachable devices are destroyed.

As these entries are created/destroyed dynamically, they are NOT persistent."

```
::= { hds12ShdslMibObjects 3 }
```

hds12ShdslInventoryEntry OBJECT-TYPE

SYNTAX Hds12ShdslInventoryEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12ShdslInventoryTable. Each entry represents inventory information for a single unit in a HDSL2/SHDSL line. It is indexed by the ifIndex of the HDSL2/SHDSL line and the Hds12ShdslUnitId of the associated unit."

INDEX { ifIndex, hds12ShdslInvIndex }

```
::= { hds12ShdslInventoryTable 1 }
```

Hds12ShdslInventoryEntry ::=

SEQUENCE

```
{
  hds12ShdslInvIndex          Hds12ShdslUnitId,
  hds12ShdslInvVendorID      OCTET STRING,
  hds12ShdslInvVendorModelNumber OCTET STRING,
  hds12ShdslInvVendorSerialNumber OCTET STRING,
  hds12ShdslInvVendorEOCSoftwareVersion Integer32,
  hds12ShdslInvStandardVersion Integer32,
  hds12ShdslInvVendorListNumber OCTET STRING,
  hds12ShdslInvVendorIssueNumber OCTET STRING,
  hds12ShdslInvVendorSoftwareVersion OCTET STRING,
  hds12ShdslInvEquipmentCode OCTET STRING,
  hds12ShdslInvVendorOther    OCTET STRING,
  hds12ShdslInvTransmissionModeCapability
                                Hds12ShdslTransmissionModeType
}
```

hds12ShdslInvIndex OBJECT-TYPE

SYNTAX Hds12ShdslUnitId

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Each entry in this table corresponds to a physical element in a HDSL2/SHDSL Span. It is based on the EOC unit addressing scheme with reference to the xtuC."

::= { hds12Shds1InventoryEntry 1 }

hds12Shds1InvVendorID OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(8))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor ID as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 25-32."

::= { hds12Shds1InventoryEntry 2 }

hds12Shds1InvVendorModelNumber OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(12))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor model number as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 33-44."

::= { hds12Shds1InventoryEntry 3 }

hds12Shds1InvVendorSerialNumber OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(12))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor serial number as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 45-56."

::= { hds12Shds1InventoryEntry 4 }

hds12Shds1InvVendorEOCSoftwareVersion OBJECT-TYPE

SYNTAX Integer32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor EOC version as reported in a Discovery Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.2](#), Discovery response - Message ID 130, Octet 12."

::= { hdsl2ShdslInventoryEntry 5 }

hdlsl2ShdslInvStandardVersion OBJECT-TYPE

SYNTAX Integer32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Version of the HDSL2/SHDSL standard implemented, as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octet 2."

::= { hdsl2ShdslInventoryEntry 6 }

hdlsl2ShdslInvVendorListNumber OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(3))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor list number as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 3-5."

::= { hdsl2ShdslInventoryEntry 7 }

hdlsl2ShdslInvVendorIssueNumber OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(2))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor issue number as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 6-7."

::= { hdsl2ShdslInventoryEntry 8 }

hdlsl2ShdslInvVendorSoftwareVersion OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(6))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Vendor software version as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 8-13."

::= { hds12ShdslInventoryEntry 9 }

hds12ShdslInvEquipmentCode OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(10))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Equipment code conforming to ANSI T1.213, Coded Identification of Equipment Entities."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 14-23."

::= { hds12ShdslInventoryEntry 10 }

hds12ShdslInvVendorOther OBJECT-TYPE

SYNTAX OCTET STRING(SIZE(12))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Other vendor information as reported in an Inventory Response message."

REFERENCE

"G.991.2, [Section 9.5.5.7.4](#), Inventory response - Message ID 130, Octets 57-68."

::= { hds12ShdslInventoryEntry 11 }

hds12ShdslInvTransmissionModeCapability OBJECT-TYPE

SYNTAX Hds12ShdslTransmissionModeType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Contains the transmission mode capability of the SHDSL unit."

::= { hds12ShdslInventoryEntry 12 }

-- Segment Endpoint Configuration Group

--

hds12ShdslEndpointConfTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12ShdslEndpointConfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table supports configuration parameters for segment endpoints in a HDSL2/SHDSL line. As this table is indexed by ifIndex, it MUST be maintained in a persistent manner."


```
::= { hds12Shds1MibObjects 4 }
```

hds12Shds1EndpointConfEntry OBJECT-TYPE

SYNTAX Hds12Shds1EndpointConfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shds1EndpointConfTable. Each entry represents a single segment endpoint in a HDSL2/SHDSL line. It is indexed by the ifIndex of the HDSL2/SHDSL line, the UnitId of the associated unit, the side of the unit, and the wire pair of the associated modem."

INDEX { ifIndex, hds12Shds1InvIndex, hds12Shds1EndpointSide, hds12Shds1EndpointWirePair }

```
::= { hds12Shds1EndpointConfTable 1 }
```

Hds12Shds1EndpointConfEntry ::=

SEQUENCE

```
{  
  hds12Shds1EndpointSide          Hds12Shds1UnitSide,  
  hds12Shds1EndpointWirePair      Hds12Shds1WirePair,  
  hds12Shds1EndpointAlarmConfProfile SnmpAdminString  
}
```

hds12Shds1EndpointSide OBJECT-TYPE

SYNTAX Hds12Shds1UnitSide

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The side of the unit associated with this segment endpoint - Network/Customer side - as per the Hds12Shds1UnitSide textual convention."

```
::= { hds12Shds1EndpointConfEntry 1 }
```

hds12Shds1EndpointWirePair OBJECT-TYPE

SYNTAX Hds12Shds1WirePair

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The wire pair of the modem associated with this segment endpoint as per the Hds12Shds1WirePair textual convention."

```
::= { hds12Shds1EndpointConfEntry 2 }
```

hds12Shds1EndpointAlarmConfProfile OBJECT-TYPE

SYNTAX SnmpAdminString (SIZE(0..32))

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object configures the alarm threshold values to be used for this segment endpoint. The values are obtained from the alarm configuration profile referenced by this object. The value of this object is the index of the referenced profile in the hds12Shds1EndpointAlarmConfProfileTable, or NULL (a zero-length SnmpAdminString). If the value is a zero-length SnmpAdminString, the endpoint uses the default Alarm Configuration Profile for the associated span as per the hds12Shds1SpanConfAlarmProfile object in the hds12Shds1SpanConfTable. The default value of this object is a zero-length SnmpAdminString.

Any attempt to set this object to a value that is not the value of the index for an active entry in the profile table, hds12Shds1EndpointAlarmConfProfileTable, MUST be rejected."

::= { hds12Shds1EndpointConfEntry 3 }

-- Segment Endpoint Current Status/Performance Group

--

hds12Shds1EndpointCurrTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12Shds1EndpointCurrEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains current status and performance information for segment endpoints in HDSL2/SHDSL Lines. As with other tables in this MIB module indexed by ifIndex, entries in this table MUST be maintained in a persistent manner."

::= { hds12Shds1MibObjects 5 }

hds12Shds1EndpointCurrEntry OBJECT-TYPE

SYNTAX Hds12Shds1EndpointCurrEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shds1EndpointCurrTable. Each entry contains status and performance information relating to a single segment endpoint. It is indexed by the ifIndex of the HDSL2/SHDSL line, the UnitId of the associated unit, the side of the unit, and the wire pair of the associated modem."

INDEX { ifIndex, hds12Shds1InvIndex, hds12Shds1EndpointSide,
hds12Shds1EndpointWirePair }

::= { hds12Shds1EndpointCurrTable 1 }

Hds12Shds1EndpointCurrEntry ::=

SEQUENCE

{


```

hds12ShdslEndpointCurrAtn          Integer32,
hds12ShdslEndpointCurrSnrMgn       Integer32,
hds12ShdslEndpointCurrStatus       BITS,
hds12ShdslEndpointES               Counter32,
hds12ShdslEndpointSES              Counter32,
hds12ShdslEndpointCRCAnomalies     Counter32,
hds12ShdslEndpointLOSWS            Counter32,
hds12ShdslEndpointUAS              Counter32,
hds12ShdslEndpointCurr15MinTimeElapsed
                                Hds12ShdslPerfTimeElapsed,
hds12ShdslEndpointCurr15MinES       PerfCurrentCount,
hds12ShdslEndpointCurr15MinSES      PerfCurrentCount,
hds12ShdslEndpointCurr15MinCRCAnomalies PerfCurrentCount,
hds12ShdslEndpointCurr15MinLOSWS    PerfCurrentCount,
hds12ShdslEndpointCurr15MinUAS      PerfCurrentCount,
hds12ShdslEndpointCurr1DayTimeElapsed
                                Hds12ShdslPerfTimeElapsed,
hds12ShdslEndpointCurr1DayES
                                Hds12ShdslPerfCurrDayCount,
hds12ShdslEndpointCurr1DaySES
                                Hds12ShdslPerfCurrDayCount,
hds12ShdslEndpointCurr1DayCRCAnomalies
                                Hds12ShdslPerfCurrDayCount,
hds12ShdslEndpointCurr1DayLOSWS
                                Hds12ShdslPerfCurrDayCount,
hds12ShdslEndpointCurr1DayUAS
                                Hds12ShdslPerfCurrDayCount,
hds12ShdslEndpointCurrTipRingReversal INTEGER,
hds12ShdslEndpointCurrActivationState INTEGER
}

```

hds12ShdslEndpointCurrAtn OBJECT-TYPE

SYNTAX Integer32(-127..128)

UNITS "dB"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The current loop attenuation for this endpoint as reported in
a Network or Customer Side Performance Status message."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 1 }

hds12ShdslEndpointCurrSnrMgn OBJECT-TYPE

SYNTAX Integer32(-127..128)

UNITS "dB"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The current SNR margin for this endpoint as reported in a Status Response/SNR message."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 2 }

hds12ShdslEndpointCurrStatus OBJECT-TYPE

SYNTAX BITS
{
noDefect(0),
powerBackoff(1),
deviceFault(2),
dcContinuityFault(3),
snrMarginAlarm(4),
loopAttenuationAlarm(5),
loswFailureAlarm(6),
configInitFailure(7),
protocolInitFailure(8),
noNeighborPresent(9),
loopbackActive(10)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Contains the current state of the endpoint. This is a bit-map of possible conditions. The various bit positions are:

noDefect	There are no defects on the line.
powerBackoff	Indicates enhanced Power Backoff.
deviceFault	Indicates a vendor-dependent diagnostic or self-test fault has been detected.
dcContinuityFault	Indicates vendor-dependent conditions that interfere with span powering such as short and open circuits.
snrMarginAlarm	Indicates that the SNR margin has dropped below the alarm threshold.
loopAttenuationAlarm	Indicates that the loop attenuation exceeds the alarm threshold.
loswFailureAlarm	Indicates a forward LOSW alarm.

configInitFailure	Endpoint failure during initialization due to paired endpoint not able to support requested configuration.
protocolInitFailure	Endpoint failure during initialization due to incompatible protocol used by the paired endpoint.
noNeighborPresent	Endpoint failure during initialization due to no activation sequence detected from paired endpoint.
loopbackActive	A loopback is currently active at this Segment Endpoint.

This is intended to supplement ifOperStatus. Note that there is a 1:1 relationship between the status bits defined in this object and the notification thresholds defined elsewhere in this MIB module."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12ShdslEndpointCurrEntry 3 }

hds12ShdslEndpointES OBJECT-TYPE

SYNTAX Counter32
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of Errored Seconds (ES) on this endpoint since the xU was last restarted."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12ShdslEndpointCurrEntry 4 }

hds12ShdslEndpointSES OBJECT-TYPE

SYNTAX Counter32
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of Severely Errored Seconds (SES) on this endpoint since the xU was last restarted."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12ShdslEndpointCurrEntry 5 }

hds12ShdslEndpointCRCAnomalies OBJECT-TYPE

SYNTAX Counter32
UNITS "detected CRC Anomalies"
MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of CRC anomalies on this endpoint since the xU was last restarted."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 6 }

hds12ShdslEndpointLOSWS OBJECT-TYPE

SYNTAX Counter32

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Loss of Sync Word (LOSWS) Seconds on this endpoint since the xU was last restarted."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 7 }

hds12ShdslEndpointUAS OBJECT-TYPE

SYNTAX Counter32

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Unavailable Seconds (UAS) on this endpoint since the xU was last restarted."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 8 }

hds12ShdslEndpointCurr15MinTimeElapsed OBJECT-TYPE

SYNTAX Hds12ShdslPerfTimeElapsed

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Total elapsed seconds in the current 15-minute interval."

::= { hds12ShdslEndpointCurrEntry 9 }

hds12ShdslEndpointCurr15MinES OBJECT-TYPE

SYNTAX PerfCurrentCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Errored Seconds (ES) in the current 15-minute interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 10 }

hds12ShdslEndpointCurr15MinSES OBJECT-TYPE

SYNTAX PerfCurrentCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Severely Errored Seconds (SES) in the current 15-minute interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 11 }

hds12ShdslEndpointCurr15MinCRCAnomalies OBJECT-TYPE

SYNTAX PerfCurrentCount

UNITS "detected CRC Anomalies"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of CRC anomalies in the current 15-minute interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 12 }

hds12ShdslEndpointCurr15MinLOSWS OBJECT-TYPE

SYNTAX PerfCurrentCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Loss of Sync Word (LOSWS) Seconds in the current 15-minute interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 13 }

hds12ShdslEndpointCurr15MinUAS OBJECT-TYPE

SYNTAX PerfCurrentCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Unavailable Seconds (UAS) in the current 15-minute interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 14 }

hds12ShdslEndpointCurr1DayTimeElapsed OBJECT-TYPE

SYNTAX Hds12ShdslPerfTimeElapsed

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Number of seconds that have elapsed since the beginning of the current 1-day interval."

::= { hds12ShdslEndpointCurrEntry 15 }

hds12ShdslEndpointCurr1DayES OBJECT-TYPE

SYNTAX Hds12ShdslPerfCurrDayCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Errored Seconds (ES) during the current day as measured by hds12ShdslEndpointCurr1DayTimeElapsed."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 16 }

hds12ShdslEndpointCurr1DaySES OBJECT-TYPE

SYNTAX Hds12ShdslPerfCurrDayCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Severely Errored Seconds (SES) during the current day as measured by hds12ShdslEndpointCurr1DayTimeElapsed."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 17 }

hds12ShdslEndpointCurr1DayCRCAnomalies OBJECT-TYPE

SYNTAX Hds12ShdslPerfCurrDayCount

UNITS "detected CRC Anomalies"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of CRC anomalies during the current day as measured by hds12ShdslEndpointCurr1DayTimeElapsed."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 18 }

hds12ShdslEndpointCurr1DayLOSWS OBJECT-TYPE

SYNTAX Hds12ShdslPerfCurrDayCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Loss of Sync Word (LOSWS) Seconds during the current day as measured by hds12ShdslEndpointCurr1DayTimeElapsed."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 19 }

hds12ShdslEndpointCurr1DayUAS OBJECT-TYPE

SYNTAX Hdsl2ShdslPerfCurrDayCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Unavailable Seconds (UAS) during the current day as measured by hds12ShdslEndpointCurr1DayTimeElapsed."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12ShdslEndpointCurrEntry 20 }

hds12ShdslEndpointCurrTipRingReversal OBJECT-TYPE

SYNTAX INTEGER

{
normal(1),
reversed(2)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the state of the tip/ring for the wire pair."

::= { hds12ShdslEndpointCurrEntry 21 }

hds12ShdslEndpointCurrActivationState OBJECT-TYPE

SYNTAX INTEGER

{
preActivation(1), -- PreTrain
activation(2), -- Training
data(3) -- Trained
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the activation or training state of the wire pair."

REFERENCE "ITU-T G.991.2, [Section 6.2](#) PMD Activation Sequence"

::= { hds12ShdslEndpointCurrEntry 22 }

-- Segment Endpoint 15-Minute Interval Status/Performance Group

--

hds12Shdsl15MinIntervalTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hdsl2Shdsl15MinIntervalEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table provides one row for each HDSL2/SHDSL endpoint

performance data collection interval. This table contains live data from equipment. As such, it is NOT persistent."
 ::= { hds12ShdslMibObjects 6 }

hds12Shdsl15MinIntervalEntry OBJECT-TYPE

SYNTAX Hds12Shdsl15MinIntervalEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shdsl15MinIntervalTable."

INDEX { ifIndex, hds12ShdslInvIndex, hds12ShdslEndpointSide,
 hds12ShdslEndpointWirePair, hds12Shdsl15MinIntervalNumber }

::= { hds12Shdsl15MinIntervalTable 1 }

Hds12Shdsl15MinIntervalEntry ::=

SEQUENCE

{
 hds12Shdsl15MinIntervalNumber Unsigned32,
 hds12Shdsl15MinIntervalES PerfIntervalCount,
 hds12Shdsl15MinIntervalSES PerfIntervalCount,
 hds12Shdsl15MinIntervalCRCAnomalies PerfIntervalCount,
 hds12Shdsl15MinIntervalLOSWS PerfIntervalCount,
 hds12Shdsl15MinIntervalUAS PerfIntervalCount
 }

hds12Shdsl15MinIntervalNumber OBJECT-TYPE

SYNTAX Unsigned32(1..96)

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Performance Data Interval number. Interval 1 is the most recent previous interval; interval 96 is 24 hours ago. Intervals 2..96 are optional."

::= { hds12Shdsl15MinIntervalEntry 1 }

hds12Shdsl15MinIntervalES OBJECT-TYPE

SYNTAX PerfIntervalCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Errored Seconds (ES) during the interval."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl15MinIntervalEntry 2 }

hds12Shdsl15MinIntervalSES OBJECT-TYPE

SYNTAX PerfIntervalCount

UNITS "seconds"

MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of Severely Errored Seconds (SES) during the interval."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12Shds115MinIntervalEntry 3 }

hds12Shds115MinIntervalCRCAnomalies OBJECT-TYPE

SYNTAX PerfIntervalCount
UNITS "detected CRC Anomalies"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of CRC anomalies during the interval."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12Shds115MinIntervalEntry 4 }

hds12Shds115MinIntervalLOSWS OBJECT-TYPE

SYNTAX PerfIntervalCount
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of Loss of Sync Word (LOSW) Seconds during the interval."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12Shds115MinIntervalEntry 5 }

hds12Shds115MinIntervalUAS OBJECT-TYPE

SYNTAX PerfIntervalCount
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Count of Unavailable Seconds (UAS) during the interval."
REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"
::= { hds12Shds115MinIntervalEntry 6 }

-- Segment Endpoint 1-Day Interval Status/Performance Group

--

hds12Shds11DayIntervalTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12Shds11DayIntervalEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table provides one row for each HDSL2/SHDSL endpoint performance data collection interval. This table contains

live data from equipment. As such, it is NOT persistent."
 ::= { hds12ShdslMibObjects 7 }

hds12Shdsl1DayIntervalEntry OBJECT-TYPE

SYNTAX Hds12Shdsl1DayIntervalEntry
 MAX-ACCESS not-accessible
 STATUS current
 DESCRIPTION
 "An entry in the hds12Shdsl1DayIntervalTable."
 INDEX { ifIndex, hds12ShdslInvIndex, hds12ShdslEndpointSide,
 hds12ShdslEndpointWirePair, hds12Shdsl1DayIntervalNumber }
 ::= { hds12Shdsl1DayIntervalTable 1 }

Hds12Shdsl1DayIntervalEntry ::=

SEQUENCE
 {
 hds12Shdsl1DayIntervalNumber Unsigned32,
 hds12Shdsl1DayIntervalMoniSecs Hds12ShdslPerfTimeElapsed,
 hds12Shdsl1DayIntervalES Hds12Shdsl1DayIntervalCount,
 hds12Shdsl1DayIntervalSES Hds12Shdsl1DayIntervalCount,
 hds12Shdsl1DayIntervalCRCAnomalies Hds12Shdsl1DayIntervalCount,
 hds12Shdsl1DayIntervalLOSWS Hds12Shdsl1DayIntervalCount,
 hds12Shdsl1DayIntervalUAS Hds12Shdsl1DayIntervalCount
 }

hds12Shdsl1DayIntervalNumber OBJECT-TYPE

SYNTAX Unsigned32(1..30)
 MAX-ACCESS not-accessible
 STATUS current
 DESCRIPTION
 "History Data Interval number. Interval 1 is the most
 recent previous day; interval 30 is 30 days ago. Intervals
 2..30 are optional."
 ::= { hds12Shdsl1DayIntervalEntry 1 }

hds12Shdsl1DayIntervalMoniSecs OBJECT-TYPE

SYNTAX Hds12ShdslPerfTimeElapsed
 UNITS "seconds"
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "The amount of time in the 1-day interval over which the
 performance monitoring information is actually counted.
 This value will be the same as the interval duration except
 in a situation where performance monitoring data could not
 be collected for any reason."
 ::= { hds12Shdsl1DayIntervalEntry 2 }

hds12Shdsl1DayIntervalES OBJECT-TYPE

SYNTAX Hdsl2Shdsl1DayIntervalCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Errored Seconds (ES) during the 1-day interval as measured by hds12Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl1DayIntervalEntry 3 }

hds12Shdsl1DayIntervalSES OBJECT-TYPE

SYNTAX Hdsl2Shdsl1DayIntervalCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Severely Errored Seconds (SES) during the 1-day interval as measured by hds12Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl1DayIntervalEntry 4 }

hds12Shdsl1DayIntervalCRCAnomalies OBJECT-TYPE

SYNTAX Hdsl2Shdsl1DayIntervalCount

UNITS "detected CRC Anomalies"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of CRC anomalies during the 1-day interval as measured by hds12Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl1DayIntervalEntry 5 }

hds12Shdsl1DayIntervalLOSWS OBJECT-TYPE

SYNTAX Hdsl2Shdsl1DayIntervalCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Loss of Sync Word (LOSWS) Seconds during the 1-day interval as measured by hds12Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl1DayIntervalEntry 6 }

hds12Shdsl1DayIntervalUAS OBJECT-TYPE

SYNTAX Hdsl2Shdsl1DayIntervalCount

UNITS "seconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Count of Unavailable Seconds (UAS) during the 1-day interval as measured by hds12Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 [Section 7.5.3.7](#); SHDSL [Section 9.5.5.7](#)"

::= { hds12Shdsl1DayIntervalEntry 7 }

-- Maintenance Group

--

hds12ShdslEndpointMaintTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12ShdslEndpointMaintEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table supports maintenance operations (e.g. loopbacks) to be performed on HDSL2/SHDSL segment endpoints. This table contains live data from equipment. As such, it is NOT persistent."

::= { hds12ShdslMibObjects 8 }

hds12ShdslEndpointMaintEntry OBJECT-TYPE

SYNTAX Hds12ShdslEndpointMaintEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12ShdslEndpointMaintTable. Each entry corresponds to a single segment endpoint, and is indexed by the ifIndex of the HDSL2/SHDSL line, the UnitId of the associated unit and the side of the unit."

INDEX { ifIndex, hds12ShdslInvIndex, hds12ShdslEndpointSide }

::= { hds12ShdslEndpointMaintTable 1 }

Hds12ShdslEndpointMaintEntry ::=

SEQUENCE

```
{
  hds12ShdslMaintLoopbackConfig      INTEGER,
  hds12ShdslMaintTipRingReversal     INTEGER,
  hds12ShdslMaintPowerBackOff        INTEGER,
  hds12ShdslMaintSoftRestart         INTEGER
}
```

hds12ShdslMaintLoopbackConfig OBJECT-TYPE

SYNTAX INTEGER

```
{
  noLoopback(1),
  normalLoopback(2),
  specialLoopback(3)
}
```



```
    }
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "This object controls configuration of loopbacks for the
        associated segment endpoint. The status of the loopback
        is obtained via the hds12ShdslEndpointCurrStatus object."
    ::= { hds12ShdslEndpointMaintEntry 1 }
```

hds12ShdslMaintTipRingReversal OBJECT-TYPE

```
    SYNTAX INTEGER
        {
            normal(1),
            reversed(2)
        }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "This object indicates the state of the tip/ring pair at the
        associated segment endpoint."
    ::= { hds12ShdslEndpointMaintEntry 2 }
```

hds12ShdslMaintPowerBackOff OBJECT-TYPE

```
    SYNTAX INTEGER
        {
            default(1),
            enhanced(2)
        }
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "This object configures the receiver at the associated
        segment endpoint to operate in default or enhanced power
        backoff mode."
    ::= { hds12ShdslEndpointMaintEntry 3 }
```

hds12ShdslMaintSoftRestart OBJECT-TYPE

```
    SYNTAX INTEGER
        {
            ready(1),
            restart(2)
        }
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "This object enables the manager to trigger a soft restart
        of the modem at the associated segment endpoint. The
        manager may only set this object to the 'restart(2)'"
```


value, which initiates a restart. The agent will perform a restart after approximately 5 seconds. Following the 5 second period, the agent will restore the object to the 'ready(1)' state."

::= { hds12Shds1EndpointMaintEntry 4 }

hds12Shds1UnitMaintTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12Shds1UnitMaintEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table supports maintenance operations for units in a HDSL2/SHDSL line. Entries in this table MUST be maintained in a persistent manner."

::= { hds12Shds1MibObjects 9 }

hds12Shds1UnitMaintEntry OBJECT-TYPE

SYNTAX Hds12Shds1UnitMaintEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the hds12Shds1UnitMaintTable. Each entry corresponds to a single unit, and is indexed by the ifIndex of the HDSL2/SHDSL line and the UnitId of the associated unit."

INDEX { ifIndex, hds12Shds1InvIndex }

::= { hds12Shds1UnitMaintTable 1 }

Hds12Shds1UnitMaintEntry ::=

SEQUENCE

{
hds12Shds1MaintLoopbackTimeout Integer32,
hds12Shds1MaintUnitPowerSource INTEGER
}

hds12Shds1MaintLoopbackTimeout OBJECT-TYPE

SYNTAX Integer32(0..4095)

UNITS "minutes"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object configures the timeout value for loopbacks initiated at segments endpoints contained in the associated unit. A value of 0 disables the timeout."

::= { hds12Shds1UnitMaintEntry 1 }

hds12Shds1MaintUnitPowerSource OBJECT-TYPE

SYNTAX INTEGER


```

        {
            local(1),
            span(2)
        }
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "This object indicates the DC power source being used by the
    associated unit."
 ::= { hdsl2ShdslUnitMaintEntry 2 }

```

```
-- Span Configuration Profile Group
```

```
--
```

```
hdlsl2ShdslSpanConfProfileTable OBJECT-TYPE
```

```

SYNTAX        SEQUENCE OF Hdsl2ShdslSpanConfProfileEntry
MAX-ACCESS    not-accessible
STATUS        current
DESCRIPTION
    "This table supports definitions of span configuration
    profiles for SHDSL lines. HDSL2 does not support these
    configuration options. This table MUST be maintained
    in a persistent manner."
 ::= { hdsl2ShdslMibObjects 10 }

```

```
hdlsl2ShdslSpanConfProfileEntry OBJECT-TYPE
```

```

SYNTAX        Hdsl2ShdslSpanConfProfileEntry
MAX-ACCESS    not-accessible
STATUS        current
DESCRIPTION
    "Each entry corresponds to a single span configuration
    profile. Each profile contains a set of span configuration
    parameters. The configuration parameters in a profile are
    applied to those lines referencing that profile (see the
    hdsl2ShdslSpanConfProfile object). Profiles may be
    created/deleted using the row creation/deletion mechanism
    via hdsl2ShdslSpanConfProfileRowStatus. If an active
    entry is referenced in hdsl2ShdslSpanConfProfile, the
    entry MUST remain active until all references are removed."
INDEX { IMPLIED hdsl2ShdslSpanConfProfileName }
 ::= { hdsl2ShdslSpanConfProfileTable 1 }

```

```
Hdsl2ShdslSpanConfProfileEntry ::=
```

```

SEQUENCE
{
    hdsl2ShdslSpanConfProfileName          SnmpAdminString,
    hdsl2ShdslSpanConfWireInterface        INTEGER,
    hdsl2ShdslSpanConfMinLineRate          Unsigned32,

```



```

hds12ShdslSpanConfMaxLineRate      Unsigned32,
hds12ShdslSpanConfPSD              INTEGER,
hds12ShdslSpanConfTransmissionMode
                                Hds12ShdslTransmissionModeType,
hds12ShdslSpanConfRemoteEnabled     INTEGER,
hds12ShdslSpanConfPowerFeeding      INTEGER,
hds12ShdslSpanConfCurrCondTargetMarginDown Integer32,
hds12ShdslSpanConfWorstCaseTargetMarginDown Integer32,
hds12ShdslSpanConfCurrCondTargetMarginUp Integer32,
hds12ShdslSpanConfWorstCaseTargetMarginUp Integer32,
hds12ShdslSpanConfUsedTargetMargins BITS,
hds12ShdslSpanConfReferenceClock
                                Hds12ShdslClockReferenceType,
hds12ShdslSpanConfLineProbeEnable   INTEGER,
hds12ShdslSpanConfProfileRowStatus  RowStatus
}

```

hds12ShdslSpanConfProfileName OBJECT-TYPE

```

SYNTAX      SnmpAdminString (SIZE(1..32))
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION

```

"This object is the unique index associated with this profile.
 Entries in this table are referenced via the object
 hds12ShdslSpanConfProfile in Hds12ShdslSpanConfEntry."

```
 ::= { hds12ShdslSpanConfProfileEntry 1 }
```

hds12ShdslSpanConfWireInterface OBJECT-TYPE

```

SYNTAX      INTEGER
            {
                twoWire(1),
                fourWire(2),
                sixWire(3),
                eightWire(4)
            }
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION

```

"This object configures the two-wire or optional four-wire,
 six-wire, or eight-wire operation for SHDSL Lines."

```

DEFVAL      { twoWire }
 ::= { hds12ShdslSpanConfProfileEntry 2 }
```

hds12ShdslSpanConfMinLineRate OBJECT-TYPE

```

SYNTAX      Unsigned32(0..4294967295)
UNITS       "bps"
MAX-ACCESS  read-create
STATUS      current

```


DESCRIPTION

"This object configures the minimum transmission rate for the associated SHDSL Line in bits-per-second (bps) and includes both payload (user data) and any applicable framing overhead. If the minimum line rate equals the maximum line rate (hds12ShdslSpanMaxLineRate), the line rate is considered 'fixed'. If the minimum line rate is less than the maximum line rate, the line rate is considered 'rate-adaptive'."

DEFVAL { 1552000 }

::= { hds12ShdslSpanConfProfileEntry 3 }

hds12ShdslSpanConfMaxLineRate OBJECT-TYPE

SYNTAX Unsigned32(0..4294967295)

UNITS "bps"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the maximum transmission rate for the associated SHDSL Line in bits-per-second (bps) and includes both payload (user data) and any applicable framing overhead. If the minimum line rate equals the maximum line rate (hds12ShdslSpanMaxLineRate), the line rate is considered 'fixed'. If the minimum line rate is less than the maximum line rate, the line rate is considered 'rate-adaptive'."

DEFVAL { 1552000 }

::= { hds12ShdslSpanConfProfileEntry 4 }

hds12ShdslSpanConfPSD OBJECT-TYPE

SYNTAX INTEGER
{
symmetric(1),
asymmetric(2)
}

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures use of symmetric/asymmetric PSD (Power Spectral Density) Mask for the associated SHDSL Line. Support for symmetric PSD is mandatory for all supported data rates. Support for asymmetric PSD is optional."

DEFVAL { symmetric }

::= { hds12ShdslSpanConfProfileEntry 5 }

hds12ShdslSpanConfTransmissionMode OBJECT-TYPE

SYNTAX Hds12ShdslTransmissionModeType

MAX-ACCESS read-create

STATUS current
DESCRIPTION
"This object specifies the regional setting for the SHDSL
line."
DEFVAL { { region1 } }
::= { hds12ShdslSpanConfProfileEntry 6 }

hds12ShdslSpanConfRemoteEnabled OBJECT-TYPE

SYNTAX INTEGER
{
enabled(1),
disabled(2)
}
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"This object enables/disables support for remote management
of the units in a SHDSL line from the STU-R via the EOC."
DEFVAL { enabled }
::= { hds12ShdslSpanConfProfileEntry 7 }

hds12ShdslSpanConfPowerFeeding OBJECT-TYPE

SYNTAX INTEGER
{
noPower(1),
powerFeed(2),
wettingCurrent(3)
}
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"This object enables/disables support for optional power
feeding in a SHDSL line."
DEFVAL { noPower }
::= { hds12ShdslSpanConfProfileEntry 8 }

hds12ShdslSpanConfCurrCondTargetMarginDown OBJECT-TYPE

SYNTAX Integer32(-10..21)
UNITS "dB"
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"This object specifies the downstream current condition target
SNR margin for a SHDSL line. The SNR margin is the difference
between the desired SNR and the actual SNR. Target SNR margin
is the desired SNR margin for a unit."
DEFVAL { 0 }
::= { hds12ShdslSpanConfProfileEntry 9 }

hds12ShdslSpanConfWorstCaseTargetMarginDown OBJECT-TYPE

SYNTAX Integer32(-10..21)

UNITS "dB"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object specifies the downstream worst case target SNR margin for a SHDSL line. The SNR margin is the difference between the desired SNR and the actual SNR. Target SNR margin is the desired SNR margin for a unit."

DEFVAL { 0 }

::= { hds12ShdslSpanConfProfileEntry 10 }

hds12ShdslSpanConfCurrCondTargetMarginUp OBJECT-TYPE

SYNTAX Integer32(-10..21)

UNITS "dB"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object specifies the upstream current condition target SNR margin for a SHDSL line. The SNR margin is the difference between the desired SNR and the actual SNR. Target SNR margin is the desired SNR margin for a unit."

DEFVAL { 0 }

::= { hds12ShdslSpanConfProfileEntry 11 }

hds12ShdslSpanConfWorstCaseTargetMarginUp OBJECT-TYPE

SYNTAX Integer32(-10..21)

UNITS "dB"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object specifies the upstream worst case target SNR margin for a SHDSL line. The SNR margin is the difference between the desired SNR and the actual SNR. Target SNR margin is the desired SNR margin for a unit."

DEFVAL { 0 }

::= { hds12ShdslSpanConfProfileEntry 12 }

hds12ShdslSpanConfUsedTargetMargins OBJECT-TYPE

SYNTAX BITS

```
{  
    currCondDown(0),  
    worstCaseDown(1),  
    currCondUp(2),  
    worstCaseUp(3)  
}
```

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"Indicates whether a target SNR margin is enabled or disabled. This is a bit-map of possible settings. The various bit positions are:

currCondDown - current condition downstream target SNR margin enabled

worstCaseDown - worst case downstream target SNR margin enabled

currCondUp - current condition upstream target SNR margin enabled

worstCaseUp - worst case upstream target SNR margin enabled."

DEFVAL { { currCondDown } }
::= { hds12ShdslSpanConfProfileEntry 13 }

hds12ShdslSpanConfReferenceClock OBJECT-TYPE

SYNTAX Hds12ShdslClockReferenceType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the clock reference for the STU-C in a SHDSL Line."

DEFVAL { localClk }
::= { hds12ShdslSpanConfProfileEntry 14 }

hds12ShdslSpanConfLineProbeEnable OBJECT-TYPE

SYNTAX INTEGER
{
disable(1),
enable(2)
}

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object enables/disables support for Line Probe of the units in a SHDSL line. When Line Probe is enabled, the system performs Line Probing to find the best possible rate. If Line probe is disabled, the rate adaptation phase is skipped to shorten set up time."

DEFVAL { disable }
::= { hds12ShdslSpanConfProfileEntry 15 }

hds12ShdslSpanConfProfileRowStatus OBJECT-TYPE

SYNTAX RowStatus
 MAX-ACCESS read-create
 STATUS current
 DESCRIPTION

"This object controls creation/deletion of the associated entry in this table per the semantics of RowStatus. If an active entry is referenced in hds12ShdslSpanConfProfile, the entry MUST remain active until all references are removed."

::= { hds12ShdslSpanConfProfileEntry 16 }

-- Segment Endpoint Alarm Configuration Profile group
 --

hds12ShdslEndpointAlarmConfProfileTable OBJECT-TYPE

SYNTAX SEQUENCE OF Hds12ShdslEndpointAlarmConfProfileEntry
 MAX-ACCESS not-accessible
 STATUS current
 DESCRIPTION

"This table supports definitions of alarm configuration profiles for HDSL2/SHDSL segment endpoints. This table MUST be maintained in a persistent manner."

::= { hds12ShdslMibObjects 11 }

hds12ShdslEndpointAlarmConfProfileEntry OBJECT-TYPE

SYNTAX Hds12ShdslEndpointAlarmConfProfileEntry
 MAX-ACCESS not-accessible
 STATUS current
 DESCRIPTION

"Each entry corresponds to a single alarm configuration profile. Each profile contains a set of parameters for setting alarm thresholds for various performance attributes monitored at HDSL2/SHDSL segment endpoints. Profiles may be created/deleted using the row creation/deletion mechanism via hds12ShdslEndpointAlarmConfProfileRowStatus. If an active entry is referenced in either hds12ShdslSpanConfAlarmProfile or hds12ShdslEndpointAlarmConfProfile, the entry MUST remain active until all references are removed."

INDEX { IMPLIED hds12ShdslEndpointAlarmConfProfileName }

::= { hds12ShdslEndpointAlarmConfProfileTable 1 }

Hds12ShdslEndpointAlarmConfProfileEntry ::=

SEQUENCE

{

hds12ShdslEndpointAlarmConfProfileName	SnmpAdminString,
hds12ShdslEndpointThreshLoopAttenuation	Integer32,
hds12ShdslEndpointThreshSNRMargin	Integer32,
hds12ShdslEndpointThreshES	

Hds12ShdslPerfIntervalThreshold,


```
hds12ShdslEndpointThreshSES
                                Hds12ShdslPerfIntervalThreshold,
hds12ShdslEndpointThreshCRCAnomalies    Integer32,
hds12ShdslEndpointThreshLOSWS
                                Hds12ShdslPerfIntervalThreshold,
hds12ShdslEndpointThreshUAS
                                Hds12ShdslPerfIntervalThreshold,
hds12ShdslEndpointAlarmConfProfileRowStatus  RowStatus
}
```

hds12ShdslEndpointAlarmConfProfileName OBJECT-TYPE

```
SYNTAX      SnmpAdminString (SIZE(1..32))
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION
    "This object is the unique index associated with this profile."
 ::= { hds12ShdslEndpointAlarmConfProfileEntry 1 }
```

hds12ShdslEndpointThreshLoopAttenuation OBJECT-TYPE

```
SYNTAX      Integer32(-127..128)
UNITS       "dB"
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "This object configures the loop attenuation alarm threshold.
    When the current value of hds12ShdslEndpointCurrAtn reaches
    or exceeds this threshold, a hds12ShdslLoopAttenCrossing
    MAY be generated."
DEFVAL      { 0 }
 ::= { hds12ShdslEndpointAlarmConfProfileEntry 2 }
```

hds12ShdslEndpointThreshSNRMargin OBJECT-TYPE

```
SYNTAX      Integer32(-127..128)
UNITS       "dB"
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "This object configures the SNR margin alarm threshold.
    When the current value of hds12ShdslEndpointCurrSnrMgn
    reaches or drops below this threshold, a
    hds12ShdslSNRMarginCrossing MAY be generated."
DEFVAL      { 0 }
 ::= { hds12ShdslEndpointAlarmConfProfileEntry 3 }
```

hds12ShdslEndpointThreshES OBJECT-TYPE

```
SYNTAX      Hds12ShdslPerfIntervalThreshold
UNITS       "seconds"
MAX-ACCESS  read-create
```


STATUS current

DESCRIPTION

"This object configures the threshold for the number of errored seconds (ES) within any given 15-minute performance data collection interval. If the value of errored seconds in a particular 15-minute collection interval reaches/exceeds this value, a hds12ShdslPerfESThresh MAY be generated. At most one notification will be sent per interval per endpoint."

DEFVAL { 0 }

::= { hds12ShdslEndpointAlarmConfProfileEntry 4 }

hds12ShdslEndpointThreshSES OBJECT-TYPE

SYNTAX Hds12ShdslPerfIntervalThreshold

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the threshold for the number of severely errored seconds (SES) within any given 15-minute performance data collection interval. If the value of severely errored seconds in a particular 15-minute collection interval reaches/exceeds this value, a hds12ShdslPerfSESThresh MAY be generated. At most one notification will be sent per interval per endpoint."

DEFVAL { 0 }

::= { hds12ShdslEndpointAlarmConfProfileEntry 5 }

hds12ShdslEndpointThreshCRCAnomalies OBJECT-TYPE

SYNTAX Integer32

UNITS "detected CRC Anomalies"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the threshold for the number of CRC anomalies within any given 15-minute performance data collection interval. If the value of CRC anomalies in a particular 15-minute collection interval reaches/exceeds this value, a hds12ShdslPerfCRCAnomaliesThresh MAY be generated. At most one notification will be sent per interval per endpoint."

DEFVAL { 0 }

::= { hds12ShdslEndpointAlarmConfProfileEntry 6 }

hds12ShdslEndpointThreshLOSWS OBJECT-TYPE

SYNTAX Hds12ShdslPerfIntervalThreshold

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the threshold for the number of Loss of Sync Word (LOSW) Seconds within any given 15-minute performance data collection interval. If the value of LOSW in a particular 15-minute collection interval reaches/exceeds this value, a hds12ShdslPerfLOSWSThresh MAY be generated. At most one notification will be sent per interval per endpoint."

DEFVAL { 0 }

::= { hds12ShdslEndpointAlarmConfProfileEntry 7 }

hds12ShdslEndpointThreshUAS OBJECT-TYPE

SYNTAX Hds12ShdslPerfIntervalThreshold

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object configures the threshold for the number of unavailable seconds (UAS) within any given 15-minute performance data collection interval. If the value of UAS in a particular 15-minute collection interval reaches/exceeds this value, a hds12ShdslPerfUASThresh MAY be generated. At most one notification will be sent per interval per endpoint."

DEFVAL { 0 }

::= { hds12ShdslEndpointAlarmConfProfileEntry 8 }

hds12ShdslEndpointAlarmConfProfileRowStatus OBJECT-TYPE

SYNTAX RowStatus

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object controls creation/deletion of the associated entry in this table as per the semantics of RowStatus. If an active entry is referenced in either hds12ShdslSpanConfAlarmProfile or hds12ShdslEndpointAlarmConfProfile, the entry MUST remain active until all references are removed."

::= { hds12ShdslEndpointAlarmConfProfileEntry 9 }

-- Notifications Group

--

hds12ShdslNotifications OBJECT IDENTIFIER ::= { hds12ShdslMIB 0 }

hds12ShdslLoopAttenCrossing NOTIFICATION-TYPE
OBJECTS


```
{
hds12ShdslEndpointCurrAtn,
hds12ShdslEndpointThreshLoopAttenuation
}
STATUS      current
DESCRIPTION
    "This notification indicates that the loop attenuation
    threshold (as per the hds12ShdslEndpointThreshLoopAttenuation
    value) has been reached/exceeded for the HDSL2/SHDSL segment
    endpoint."
 ::= { hds12ShdslNotifications 1 }
```

hds12ShdslSNRMarginCrossing NOTIFICATION-TYPE

```
OBJECTS
{
hds12ShdslEndpointCurrSnrMgn,
hds12ShdslEndpointThreshSNRMargin
}
STATUS      current
DESCRIPTION
    "This notification indicates that the SNR margin threshold (as
    per the hds12ShdslEndpointThreshSNRMargin value) has been
    reached/exceeded for the HDSL2/SHDSL segment endpoint."
 ::= { hds12ShdslNotifications 2 }
```

hds12ShdslPerfESThresh NOTIFICATION-TYPE

```
OBJECTS
{
hds12ShdslEndpointCurr15MinES,
hds12ShdslEndpointThreshES
}
STATUS      current
DESCRIPTION
    "This notification indicates that the errored seconds
    threshold (as per the hds12ShdslEndpointThreshES value)
    has been reached/exceeded for the HDSL2/SHDSL segment
    endpoint."
 ::= { hds12ShdslNotifications 3 }
```

hds12ShdslPerfSESThresh NOTIFICATION-TYPE

```
OBJECTS
{
hds12ShdslEndpointCurr15MinSES,
hds12ShdslEndpointThreshSES
}
STATUS      current
DESCRIPTION
    "This notification indicates that the severely errored seconds
```


threshold (as per the hds12Shds1EndpointThreshSES value) has been reached/exceeded for the HDSL2/SHDSL Segment Endpoint."
 ::= { hds12Shds1Notifications 4 }

hds12Shds1PerfCRCAnomaliesThresh NOTIFICATION-TYPE

OBJECTS

```
{  
  hds12Shds1EndpointCurr15MinCRCAnomalies,  
  hds12Shds1EndpointThreshCRCAnomalies  
}
```

STATUS current

DESCRIPTION

"This notification indicates that the CRC anomalies threshold (as per the hds12Shds1EndpointThreshCRCAnomalies value) has been reached/exceeded for the HDSL2/SHDSL Segment Endpoint."
 ::= { hds12Shds1Notifications 5 }

hds12Shds1PerfLOSWSThresh NOTIFICATION-TYPE

OBJECTS

```
{  
  hds12Shds1EndpointCurr15MinLOSWS,  
  hds12Shds1EndpointThreshLOSWS  
}
```

STATUS current

DESCRIPTION

"This notification indicates that the LOSW seconds threshold (as per the hds12Shds1EndpointThreshLOSWS value) has been reached/exceeded for the HDSL2/SHDSL segment endpoint."
 ::= { hds12Shds1Notifications 6 }

hds12Shds1PerfUASThresh NOTIFICATION-TYPE

OBJECTS

```
{  
  hds12Shds1EndpointCurr15MinUAS,  
  hds12Shds1EndpointThreshUAS  
}
```

STATUS current

DESCRIPTION

"This notification indicates that the unavailable seconds threshold (as per the hds12Shds1EndpointThreshUAS value) has been reached/exceeded for the HDSL2/SHDSL segment endpoint."
 ::= { hds12Shds1Notifications 7 }

hds12Shds1SpanInvalidNumRepeaters NOTIFICATION-TYPE

OBJECTS

```
{  
  hds12Shds1SpanConfNumRepeaters  
}
```


STATUS current

DESCRIPTION

"This notification indicates that a mismatch has been detected between the number of repeater/regenerator units configured for a HDSL2/SHDSL line via the hdsl2ShdslSpanConfNumRepeaters object and the actual number of repeater/regenerator units discovered via the EOC."

::= { hdsl2ShdslNotifications 8 }

hdlsl2ShdslLoopbackFailure NOTIFICATION-TYPE

OBJECTS

{
 hdlsl2ShdslMaintLoopbackConfig
}

STATUS current

DESCRIPTION

"This notification indicates that an endpoint maintenance loopback command failed for an HDSL2/SHDSL segment."

::= { hdsl2ShdslNotifications 9 }

hdlsl2ShdslpowerBackoff NOTIFICATION-TYPE

OBJECTS

{
 hdlsl2ShdslEndpointCurrStatus
}

STATUS current

DESCRIPTION

"This notification indicates that the bit setting for powerBackoff in the hdsl2ShdslEndpointCurrStatus object for this endpoint has changed."

::= { hdsl2ShdslNotifications 10 }

hdlsl2ShdsldeviceFault NOTIFICATION-TYPE

OBJECTS

{
 hdlsl2ShdslEndpointCurrStatus
}

STATUS current

DESCRIPTION

"This notification indicates that the bit setting for deviceFault in the hdsl2ShdslEndpointCurrStatus object for this endpoint has changed."

::= { hdsl2ShdslNotifications 11 }

hdlsl2ShdslcdcContinuityFault NOTIFICATION-TYPE

OBJECTS

{
 hdlsl2ShdslEndpointCurrStatus
}


```
}
STATUS      current
DESCRIPTION
    "This notification indicates that the bit setting for
    dcContinuityFault in the hds12ShdslEndpointCurrStatus object
    for this endpoint has changed."
 ::= { hds12ShdslNotifications 12 }
```

hds12ShdslconfigInitFailure NOTIFICATION-TYPE

```
OBJECTS
{
    hds12ShdslEndpointCurrStatus
}
STATUS      current
DESCRIPTION
    "This notification indicates that the bit setting for
    configInitFailure in the hds12ShdslEndpointCurrStatus object
    for this endpoint has changed."
 ::= { hds12ShdslNotifications 13 }
```

hds12ShdslprotocolInitFailure NOTIFICATION-TYPE

```
OBJECTS
{
    hds12ShdslEndpointCurrStatus
}
STATUS      current
DESCRIPTION
    "This notification indicates that the bit setting for
    protocolInitFailure in the hds12ShdslEndpointCurrStatus
    object for this endpoint has changed."
 ::= { hds12ShdslNotifications 14 }
```

hds12ShdslnoNeighborPresent NOTIFICATION-TYPE

```
OBJECTS
{
    hds12ShdslEndpointCurrStatus
}
STATUS      current
DESCRIPTION
    "This notification indicates that the bit setting for
    noNeighborPresent in the hds12ShdslEndpointCurrStatus object
    for this endpoint has changed."
 ::= { hds12ShdslNotifications 15 }
```

hds12ShdslLocalPowerLoss NOTIFICATION-TYPE

```
OBJECTS
{
    hds12ShdslInvVendorID
}
```



```
    }
    STATUS      current
    DESCRIPTION
        "This notification indicates impending unit failure due to
        loss of local power (last gasp).\"
    ::= { hds12Shds1Notifications 16 }

-- conformance information
--

hds12Shds1Conformance OBJECT IDENTIFIER ::= { hds12Shds1MIB 3 }
hds12Shds1Groups      OBJECT IDENTIFIER ::=
    { hds12Shds1Conformance 1 }
hds12Shds1Compliances OBJECT IDENTIFIER ::=
    { hds12Shds1Conformance 2 }

-- agent compliance statements

hds12Shds1LineMibCompliance MODULE-COMPLIANCE
    STATUS deprecated
    DESCRIPTION
        "The compliance statement for SNMP entities which implement
        HDSL2 and SHDSL. The version of SHDSL supported in this
        compliance statement is g.shds1.

        **** This compliance statement is deprecated. ****"
    MODULE
    MANDATORY-GROUPS
    {
        hds12Shds1SpanConfGroup,
        hds12Shds1SpanStatusGroup,
        hds12Shds1InventoryGroup,
        hds12Shds1EndpointConfGroup,
        hds12Shds1EndpointCurrGroup,
        hds12Shds115MinIntervalGroup,
        hds12Shds11DayIntervalGroup,
        hds12Shds1MaintenanceGroup,
        hds12Shds1EndpointAlarmConfGroup,
        hds12Shds1NotificationGroup
    }

GROUP hds12Shds1InventoryShds1Group
    DESCRIPTION
        "Support for this group is only required for implementations
        supporting SHDSL lines."

GROUP hds12Shds1SpanShds1StatusGroup
    DESCRIPTION
```


"Support for this group is only required for implementations supporting SHDSL lines."

GROUP hds12ShdslSpanConfProfileGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

OBJECT hds12ShdslSpanConfWireInterface

SYNTAX INTEGER
{
twoWire(1),
fourWire(2)
}

DESCRIPTION

"An implementation only has to support the range as applicable for the original g.shdsl specification defined in [RFC 3276](#)."

OBJECT hds12ShdslStatusMaxAttainableLineRate

SYNTAX Unsigned32(0..4112000)

DESCRIPTION

"An implementation only has to support the range as applicable for the original g.shdsl specification defined in [RFC 3276](#)."

OBJECT hds12ShdslStatusActualLineRate

SYNTAX Unsigned32(0..4112000)

DESCRIPTION

"An implementation only has to support the range as applicable for the original g.shdsl specification defined in [RFC 3276](#)."

OBJECT hds12ShdslSpanConfMinLineRate

SYNTAX Unsigned32(0..4112000)

DESCRIPTION

"An implementation only has to support the range as applicable for the original g.shdsl specification defined in [RFC 3276](#)."

OBJECT hds12ShdslSpanConfMaxLineRate

SYNTAX Unsigned32(0..4112000)

DESCRIPTION

"An implementation only has to support the range as applicable for the original g.shdsl specification defined in [RFC 3276](#)."

::= { hds12ShdslCompliances 1 }

hds12GshdslbisLineMibCompliance MODULE-COMPLIANCE

STATUS current

DESCRIPTION

"The compliance statement for SNMP entities which implement HDSL2 and SHDSL. The version of SHDSL supported in this compliance statement is g.shdsl.bis."

MODULE

MANDATORY-GROUPS

```
{
hds12ShdslSpanConfGroup,
hds12ShdslSpanStatusGroup,
hds12ShdslInventoryGroup,
hds12ShdslEndpointConfGroup,
hds12ShdslEndpointCurrGroup,
hds12Shdsl15MinIntervalGroup,
hds12Shdsl1DayIntervalGroup,
hds12ShdslMaintenanceGroup,
hds12ShdslEndpointAlarmConfGroup,
hds12ShdslNotificationGroup
}
```

GROUP hds12ShdslInventoryShdslGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

GROUP hds12ShdslSpanShdslStatusGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

GROUP hds12ShdslSpanConfProfileGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

GROUP hds12ShdslWirePairGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

GROUP hds12ShdslPayloadRateGroup

DESCRIPTION

"Support for this group is only required for implementations supporting SHDSL lines."

```
::= { hds12ShdslCompliances 2 }
```



```
-- units of conformance
--
```

```
hds12Shds1SpanConfGroup OBJECT-GROUP
```

```
OBJECTS
```

```
{
  hds12Shds1SpanConfNumRepeaters,
  hds12Shds1SpanConfProfile,
  hds12Shds1SpanConfAlarmProfile
}
```

```
STATUS      current
```

```
DESCRIPTION
```

```
  "This group supports objects for configuring span related
   parameters for HDSL2/SHDSL lines."
```

```
::= { hds12Shds1Groups 1 }
```

```
hds12Shds1SpanStatusGroup OBJECT-GROUP
```

```
OBJECTS
```

```
{
  hds12Shds1StatusNumAvailRepeaters
}
```

```
STATUS      current
```

```
DESCRIPTION
```

```
  "This group supports objects for retrieving span related
   status for HDSL2/SHDSL lines."
```

```
::= { hds12Shds1Groups 2 }
```

```
hds12Shds1InventoryShds1Group OBJECT-GROUP
```

```
OBJECTS
```

```
{
  hds12Shds1InvTransmissionModeCapability
}
```

```
STATUS      current
```

```
DESCRIPTION
```

```
  "This group supports objects for retrieving SHDSL-specific
   inventory information."
```

```
::= { hds12Shds1Groups 3 }
```

```
hds12Shds1SpanShds1StatusGroup OBJECT-GROUP
```

```
OBJECTS
```

```
{
  hds12Shds1StatusMaxAttainableLineRate,
  hds12Shds1StatusActualLineRate,
  hds12Shds1StatusTransmissionModeCurrent
}
```

```
STATUS      current
```

```
DESCRIPTION
```

```
  "This group supports objects for retrieving SHDSL-specific
```



```
    span related status."  
 ::= { hds12ShdslGroups 4 }
```

hds12ShdslInventoryGroup OBJECT-GROUP

OBJECTS

```
{  
  hds12ShdslInvVendorID,  
  hds12ShdslInvVendorModelNumber,  
  hds12ShdslInvVendorSerialNumber,  
  hds12ShdslInvVendorEOCSoftwareVersion,  
  hds12ShdslInvStandardVersion,  
  hds12ShdslInvVendorListNumber,  
  hds12ShdslInvVendorIssueNumber,  
  hds12ShdslInvVendorSoftwareVersion,  
  hds12ShdslInvEquipmentCode,  
  hds12ShdslInvVendorOther  
}
```

STATUS current

DESCRIPTION

"This group supports objects that provide unit inventory information about the units in HDSL2/SHDSL lines."

```
::= { hds12ShdslGroups 5 }
```

hds12ShdslEndpointConfGroup OBJECT-GROUP

OBJECTS

```
{  
  hds12ShdslEndpointCurrAtn  
}
```

STATUS current

DESCRIPTION

"This group supports objects for configuring parameters for segment endpoints in HDSL2/SHDSL lines."

```
::= { hds12ShdslGroups 6 }
```

hds12ShdslEndpointCurrGroup OBJECT-GROUP

OBJECTS

```
{  
  hds12ShdslEndpointCurrAtn,  
  hds12ShdslEndpointCurrSnrMgn,  
  hds12ShdslEndpointCurrStatus,  
  hds12ShdslEndpointES,  
  hds12ShdslEndpointSES,  
  hds12ShdslEndpointCRCAnomalies,  
  hds12ShdslEndpointLOSWS,  
  hds12ShdslEndpointUAS,  
  hds12ShdslEndpointCurr15MinTimeElapsed,  
  hds12ShdslEndpointCurr15MinES,  
  hds12ShdslEndpointCurr15MinSES,  
}
```



```
hds12ShdslEndpointCurr15MinCRCAnomalies,  
hds12ShdslEndpointCurr15MinLOSWS,  
hds12ShdslEndpointCurr15MinUAS,  
hds12ShdslEndpointCurr1DayTimeElapsed,  
hds12ShdslEndpointCurr1DayES,  
hds12ShdslEndpointCurr1DaySES,  
hds12ShdslEndpointCurr1DayCRCAnomalies,  
hds12ShdslEndpointCurr1DayLOSWS,  
hds12ShdslEndpointCurr1DayUAS  
}
```

STATUS current

DESCRIPTION

"This group supports objects which provide current status and performance measurements relating to segment endpoints in HDSL2/SHDSL lines."

::= { hds12ShdslGroups 7 }

hds12Shdsl15MinIntervalGroup OBJECT-GROUP

OBJECTS

```
{  
hds12Shdsl15MinIntervalES,  
hds12Shdsl15MinIntervalSES,  
hds12Shdsl15MinIntervalCRCAnomalies,  
hds12Shdsl15MinIntervalLOSWS,  
hds12Shdsl15MinIntervalUAS  
}
```

STATUS current

DESCRIPTION

"This group supports objects which maintain historic performance measurements relating to segment endpoints in HDSL2/SHDSL lines in 15-minute intervals."

::= { hds12ShdslGroups 8 }

hds12Shdsl1DayIntervalGroup OBJECT-GROUP

OBJECTS

```
{  
hds12Shdsl1DayIntervalMoniSecs,  
hds12Shdsl1DayIntervalES,  
hds12Shdsl1DayIntervalSES,  
hds12Shdsl1DayIntervalCRCAnomalies,  
hds12Shdsl1DayIntervalLOSWS,  
hds12Shdsl1DayIntervalUAS  
}
```

STATUS current

DESCRIPTION

"This group supports objects which maintain historic performance measurements relating to segment endpoints in HDSL2/SHDSL lines in 1-day intervals."


```
::= { hds12Shds1Groups 9 }
```

hds12Shds1MaintenanceGroup OBJECT-GROUP

OBJECTS

```
{  
  hds12Shds1MaintLoopbackConfig,  
  hds12Shds1MaintTipRingReversal,  
  hds12Shds1MaintPowerBackOff,  
  hds12Shds1MaintSoftRestart,  
  hds12Shds1MaintLoopbackTimeout,  
  hds12Shds1MaintUnitPowerSource  
}
```

STATUS current

DESCRIPTION

"This group supports objects that provide support for maintenance actions for HDSL2/SHDSL lines."

```
::= { hds12Shds1Groups 10 }
```

hds12Shds1EndpointAlarmConfGroup OBJECT-GROUP

OBJECTS

```
{  
  hds12Shds1EndpointAlarmConfProfile,  
  hds12Shds1EndpointThreshLoopAttenuation,  
  hds12Shds1EndpointThreshSNRMargin,  
  hds12Shds1EndpointThreshES,  
  hds12Shds1EndpointThreshSES,  
  hds12Shds1EndpointThreshCRCAnomalies,  
  hds12Shds1EndpointThreshLOSWS,  
  hds12Shds1EndpointThreshUAS,  
  hds12Shds1EndpointAlarmConfProfileRowStatus  
}
```

STATUS current

DESCRIPTION

"This group supports objects that allow configuration of alarm thresholds for various performance parameters for HDSL2/SHDSL lines."

```
::= { hds12Shds1Groups 11 }
```

hds12Shds1NotificationGroup NOTIFICATION-GROUP

NOTIFICATIONS

```
{  
  hds12Shds1LoopAttenCrossing,  
  hds12Shds1SNRMarginCrossing,  
  hds12Shds1PerfESThresh,  
  hds12Shds1PerfSESThresh,  
  hds12Shds1PerfCRCAnomaliesThresh,  
  hds12Shds1PerfLOSWSThresh,  
  hds12Shds1PerfUASThresh,  
}
```



```
hds12ShdslSpanInvalidNumRepeaters,
hds12ShdslLoopbackFailure,
hds12ShdslpowerBackoff,
hds12ShdsldeviceFault,
hds12ShdslcdcContinuityFault,
hds12ShdslconfigInitFailure,
hds12ShdslprotocolInitFailure,
hds12ShdslnoNeighborPresent,
hds12ShdslLocalPowerLoss
}
STATUS          current
DESCRIPTION
    "This group supports notifications of significant conditions
    associated with HDSL2/SHDSL lines."
::= { hds12ShdslGroups 12 }
```

hds12ShdslSpanConfProfileGroup OBJECT-GROUP

```
OBJECTS
{
hds12ShdslSpanConfWireInterface,
hds12ShdslSpanConfMinLineRate,
hds12ShdslSpanConfMaxLineRate,
hds12ShdslSpanConfPSD,
hds12ShdslSpanConfTransmissionMode,
hds12ShdslSpanConfRemoteEnabled,
hds12ShdslSpanConfPowerFeeding,
hds12ShdslSpanConfCurrCondTargetMarginDown,
hds12ShdslSpanConfWorstCaseTargetMarginDown,
hds12ShdslSpanConfCurrCondTargetMarginUp,
hds12ShdslSpanConfWorstCaseTargetMarginUp,
hds12ShdslSpanConfUsedTargetMargins,
hds12ShdslSpanConfReferenceClock,
hds12ShdslSpanConfLineProbeEnable,
hds12ShdslSpanConfProfileRowStatus
}
STATUS          current
DESCRIPTION
    "This group supports objects that constitute configuration
    profiles for configuring span related parameters in SHDSL
    lines."
::= { hds12ShdslGroups 13 }
```

hds12ShdslWirePairGroup OBJECT-GROUP

```
OBJECTS
{
hds12ShdslEndpointCurrTipRingReversal,
hds12ShdslEndpointCurrActivationState
}
```



```
STATUS      current
DESCRIPTION
    "This group supports objects which provide the status
      of SHDSL-specific wire pairs."
 ::= { hds12ShdslGroups 14 }

hds12ShdslPayloadRateGroup OBJECT-GROUP
OBJECTS
{
    hds12ShdslStatusMaxAttainablePayloadRate,
    hds12ShdslStatusActualPayloadRate
}
STATUS      current
DESCRIPTION
    "This group supports object for retrieving payload rates
      which excludes any framing overhead."
 ::= { hds12ShdslGroups 15 }

END
```

4. Implementation Analysis

A management application which supports [RFC 3276](#) could mistakenly flag a unit which responds with a rate or wire pair which exceeds the ranges and/or enumerations specified in [RFC 3276](#). For example, a G.shdsl.bis line with four wire pairs would report statistics for wire pairs that do not exist in [RFC 3276](#). That is, a GET-NEXT request issues with the object identifier:

```
hds12ShdslEndpointCurrAtn.1.1.1.2
```

might return

```
hds12ShdslEndpointCurrAtn.1.1.1.3 = 0
```

with a G.shdsl.bis unit and

```
hds12ShdslEndpointCurrSnrMgn.1.1.1.1 = 0
```

with an HDSL2 unit as these objects are indexed by

```
INDEX { ifIndex, hds12ShdslInvIndex, hds12ShdslendpointSide,
        hds12ShdslEndpointWirePair }
```

A management application intended to manage G.shdsl.bis agents SHOULD be modified to accept this sequence.

One should note that this same unmodified management application is still capable of managing G.shdsl.bis agents albeit to the degree of G.SHDSL (non-bis) limitations. That is, it can create and monitor configurations limited to two wire pairs with an upper rate limit of 4112000 bits/second.

5. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

o hds12ShdslSpanConfTable

The table consists of the following objects that support SET operations:

- * hds12ShdslSpanConfNumRepeaters
- * hds12ShdslSpanConfProfile
- * hds12ShdslSpanConfAlarmProfile

Unauthorized changes to hds12ShdslSpanConfNumRepeaters could result in a hds12ShdslSpanInvalidNumRepeaters notification. Note the discussion on hds12ShdslSpanInvalidNumRepeaters in the Notifications Section above.

Unauthorized changes to hds12ShdslSpanConfProfile could have an adverse operational effect on a span. Reference the hds12ShdslSpanConfProfileTable discussion below.

Unauthorized changes to hds12ShdslSpanConfAlarmProfile could have a contrary effect on notifications. Reference the hds12ShdslEndpointAlarmConfProfileTable discussion below.

o hds12ShdslEndpointConfTable

This table contains one object, hds12ShdslEndpointAlarmConfProfile, that supports SET operations. Unauthorized changes could have an undesirable notifications. Reference the hds12ShdslEndpointAlarmConfProfileTable discussion below.

o hds12ShdslEndpointMaintTable

The table consists of the following objects that support SET operations:

- * hds12ShdslMaintLoopbackConfig
- * hds12ShdslMaintPowerBackoff
- * hds12ShdslMaintSoftRestart

Unauthorized changes to hds12ShdslMaintLoopbackConfig could prevent end-to-end data transfer due to an activation of a loopback.

Unauthorized changes to hds12ShdslMaintPowerBackoff could result in an increased in bundle interference.

Unauthorized changes to hds12ShdslMaintSoftRestart could result in a temporary interruption of end-to-end data transfer as the result of the triggering of a soft restart.

o hds12ShdslUnitMaintTable

This table contains one object, hds12ShdslMaintLoopbackTimeout, that supports SET operations. An unauthorized change to this object could result in the timeout value for loopbacks being increased, decreased, or disabled.

o hds12ShdslSpanConfProfileTable

The table consists of the following objects that support SET operations:

- * hds12ShdslSpanConfWireInterface
- * hds12ShdslSpanConfMinLineRate
- * hds12ShdslSpanConfMaxLineRate
- * hds12ShdslSpanConfPSD
- * hds12ShdslSpanConfTransmissionMode
- * hds12ShdslSpanConfRemoteEnabled
- * hds12ShdslSpanConfPowerFeeding
- * hds12ShdslSpanConfCurrCondTargetMarginDown
- * hds12ShdslSpanConfWorstCaseTargetMarginDown
- * hds12ShdslSpanConfCurrCondTargetMarginUp
- * hds12ShdslSpanConfWorstCaseTargetMarginUp
- * hds12ShdslSpanConfUsedTargetMargins
- * hds12ShdslSpanConfReferenceClock
- * hds12ShdslSpanConfLineProbeEnable

* hds12ShdslSpanConfProfileRowStatus

Setting any of the objects to an incorrect value could have an adverse operational effect on a span.

Unauthorized changes to the hds12ShdslSpanConfWireInterface could result in the failure of a span to achieve activation to a state that would permit data flow. For example, setting this object to six-wire or eight-wire operation when one of the units in the span only supports two-wire or four-wire operation would likely prevent an expected end-to-end data transfer capability.

Unauthorized changes to hds12ShdslSpanConfMinLineRate or hds12ShdslSpanConfMaxLineRate could have an adverse effect on performance. The range of allowable line rates could be altered such that the span may not be able to train to a line rate that would permit any end-user data to traverse the span or the span could train to a line rate that is either greater than or less than the line rate that the provider has pledged.

Unauthorized changes to hds12ShdslSpanConfPSD or hds12ShdslSpanConfTransmissionMode could have a detrimental effect loop reach, performance, or spectral compatibility.

Unauthorized changes to hds12ShdslSpanConfRemoteEnable could alter the remote management ability of units.

Unauthorized changes to hds12ShdslSpanConfPowerFeeding could shutdown units that are expected to be feed power remotely. Changing the configuration such that wetting current is not supplied may result in corrosion of electrical contacts.

Unauthorized changes to hds12ShdslSpanConfCurrCondTargetMarginDown, hds12ShdslSpanConfWorstCaseTargetMarginDown, hds12ShdslSpanConfCurrCondTargetMarginUp, hds12ShdslSpanConfWorstCaseTargetMarginUp, or hds12ShdslSpanConfUsedTargetMargins could result in invalid parameters used to determine if a data rate can be supported under current and worst-case noise.

Unauthorized changes to hds12ShdslSpanConfReferenceClock could result in the selection of a clock source which might either prevent any data from being transferred or impair data transfer. In addition, an increase in CRC anomalies may be experienced.

Unauthorized changes to hds12ShdslSpanConfLineProbeEnable could have a negative effect on selecting the optimum rate or power

level based on current line conditions.

Unauthorized changes to row status could result in unwanted profiles being created or brought into service. Also, changes to the row status could result in profiles being inadvertently deleted or taken out of service.

o hds12ShdslEndpointAlarmConfProfileTable

The table consists of the following objects that support SET operations:

- * hds12ShdslEndpointThreshLoopAttenuation
- * hds12ShdslEndpointThreshSNRMargin
- * hds12ShdslEndpointThreshES
- * hds12ShdslEndpointThreshSES
- * hds12ShdslEndpointThreshCRCAnomalies
- * hds12ShdslEndpointThreshLOSWS
- * hds12ShdslEndpointThreshUAS
- * hds12ShdslEndpointAlarmConfProfileRowStatus

Increasing any of the threshold values could result a notification being suppressed or deferred. Setting a threshold to 0 could result in a notification being suppressed. Suppressing or deferring a notification could prevent the timely delivery of important diagnostic information. Decreasing any of the threshold values could result in a notification being sent from the network falsely reporting a threshold crossing.

Changing a threshold value could also have an impact on the amount of notifications the agent sends. This document adds a paragraph, which was not in [RFC 3276](#) [[RFC3276](#)], to the Notifications Section which provides general guidance to the rate limiting of notifications. Agent implementations not adhering to the rate-limiting desires could result in notifications being generated at an uncontrolled rate. Unauthorized changes to a threshold value could result in an undesired notification rate.

Unauthorized changes to row status could result in unwanted profiles being created or brought into service. Also, changes to the row status could result in profiles being inadvertently deleted or taken out of service.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over

the network via SNMP. These are the tables and objects and their sensitivity/vulnerability:

o hds12ShdslInventoryTable

Access to these objects would allow an intruder to obtain information about which vendor's equipment is in use on the network. Further, such information is considered sensitive in many environments for competitive reasons.

- * hds12ShdslInvVendorID
- * hds12ShdslInvVendorModelNumber
- * hds12ShdslInvVendorSerialNumber
- * hds12ShdslInvVendorEOCSoftwareVersion
- * hds12ShdslInvStandardVersion
- * hds12ShdslInvVendorListNumber
- * hds12ShdslInvVendorIssueNumber
- * hds12ShdslInvVendorSoftwareVersion
- * hds12ShdslInvEquipmentCode
- * hds12ShdslInvVendorOther
- * hds12ShdslInvTransmissionModeCapability

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [\[RFC3410\]](#), [Section 8](#)), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

6. Acknowledgments

The authors are deeply grateful to the authors of the ADSL LINE MIB ([RFC 2662](#) [[RFC2662](#)]), Gregory Bathrick and Faye Ly, as much of the text and structure of this document originates in their documents.

The authors are also grateful to the authors of FR MFR MIB ([RFC 3020](#)

[[RFC3020](#)]], Prayson Pate, Bob Lynch, and Kenneth Rehbehn, as the majority of the Security Considerations section was lifted from their document.

The authors also acknowledge the importance of the contributions and suggestions regarding interface indexing structures received from David Horton of CITR.

The authors are extremely thankful to Bert Wijnen, Randy Presuhn, and C. M. Heard for their extensive review and the many suggestions they provided.

Other contributions were received from the following:

Matt Beanland (Extel Communications)
Philip Bergstresser (Adtran)
Steve Blackwell (Centillium)
Umberto Bonollo (NEC Australia)
John Egan (Metalink BroadBand)
Yagal Hachmon (RAD)
Mark Johnson (Red Point)
Sharon Mantin (Orckit)
Moti Morgenstern (ECI)
Raymond Murphy (Ericsson)
Lee Nipper (Verilink)
Randy Presuhn (BMC Software)
Katy Sherman (Orckit)
Mike Sneed (ECI)
Jon Turney (DSL Solutions)
Aron Wahl (Memotec)
Jim Wilson (for Mindspeed)
Bert Wijnen (Lucent)
Michael Wrobel (Memotec)

[7.](#) References

[7.1](#) Normative References

- [G.991.2] Blackwell, S., "Single-Pair High-Speed Digital Subscriber Line (SHDSL) Transceivers", ITU-T G.991.2, December 2003.
- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", [BCP 14](#), [RFC 2119](#), March 1997.
- [RFC2578] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Structure of Management Information Version 2 (SMIv2)", STD 58, [RFC 2578](#), April 1999.

- [RFC2579] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Textual Conventions for SMIV2", STD 58, [RFC 2579](#), April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIV2", STD 58, [RFC 2580](#), April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", [RFC 2863](#), June 2000.
- [RFC3411] Harrington, D., Presuhn, R., and B. Wijnen, "An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks", STD 62, [RFC 3411](#), December 2002.
- [RFC3593] Tesink, K., "Textual Conventions for MIB Modules Using Performance History Based on 15 Minute Intervals", [RFC 3593](#), September 2003.
- [T1E1.4] American National Standards Institute, "ANSI T1E1.4/2000-006", February 2000.

7.2 Informative References

- [RFC2662] Bathrick, G. and F. Ly, "Definitions of Managed Objects for the ADSL Lines", [RFC 2662](#), August 1999.
- [RFC3020] Pate, P., Lynch, B., and K. Rehbehn, "Definitions of Managed Objects for Monitoring and Controlling the UNI/NNI Multilink Frame Relay Function", [RFC 3020](#), December 2000.
- [RFC3276] Ray, B. and R. Abbi, "Definitions of Managed Objects for High Bit-Rate DSL - 2nd generation (HDSL2) and Single-Pair High-Speed Digital Subscriber Line (SHDSL) Lines Processing", [RFC 3276](#), May 2002.
- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", [RFC 3410](#), December 2002.
- [RFC3418] Presuhn, R., "Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)", STD 62, [RFC 3418](#), December 2002.

Authors' Addresses

Clay Sikes
Paradyne Networks, Inc.
8454 126th Ave. N.
Largo, FL 33773
US

Phone: +1 727 530 8257
Fax: +1 727 532 5698
Email: csikes@paradyne.com

Bob Ray
PESA Switching Systems, Inc.
330-A Wynn Drive
Huntsville, AL 35805
US

Phone: +1 256 726 9200 ext. 142
Fax: +1 256 726 9271
Email: rray@pesa.com

Rajesh Abbi
Alcatel USA
2912 Wake Forest Road
Raleigh, NC 27609-7860
US

Phone: +1 919-850-6194
Fax: +1 919-850-6670
Email: Rajesh.Abbi@alcatel.com

Intellectual Property Statement

The IETF takes no position regarding the validity or scope of any Intellectual Property Rights or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; nor does it represent that it has made any independent effort to identify any such rights. Information on the procedures with respect to rights in RFC documents can be found in [BCP 78](#) and [BCP 79](#).

Copies of IPR disclosures made to the IETF Secretariat and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this specification can be obtained from the IETF on-line IPR repository at <http://www.ietf.org/ipr>.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights that may cover technology that may be required to implement this standard. Please address the information to the IETF at ietf-ipr@ietf.org.

The IETF has been notified of intellectual property rights claimed in regard to some or all of the specification contained in this document. For more information consult the online list of claimed rights.

Disclaimer of Validity

This document and the information contained herein are provided on an "AS IS" basis and THE CONTRIBUTOR, THE ORGANIZATION HE/SHE REPRESENTS OR IS SPONSORED BY (IF ANY), THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Copyright Statement

Copyright (C) The Internet Society (2005). This document is subject to the rights, licenses and restrictions contained in [BCP 78](#), and except as set forth therein, the authors retain all their rights.

Acknowledgment

Funding for the RFC Editor function is currently provided by the Internet Society.

-- Paradyne Mail --