

Network Working Group  
Internet-Draft  
Intended status: Standards Track  
Expires: June 3, 2015

J. Quittek  
R. Winter  
T. Dietz  
NEC Europe Ltd.  
November 30, 2014

**Definition of Managed Objects for Battery Monitoring**  
**draft-ietf-eman-battery-mib-13**

**Abstract**

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines managed objects that provide information on the status of batteries in managed devices.

**Status of this Memo**

This Internet-Draft is submitted in full conformance with the provisions of [BCP 78](#) and [BCP 79](#).

Internet-Drafts are working documents of the Internet Engineering Task Force (IETF). Note that other groups may also distribute working documents as Internet-Drafts. The list of current Internet-Drafts is at <http://datatracker.ietf.org/drafts/current/>.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet-Drafts as reference material or to cite them other than as "work in progress."

This Internet-Draft will expire on June 3, 2015.

**Copyright Notice**

Copyright (c) 2014 IETF Trust and the persons identified as the document authors. All rights reserved.

This document is subject to [BCP 78](#) and the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>) in effect on the date of publication of this document. Please review these documents carefully, as they describe your rights and restrictions with respect to this document. Code Components extracted from this document must include Simplified BSD License text as described in Section 4.e of the Trust Legal Provisions and are provided without warranty as described in the Simplified BSD License.

## Table of Contents

<a href="#">1.</a>	Introduction . . . . .	<a href="#">3</a>
<a href="#">2.</a>	The Internet-Standard Management Framework . . . . .	<a href="#">4</a>
<a href="#">3.</a>	Design of the Battery MIB Module . . . . .	<a href="#">5</a>
<a href="#">3.1.</a>	MIB Module Structure . . . . .	<a href="#">5</a>
<a href="#">3.2.</a>	Battery Technologies . . . . .	<a href="#">7</a>
<a href="#">3.2.1.</a>	Guidelines for Adding Battery Technologies . . . . .	<a href="#">8</a>
<a href="#">3.3.</a>	Battery Identification . . . . .	<a href="#">8</a>
<a href="#">3.4.</a>	Charging Cycles . . . . .	<a href="#">9</a>
<a href="#">4.</a>	Definitions . . . . .	<a href="#">9</a>
<a href="#">5.</a>	Security Considerations . . . . .	<a href="#">31</a>
<a href="#">6.</a>	IANA Considerations . . . . .	<a href="#">33</a>
<a href="#">6.1.</a>	SMI Object Identifier Registration . . . . .	<a href="#">33</a>
<a href="#">6.2.</a>	Battery Technology Registration . . . . .	<a href="#">33</a>
<a href="#">7.</a>	Acknowledgements . . . . .	<a href="#">34</a>
<a href="#">8.</a>	References . . . . .	<a href="#">34</a>
<a href="#">8.1.</a>	Normative References . . . . .	<a href="#">34</a>
<a href="#">8.2.</a>	Informative References . . . . .	<a href="#">34</a>
	Authors' Addresses . . . . .	<a href="#">35</a>



## 1. Introduction

Today, more and more managed devices contain batteries that supply them with power when disconnected from electrical power distribution grids. Common examples are nomadic and mobile devices, such as notebook computers, netbooks, and smart phones. The status of batteries in such a device, particularly the charging status is typically controlled by automatic functions that act locally on the device and manually by users of the device.

In addition to this, there is a need to monitor battery status of these devices by network management systems. This document defines a portion of the Management Information Base (MIB) that provides a means for monitoring batteries in or attached to managed devices. The Battery MIB module defined in [Section 4](#) meets the requirements for monitoring the status of batteries specified in [RFC 6988](#) [[RFC6988](#)].

The Battery MIB module provides for monitoring the battery status. According to the framework for energy management [[RFC7326](#)] it is an Energy Managed Object, and thus, MIB modules such as the Power and Energy Monitoring MIB [[I-D.ietf-eman-energy-monitoring-mib](#)] could in principle be implemented for batteries. The Battery MIB extends the more generic aspects of energy management by adding battery-specific information. Amongst other things, the Battery MIB enables the monitoring of:

- o the current charge of a battery,
- o the age of a battery (charging cycles),
- o the state of a battery (e.g. being re-charged),
- o last usage of a battery,
- o maximum energy provided by a battery (remaining and total capacity).

Further, means are provided for battery-powered devices to send notifications when the current battery charge has dropped below a certain threshold to inform the management system of needed replacement. The same applies to the age of a battery.

Many battery-driven devices have existing instrumentation for monitoring the battery status because this is already needed for local control of the battery by the device. This reduces the effort for implementing the managed objects defined in this document. For many devices only additional software will be needed but no additional hardware instrumentation for battery monitoring.

Since there are a lot of devices in use that contain more than one battery, means for battery monitoring defined in this document



support addressing multiple batteries within a single device. Also, batteries today often come in packages that can include identification and might contain additional hardware and firmware. The former allows tracing a battery and allows continuous monitoring even if the battery is installed in another device. The firmware version is useful information as the battery behavior might be different for different firmware versions.

Not explicitly in scope of definitions in this document are very small backup batteries, such as for example, batteries used on PC motherboard to run the clock circuit and retain configuration memory while the system is turned off. Other means may be required for reporting on these batteries. However, the MIB module defined in [Section 3.1](#) can be used for this purpose.

A traditional type of managed device containing batteries is an Uninterruptible Power Supply (UPS) system; these supply other devices with electrical energy when the main power supply fails. There is already a MIB module for managing UPS systems defined in [RFC 1628](#) [[RFC1628](#)]. The UPS MIB module includes managed objects for monitoring the batteries contained in an UPS system. However, the information provided by the UPS MIB objects is limited and tailored the particular needs of UPS systems.

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "NOT RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC 2119](#) [[RFC2119](#)].

## **2. The Internet-Standard Management Framework**

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to [section 7 of RFC 3410](#) [[RFC3410](#)].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies MIB modules that are compliant to the SMIV2, which is described in STD 58, [RFC 2578](#) [[RFC2578](#)], STD 58, [RFC 2579](#) [[RFC2579](#)] and STD 58, [RFC 2580](#) [[RFC2580](#)].



### **3. Design of the Battery MIB Module**

#### **3.1. MIB Module Structure**

The Battery MIB module defined in this document defines objects for reporting information about batteries. All managed objects providing information of the status of a battery are contained in a single table called batteryTable. The batteryTable contains one conceptual row per battery.

Batteries are indexed by the entPhysicalIndex of the entPhysicalTable defined in the ENTITY-MIB module [[RFC6933](#)]. An implementation of the ENTITY-MIB module complying with the entity4CRCompliance MODULE-COMPLIANCE statement is required for compliant implementations of the BATTERY-MIB module.

If a battery is replaced, and the replacing battery uses the same physical connector as the replaced battery, then the replacing battery **MUST** be indexed with the same value of object entPhysicalIndex as the replaced battery.

The kind of entity in the entPhysicalTable of the Entity MIB module is indicated by the value of enumeration object entPhysicalClass. All batteries **SHOULD** have the value of object entPhysicalClass set to battery(14) in their row of the entPhysicalTable.

The batteryTable contains three groups of objects. The first group (OIDs ending with 1-9) provides information on static properties of the battery. The second group of objects (OIDs ending with 10-18) provides information on the current battery state, if it is charging or discharging, how much it is charged, its remaining capacity, the number of experienced charging cycles, etc.





```
batteryTable(1)
+--batteryEntry(1) [entPhysicalIndex]
    +-- r-n SnmpAdminString batteryIdentifier(1)
    +-- r-n SnmpAdminString batteryFirmwareVersion(2)
    +-- r-n Enumeration      batteryType(3)
    +-- r-n Unsigned32       batteryTechnology(4)
    +-- r-n Unsigned32       batteryDesignVoltage(5)
    +-- r-n Unsigned32       batteryNumberOfCells(6)
    +-- r-n Unsigned32       batteryDesignCapacity(7)
    +-- r-n Unsigned32       batteryMaxChargingCurrent(8)
    +-- r-n Unsigned32       batteryTrickleChargingCurrent(9)
    +-- r-n Unsigned32       batteryActualCapacity(10)
    +-- r-n Unsigned32       batteryChargingCycleCount(11)
    +-- r-n DateAndTime      batteryLastChargingCycleTime(12)
    +-- r-n Enumeration      batteryChargingOperState(13)
    +-- rwn Enumeration      batteryChargingAdminState(14)
    +-- r-n Unsigned32       batteryActualCharge(15)
    +-- r-n Unsigned32       batteryActualVoltage(16)
    +-- r-n Integer32        batteryActualCurrent(17)
    +-- r-n Integer32        batteryTemperature(18)
    +-- rwn Unsigned32       batteryAlarmLowCharge(19)
    +-- rwn Unsigned32       batteryAlarmLowVoltage(20)
    +-- rwn Unsigned32       batteryAlarmLowCapacity(21)
    +-- rwn Unsigned32       batteryAlarmHighCycleCount(22)
    +-- rwn Integer32        batteryAlarmHighTemperature(23)
    +-- rwn Integer32        batteryAlarmLowTemperature(24)
    +-- r-n SnmpAdminString batteryCellIdentifier(25)
```

The third group of objects in this table (OIDs ending with 19-25) is used for notifications. Threshold objects (OIDs ending with 19-24) indicate thresholds which can be used to raise an alarm if a property of the battery exceeds one of them. Raising an alarm may include sending a notification.

The Battery MIB defines seven notifications for indicating

1. a battery charging state change that was not triggered by writing to object batteryChargingAdminState,
2. a low battery charging state,
3. a critical battery state in which it cannot be used for power supply,
4. an aged battery that may need to be replaced,
5. a battery exceed a temperature threshold,
6. a battery that has been connected,
7. disconnection of one or more batteries.

Notifications 2.-5. can use object batteryCellIdentifier to indicate a specific cell or a set of cells within the battery that have



triggered the notification.

### **3.2. Battery Technologies**

Static information in the batteryTable includes battery type and technology. The battery type distinguishes primary (not rechargeable) batteries from rechargeable (secondary) batteries and capacitors. The battery technology describes the actual technology of a battery, which typically is a chemical technology.

Since battery technologies are subject of intensive research and widely used technologies are often replaced by successor technologies within an few years, the list of battery technologies was not chosen as a fixed list. Instead, IANA has created a registry for battery technologies at <http://www.iana.org/assignments/eman> where numbers are assigned to battery technologies (TBD).

The table below shows battery technologies known today that are in commercial use with the numbers assigned to them by IANA. New entries can be added to the IANA registry if new technologies are developed or if missing technologies are identified. Note that there exists a huge number of battery types that are not listed in the IANA registry. Many of them are experimental or cannot be used in an economically useful way. New entries should be added to the IANA registry only if the respective technologies are in commercial use and relevant to standardized battery monitoring over the Internet.



+-----+	
battery technology	assigned
	number
+-----+	
Unknown	1
Other	2
Zinc-carbon	3
Zinc chloride	4
Nickel oxyhydroxide	5
Lithium-copper oxide	6
Lithium-iron disulfide	7
Lithium-manganese dioxide	8
Zinc-air	9
Silver oxide	10
Alkaline	11
Lead acid	12
Valve-Regulated Lead Acid, Gel	13
Valve-Regulated Lead Acid, AGM	14
Nickel-cadmium	15
Nickel-metal hydride	16
Nickel-zinc	17
Lithium-ion	18
Lithium polymer	19
Double layer capacitor	20
+-----+	

### **3.2.1. Guidelines for Adding Battery Technologies**

New entries can be added to the IANA registry if new technologies are developed or if missing technologies are identified. Note that there exists a huge number of battery types that are not listed in the IANA registry. Many of them are experimental or cannot be used in an economically useful way. New entries should be added to the IANA registry only if the respective technologies are in commercial use and relevant to standardized battery monitoring over the Internet.

### **3.3. Battery Identification**

There are two identifiers to be used: The entPhysicalUUID defined in the ENTITY-MIB [[RFC6933](#)] module and the batteryIdentifier defined in this module. A battery is linked to an entPhysicalUUID through the shared entPhysicalIndex.

The batteryIdentifier uniquely identifies the battery itself while the entPhysicalUUID identifies the slot of the device in which the battery is (currently) contained. For a non-replaceable battery both identifiers are always linked to the same physical battery. But for batteries that can be replaced, the identifiers have different



functions.

The entPhysicalUUID is always the same for a certain battery slot of a containing device even if the contained battery is replaced by another one. The batteryIdentifier is a representation of the battery identifier set by the battery manufacturer. It is tied to the battery and usually cannot be changed.

Many manufacturers deliver not just plain batteries but battery packages including additional hardware and firmware. Typically, these modules include an battery identifier that can be retrieved by a device in which a battery has been installed. The value of the object batteryIdentifier is an exact representation of this identifier. The batteryIdentifier is useful when batteries are removed and re-installed in the same device or in other devices. Then the device or the network management system can trace batteries and achieve continuity of battery monitoring.

### **3.4. Charging Cycles**

The lifetime of a battery can be approximated using the measure of charging cycles. A commonly used definition of a charging cycle is the amount of discharge equal to the design (or nominal) capacity of the battery [SBS]. This means that a single charging cycle may include several steps of partial charging and discharging until the amount of discharging has reached the design capacity of the battery. After that the next charging cycle immediately starts.

## **4. Definitions**

BATTERY-MIB DEFINITIONS ::= BEGIN

IMPORTS

MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE,  
mib-2, Integer32, Unsigned32  
FROM SNMPv2-SMI -- [RFC2578](#)  
SnmpAdminString  
FROM SNMP-FRAMEWORK-MIB -- [RFC3411](#)  
DateAndTime  
FROM SNMPv2-TC -- [RFC2579](#)  
MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP  
FROM SNMPv2-CONF -- [RFC2580](#)  
entPhysicalIndex  
FROM ENTITY-MIB; -- [RFC6933](#)

batteryMIB MODULE-IDENTITY

LAST-UPDATED "201411301200Z" -- 30 November 2014





ORGANIZATION "IETF EMAN Working Group"

CONTACT-INFO

"General Discussion: [eman@ietf.org](mailto:eman@ietf.org)

To Subscribe: <http://www.ietf.org/mailman/listinfo/eman>

Archive: <http://www.ietf.org/mail-archive/web/eman>

Editor:

Juergen Quittek  
NEC Europe Ltd.  
NEC Laboratories Europe  
Kurfuersten-Anlage 36  
69115 Heidelberg  
Germany  
Tel: +49 6221 4342-115  
Email: [quittek@neclab.eu](mailto:quittek@neclab.eu)"

DESCRIPTION

"This MIB module defines a set of objects for monitoring batteries of networked devices and of their components.

Copyright (c) 2014 IETF Trust and the persons identified as authors of the code. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, is permitted pursuant to, and subject to the license terms contained in, the Simplified BSD License set forth in [Section 4.c](#) of the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>).

This version of this MIB module is part of RFC yyyy; see the RFC itself for full legal notices."

-- replace yyyy with actual RFC number & remove this notice

-- Revision history

REVISION "201411301200Z" -- 30 November 2014

DESCRIPTION

"Initial version, published as RFC yyyy."

-- replace yyyy with actual RFC number & remove this notice

::= { mib-2 zzz }

-- zzz to be assigned by IANA.

-- \*\*\*\*\*

-- Top Level Structure of the MIB module

-- \*\*\*\*\*



```

batteryNotifications OBJECT IDENTIFIER ::= { batteryMIB 0 }
batteryObjects       OBJECT IDENTIFIER ::= { batteryMIB 1 }
batteryConformance  OBJECT IDENTIFIER ::= { batteryMIB 2 }

```

```

--=====
-- 1. Object Definitions
--=====

```

```

-----
-- 1.1. Battery Table
-----

```

```

batteryTable OBJECT-TYPE

```

```

    SYNTAX      SEQUENCE OF BatteryEntry

```

```

    MAX-ACCESS  not-accessible

```

```

    STATUS      current

```

```

    DESCRIPTION

```

"This table provides information on batteries. It contains one conceptual row per battery in a managed entity.

Batteries are indexed by the entPhysicalIndex of the entPhysicalTable defined in the ENTITY-MIB ([RFC6933](#)).

For implementations of the BATTERY-MIB an implementation of the ENTITY-MIB complying with the entity4CRCompliance MODULE-COMPLIANCE statement of the ENTITY-MIB is required.

If batteries are replaced, and the replacing battery uses the same physical connector as the replaced battery, then the replacing battery SHOULD be indexed with the same value of object entPhysicalIndex as the replaced battery."

```
 ::= { batteryObjects 1 }

```

```

batteryEntry OBJECT-TYPE

```

```

    SYNTAX      BatteryEntry

```

```

    MAX-ACCESS  not-accessible

```

```

    STATUS      current

```

```

    DESCRIPTION

```

"An entry providing information on a battery."

```

    INDEX { entPhysicalIndex }

```

```
 ::= { batteryTable 1 }

```

```

BatteryEntry ::=

```

```

    SEQUENCE {

```

```
        batteryIdentifier          SnmpAdminString,
```

```
        batteryFirmwareVersion     SnmpAdminString,
```

```
        batteryType                INTEGER,
```

```
        batteryTechnology           Unsigned32,
```

```
        batteryDesignVoltage       Unsigned32,

```



```
batteryNumberOfCells      Unsigned32,
batteryDesignCapacity      Unsigned32,
batteryMaxChargingCurrent  Unsigned32,
batteryTrickleChargingCurrent Unsigned32,
batteryActualCapacity      Unsigned32,
batteryChargingCycleCount  Unsigned32,
batteryLastChargingCycleTime DateAndTime,
batteryChargingOperState   INTEGER,
batteryChargingAdminState  INTEGER,
batteryActualCharge        Unsigned32,
batteryActualVoltage       Unsigned32,
batteryActualCurrent       Integer32,
batteryTemperature         Integer32,
batteryAlarmLowCharge      Unsigned32,
batteryAlarmLowVoltage     Unsigned32,
batteryAlarmLowCapacity    Unsigned32,
batteryAlarmHighCycleCount Unsigned32,
batteryAlarmHighTemperature Integer32,
batteryAlarmLowTemperature Integer32,
batteryCellIdentifier      SnmpAdminString
}
```

#### batteryIdentifier OBJECT-TYPE

SYNTAX SnmpAdminString

MAX-ACCESS read-only

STATUS current

#### DESCRIPTION

"This object contains an identifier for the battery.

Many manufacturers deliver not only simple batteries but battery packages including additional hardware and firmware. Typically, these modules include an identifier that can be retrieved by a device in which a battery has been installed. The identifier is useful when batteries are removed and re-installed in the same or other devices. Then the device or the network management system can trace batteries and achieve continuity of battery monitoring.

If the battery is identified by more than one value, for example, by a model number and a serial number, then the value of this object is a concatenation of these values, separated by the colon symbol ':'. The values should be ordered that a more significant value comes before a less significant one. In the example above, the (more significant) model number would be first, the serial number would follow: '<model number>:<serial number>'.

If the battery identifier cannot be represented using the



ISO/IEC IS 10646-1 character set, then a hexadecimal encoding of a binary representation of the entire battery identifier must be used.

The value of this object must be an empty string if there is no battery identifier or if the battery identifier is unknown."

::= { batteryEntry 1 }

#### batteryFirmwareVersion OBJECT-TYPE

SYNTAX SnmpAdminString

MAX-ACCESS read-only

STATUS current

##### DESCRIPTION

"This object indicates the version number of the firmware that is included in a battery module.

Many manufacturers deliver not pure batteries but battery packages including additional hardware and firmware.

Since the behavior of the battery may change with the firmware, it may be useful to retrieve the firmware version number.

The value of this object must be an empty string if there is no firmware or if the version number of the firmware is unknown."

::= { batteryEntry 2 }

#### batteryType OBJECT-TYPE

SYNTAX INTEGER {  
    unknown(1),  
    other(2),  
    primary(3),  
    rechargeable(4),  
    capacitor(5)  
}

MAX-ACCESS read-only

STATUS current

##### DESCRIPTION

"This object indicates the type of battery. It distinguishes between primary (not rechargeable) batteries, rechargeable (secondary) batteries, and capacitors. Capacitors are not really batteries but often used in the same way as a battery.

The value other(2) can be used if the battery type is known but none of the ones above. Value unknown(1) is to be used





if the type of battery cannot be determined."  
::= { batteryEntry 3 }

batteryTechnology OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the technology used by the battery.  
Numbers identifying battery types are registered at IANA.  
A current list of assignments can be found at  
<<http://www.iana.org/assignments/eman>>."

Value 1 (unknown) MUST be used if the type of battery  
cannot be determined.

Value 2 (other) can be used if the battery type is known  
but not one of the types already registered at IANA."

::= { batteryEntry 4 }

batteryDesignVoltage OBJECT-TYPE

SYNTAX Unsigned32

UNITS "millivolt"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the design (or nominal) voltage of the  
battery in units of millivolt (mV)."

Note that the design voltage is a constant value and  
typically different from the actual voltage of the battery.

A value of 0 indicates that the design voltage is unknown."

::= { batteryEntry 5 }

batteryNumberOfCells OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the number of cells contained in the  
battery."

A value of 0 indicates that the number of cells is unknown."

::= { batteryEntry 6 }

batteryDesignCapacity OBJECT-TYPE

SYNTAX Unsigned32



UNITS "milliampere hours"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the design (or nominal) capacity of the battery in units of milliampere hours (mAh).

Note that the design capacity is a constant value and typically different from the actual capacity of the battery. Usually, this is a value provided by the manufacturer of the battery.

A value of 0 indicates that the design capacity is unknown."

::= { batteryEntry 7 }

batteryMaxChargingCurrent OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the maximal current to be used for charging the battery in units of milliampere (mA).

Note that the maximal charging current may not lead to optimal charge of the battery and that some batteries can only be charged with the maximal current for a limited amount of time.

A value of 0 indicates that the maximal charging current is unknown."

::= { batteryEntry 8 }

batteryTrickleChargingCurrent OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the recommended current to be used for trickle charging the battery in units of milliampere (mA).

Typically, this is a value recommended by the manufacturer of the battery or by the manufacturer of the charging circuit.

A value of 0 indicates that the recommended trickle charging



current is unknown."  
::= { batteryEntry 9 }

batteryActualCapacity OBJECT-TYPE

SYNTAX        Unsigned32  
UNITS         "milliampere hours"  
MAX-ACCESS   read-only  
STATUS        current  
DESCRIPTION

"This object provides the actual capacity of the battery in units of milliampere hours (mAh).

Typically, the actual capacity of a battery decreases with time and with usage of the battery. It is usually lower than the design capacity

Note that the actual capacity needs to be measured and is typically an estimate based on observed discharging and charging cycles of the battery.

A value of 'ffffffff'H indicates that the actual capacity cannot be determined."

::= { batteryEntry 10 }

batteryChargingCycleCount OBJECT-TYPE

SYNTAX        Unsigned32  
MAX-ACCESS   read-only  
STATUS        current  
DESCRIPTION

"This object indicates the number of completed charging cycles that the battery underwent. In line with the Smart Battery Data Specification Revision 1.1, a charging cycle is defined as the process of discharging the battery by a total amount equal to the battery design capacity as given by object batteryDesignCapacity. A charging cycle may include several steps of charging and discharging the battery until the discharging amount given by batteryDesignCapacity has been reached. As soon as a charging cycle has been completed the next one starts immediately independent of the battery's current charge at the end of the cycle.

For batteries of type primary(3) the value of this object is always 0.

A value of 'ffffffff'H indicates that the number of charging cycles cannot be determined."

::= { batteryEntry 11 }



**batteryLastChargingCycleTime OBJECT-TYPE**

SYNTAX       DateAndTime

MAX-ACCESS   read-only

STATUS       current

**DESCRIPTION**

"The date and time of the last charging cycle. The value '0000000000000000'H is returned if the battery has not been charged yet or if the last charging time cannot be determined.

For batteries of type primary(1) the value of this object is always '0000000000000000'H."

::= { batteryEntry 12 }

**batteryChargingOperState OBJECT-TYPE**

SYNTAX       INTEGER {  
                    unknown(1),  
                    charging(2),  
                    fastCharging(3),  
                    maintainingCharge(4),  
                    noCharging(5),  
                    discharging(6)  
              }

MAX-ACCESS   read-only

STATUS       current

**DESCRIPTION**

"This object indicates the current charging state of the battery.

Value unknown(1) indicates that the charging state of the battery cannot be determined.

Value charging(2) indicates that the battery is being charged in a way that the charge of the battery increases.

Value fastCharging(3) indicated that the battery is being charged rapidly, i.e. faster than in the charging(2) state. If multiple fast charging states exist, all of these states are indicated by fastCharging(3).

Value maintainingCharge(4) indicates that the battery is being charged with a low current that compensates self-discharging. This includes trickle charging, float charging and other methods for maintaining the current charge of a battery.

Value noCharging(5) indicates that the battery is not being charged or discharged by electric current between the





battery and electric circuits external to the battery.  
Note that the battery may still be subject to  
self-discharging.

Value discharging(6) indicates that the battery is being  
discharged and that the charge of the battery decreases."  
::= { batteryEntry 13 }

batteryChargingAdminState OBJECT-TYPE

```
SYNTAX      INTEGER {
                charging(2),
                fastCharging(3),
                maintainingCharge(4),
                noCharging(5),
                discharging(6),
                notSet(7)
            }
```

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The value of this object indicates the desired  
charging state of the battery. The real state is  
indicated by object batteryChargingOperState. See the  
definition of object batteryChargingOperState for a  
description of the values.

When this object is initialized by an implementation of the  
BATTERY-MIB module, its value is set to notSet(7).

However, a SET request can only set this object to either  
charging(2), fastCharging(3), maintainingCharge(4),  
noCharging(5), or discharging(6). Attempts to set this  
object to notSet(7) will always fail with an  
'inconsistentValue' error. In case multiple fast charging  
states exist, the battery logic can choose an appropriate  
fast charging state - preferably the fastest.

When the batteryChargingAdminState object is set, then the  
BATTERY-MIB implementation must try to set the battery  
to the indicated state. The result will be indicated by  
object batteryChargingOperState.

Due to operational conditions and limitations of the  
implementation of the BATTERY-MIB module, changing the  
battery status according to a set value of object  
batteryChargingAdminState may not be possible.

Setting the value of object batteryChargingAdminState



may result in not changing the state of the battery to this value or even in setting the charging state to another value. For example, setting batteryChargingAdminState to value fastCharging(3) may have no effect when the battery logic is not allowing fast charging due to temperature constraints."

::= { batteryEntry 14 }

batteryActualCharge OBJECT-TYPE

SYNTAX        Unsigned32  
UNITS         "milliampere hours"  
MAX-ACCESS   read-only  
STATUS        current  
DESCRIPTION

"This object provides the actual charge of the battery in units of milliampere hours (mAh).

Note that the actual charge needs to be measured and is typically an estimate based on observed discharging and charging cycles of the battery.

A value of 'ffffffff'H indicates that the actual charge cannot be determined."

::= { batteryEntry 15 }

batteryActualVoltage OBJECT-TYPE

SYNTAX        Unsigned32  
UNITS         "millivolt"  
MAX-ACCESS   read-only  
STATUS        current  
DESCRIPTION

"This object provides the actual voltage of the battery in units of millivolt (mV).

A value of 'ffffffff'H indicates that the actual voltage cannot be determined."

::= { batteryEntry 16 }

batteryActualCurrent OBJECT-TYPE

SYNTAX        Integer32  
UNITS         "milliampere"  
MAX-ACCESS   read-only  
STATUS        current  
DESCRIPTION

"This object provides the actual charging or discharging current of the battery in units of milliampere (mA). Charging current is represented by positive values,



discharging current is represented by negative values.

A value of '7fffffff'H indicates that the actual current cannot be determined."

::= { batteryEntry 17 }

batteryTemperature OBJECT-TYPE

SYNTAX Integer32

UNITS "deci-degrees Celsius"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The ambient temperature at or within close proximity of the battery.

A value of '7fffffff'H indicates that the temperature cannot be determined."

::= { batteryEntry 18 }

batteryAlarmLowCharge OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere hours"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the lower threshold value for object batteryActualCharge. If the value of object batteryActualCharge falls below this threshold, a low battery alarm will be raised. The alarm procedure may include generating a batteryLowNotification.

This object should be set to a value such that when the batteryLowNotification is generated, the battery is still sufficiently charged to keep the device(s) that it powers operational for a time long enough to take actions before the powered device(s) enter a 'sleep' or 'off' state.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualCharge."

::= { batteryEntry 19 }

batteryAlarmLowVoltage OBJECT-TYPE

SYNTAX Unsigned32

UNITS "millivolt"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the lower threshold value for object



batteryActualVoltage. If the value of object batteryActualVoltage falls below this threshold, a low battery alarm will be raised. The alarm procedure may include generating a batteryLowNotification.

This object should be set to a value such that when the batteryLowNotification is generated, the battery is still sufficiently charged to keep the device(s) that it powers operational for a time long enough to take actions before the powered device(s) enter a 'sleep' or 'off' state.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualVoltage."

::= { batteryEntry 20 }

#### batteryAlarmLowCapacity OBJECT-TYPE

SYNTAX        Unsigned32  
UNITS         "milliampere hours"  
MAX-ACCESS   read-write  
STATUS        current

##### DESCRIPTION

"This object provides the lower threshold value for object batteryActualCapacity. If the value of object batteryActualCapacity falls below this threshold, a battery aging alarm will be raised. The alarm procedure may include generating a batteryAgingNotification.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualCapacity."

::= { batteryEntry 21 }

#### batteryAlarmHighCycleCount OBJECT-TYPE

SYNTAX        Unsigned32  
MAX-ACCESS   read-write  
STATUS        current

##### DESCRIPTION

"This object provides the upper threshold value for object batteryChargingCycleCount. If the value of object batteryChargingCycleCount rises above this threshold, a battery aging alarm will be raised. The alarm procedure may include generating a batteryAgingNotification.

A value of 0 indicates that no alarm will be raised for any value of object batteryChargingCycleCount."

::= { batteryEntry 22 }

#### batteryAlarmHighTemperature OBJECT-TYPE

SYNTAX        Integer32





UNITS "deci-degrees Celsius"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the upper threshold value for object batteryTemperature. If the value of object batteryTemperature rises above this threshold, a battery high temperature alarm will be raised. The alarm procedure may include generating a batteryTemperatureNotification.

A value of '7fffffff'H indicates that no alarm will be raised for any value of object batteryTemperature."

::= { batteryEntry 23 }

batteryAlarmLowTemperature OBJECT-TYPE

SYNTAX Integer32

UNITS "deci-degrees Celsius"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the lower threshold value for object batteryTemperature. If the value of object batteryTemperature falls below this threshold, a battery low temperature alarm will be raised. The alarm procedure may include generating a batteryTemperatureNotification.

A value of '7fffffff'H indicates that no alarm will be raised for any value of object batteryTemperature."

::= { batteryEntry 24 }

batteryCellIdentifier OBJECT-TYPE

SYNTAX SnmpAdminString

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The value of this object identifies one or more cells of a battery. The format of the cell identifier may vary between different implementations. It should uniquely identify one or more cells of the indexed battery.

This object can be used for batteries, such as, for example, lithium polymer batteries for which battery controllers monitor cells individually.

This object is used by notifications of type batteryLowNotification, batteryTemperatureNotification, batteryCriticalNotification, and batteryAgingNotification. These notifications can use the value of this object to



indicate the event that triggered the generation of the notification in more details by specifying a single cell or a set of cells within the battery which are specifically addressed by the notification.

An example use case for this object is a single cell in a battery that exceeds the temperature indicated by object `batteryAlarmHighTemperature`. In such a case, a `batteryTemperatureNotification` can be generated that not just indicates the battery for which the temperature is exceeded but also the particular cell.

The initial value of this object is the empty string. The value of this object is set at each time a `batteryLowNotification`, a `batteryTemperatureNotification`, a `batteryCriticalNotification`, or a `batteryAgingNotification` is generated.

When a notification is generated that does not indicate a specific cell or set of cells, the value of this object is set to the empty string."

```
::= { batteryEntry 25 }
```

```
--=====
-- 2. Notifications
--=====
```

`batteryChargingStateNotification` NOTIFICATION-TYPE

```
    OBJECTS      {
        batteryChargingOperState
    }
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "This notification can be generated when a charging state
        of the battery (indicated by the value of object
        batteryChargingOperState) is triggered by an event other
        than a write action to object batteryChargingAdminState.
        Such an event may, for example, be triggered by a local
        battery controller."
```

```
::= { batteryNotifications 1 }
```

`batteryLowNotification` NOTIFICATION-TYPE

```
    OBJECTS      {
        batteryActualCharge,
        batteryActualVoltage,
        batteryCellIdentifier
```



```
}
```

```
STATUS      current
```

```
DESCRIPTION
```

"This notification can be generated when the current charge (batteryActualCharge) or the current voltage (batteryActualVoltage) of the battery falls below a threshold defined by object batteryAlarmLowCharge or object batteryAlarmLowVoltage, respectively.

Note that typically, this notification is generated in a state where the battery is still sufficiently charged to keep the device(s) that it powers operational for some time. If the charging state of the battery has become critical, i.e., the device(s) powered by the battery must go to a 'sleep' or 'off' state, then the batteryCriticalNotification should be used instead.

If the low charge or voltage has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object batteryCellIdentifier should be set to a value that identifies the cell or set of cells. Otherwise, the value of object batteryCellIdentifier should be set to the empty string when this notification is generated.

The notification should not be sent again for the same battery or cell before either (a) the current voltage or the current charge, respectively, has become higher than the corresponding threshold through charging or (b) an indication of a maintenance action has been detected, such as battery disconnection event, or a reinitialization of the battery monitoring system.

This notification should not be sent when the battery is in a charging mode, i.e., the value of object batteryChargingOperState is charging(2) or fastCharging(3)."

```
::= { batteryNotifications 2 }
```

batteryCriticalNotification NOTIFICATION-TYPE

```
OBJECTS      {  
    batteryActualCharge,  
    batteryActualVoltage,  
    batteryCellIdentifier  
}
```

```
STATUS      current
```

```
DESCRIPTION
```

"This notification can be generated when the current charge of the battery falls so low that it cannot provide a



sufficient power supply function for regular operation of the powered device(s). The battery needs to be charged before it can be used for regular power supply again. The battery may still provide sufficient power for a 'sleep' mode of powered device(s) or for a transition into an 'off' mode.

If the critical state is caused a single cell or a set of cells of the battery, then object `batteryCellIdentifier` should be set to a value that identifies the cell or set of cells. Otherwise, the value of object `batteryCellIdentifier` should be set to the empty string when this notification is generated.

The notification should not be sent again for the same battery before either the battery charge has increased through charging to a non-critical value or an indication of a maintenance action has been detected, such a battery disconnection event, or a reinitialization of the battery monitoring system.

This notification should not be sent when the battery is in a charging mode, i.e., the value of object `batteryChargingOperState` is `charging(2)` or `fastCharging(3)`.  
 ::= { batteryNotifications 3 }

#### batteryTemperatureNotification NOTIFICATION-TYPE

```
OBJECTS      {
    batteryTemperature,
    batteryCellIdentifier
}
STATUS      current
DESCRIPTION
```

"This notification can be generated when the measured temperature (`batteryTemperature`) rises above the threshold defined by object `batteryAlarmHighTemperature` or falls below the threshold defined by object `batteryAlarmLowTemperature`.

If the low or high temperature has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object `batteryCellIdentifier` should be set to a value that identifies the cell or set of cells. Otherwise, the value of object `batteryCellIdentifier` should be set to the empty string when this notification is generated.

It may occur that the temperature alternates between values





slightly below and slightly above a threshold. For limiting the notification rate in such a case, this notification should not be sent again for the same battery or cell, respectively, with in a time interval of 10 minutes.

An exception to the rate limitations occurs immediately after the reinitialization of the battery monitoring system. If at this point in time the battery temperature is above the threshold defined by object `batteryAlarmHighTemperature` or below the threshold defined by object `batteryAlarmLowTemperature`, respectively, then this notification should be sent, independent of the time at which previous notifications for the same battery or cell, respectively, had been sent."

::= { batteryNotifications 4 }

#### `batteryAgingNotification` NOTIFICATION-TYPE

OBJECTS {  
    `batteryActualCapacity`,  
    `batteryChargingCycleCount`,  
    `batteryCellIdentifier`  
}

STATUS current

#### DESCRIPTION

"This notification can be generated when the actual capacity (`batteryActualCapacity`) falls below a threshold defined by object `batteryAlarmLowCapacity` or when the charging cycle count of the battery (`batteryChargingCycleCount`) exceeds the threshold defined by object `batteryAlarmHighCycleCount`.

If the aging has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object `batteryCellIdentifier` should be set to a value that identifies the cell or set of cells. Otherwise, the value of object `batteryCellIdentifier` should be set to the empty string when this notification is generated.

This notification should not be sent again for the same battery or cell, respectively, before an indication of a maintenance action has been detected, such as a battery disconnection event, or a reinitialization of the battery monitoring system."

::= { batteryNotifications 5 }

#### `batteryConnectedNotification` NOTIFICATION-TYPE

OBJECTS {  
    `batteryIdentifier`



```
}
STATUS      current
DESCRIPTION
    "This notification can be generated when it has been
    detected that a battery has been connected. The battery
    can be identified by the value of object batteryIdentifier
    as well as by the value of index entPhysicalIndex that is
    contained in the OID of object batteryIdentifier."
 ::= { batteryNotifications 6 }

batteryDisconnectedNotification NOTIFICATION-TYPE
STATUS      current
DESCRIPTION
    "This notification can be generated when it has been
    detected that one or more batteries have been disconnected."
 ::= { batteryNotifications 7 }

-----
-- 3. Conformance Information
-----

batteryCompliances OBJECT IDENTIFIER ::= { batteryConformance 1 }
batteryGroups      OBJECT IDENTIFIER ::= { batteryConformance 2 }

-----
-- 3.1. Compliance Statements
-----

batteryCompliance MODULE-COMPLIANCE
STATUS      current
DESCRIPTION
    "The compliance statement for implementations of the
    BATTERY-MIB module.

    A compliant implementation MUST implement the objects
    defined in the mandatory groups batteryDescriptionGroup
    and batteryStatusGroup.

    Note that compliance with this compliance
    statement requires compliance with the
    entity4CRCompliance MODULE-COMPLIANCE statement of the
    ENTITY-MIB (RFC6933)."
```

```
MODULE -- this module
MANDATORY-GROUPS {
    batteryDescriptionGroup,
    batteryStatusGroup
}
```



GROUP batteryAlarmThresholdsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryAlarmThresholdsGroup."

GROUP batteryNotificationsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryNotificationsGroup."

GROUP batteryPerCellNotificationsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryPerCellNotificationsGroup."

GROUP batteryAdminGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryAdminGroup."

OBJECT batteryAlarmLowCharge

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required to support set operations to this object."

OBJECT batteryAlarmLowVoltage

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required to support set operations to this object."

OBJECT batteryAlarmLowCapacity

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required to support set operations to this object."

OBJECT batteryAlarmHighCycleCount

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required to support set operations to this object."

OBJECT batteryAlarmHighTemperature

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required



to support set operations to this object."

OBJECT batteryAlarmLowTemperature

MIN-ACCESS read-only

DESCRIPTION

"A compliant implementation is not required  
to support set operations to this object."

::= { batteryCompliances 1 }

-----  
-- 3.2. MIB Grouping  
-----

batteryDescriptionGroup OBJECT-GROUP

OBJECTS {

batteryIdentifier,  
batteryFirmwareVersion,  
batteryType,  
batteryTechnology,  
batteryDesignVoltage,  
batteryNumberOfCells,  
batteryDesignCapacity,  
batteryMaxChargingCurrent,  
batteryTrickleChargingCurrent

}

STATUS current

DESCRIPTION

"A compliant implementation MUST implement the objects  
contained in this group."

::= { batteryGroups 1 }

batteryStatusGroup OBJECT-GROUP

OBJECTS {

batteryActualCapacity,  
batteryChargingCycleCount,  
batteryLastChargingCycleTime,  
batteryChargingOperState,  
batteryActualCharge,  
batteryActualVoltage,  
batteryActualCurrent,  
batteryTemperature

}

STATUS current

DESCRIPTION

"A compliant implementation MUST implement the objects  
contained in this group."

::= { batteryGroups 2 }





```
batteryAdminGroup OBJECT-GROUP
    OBJECTS {
        batteryChargingAdminState
    }
    STATUS      current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        object contained in this group."
    ::= { batteryGroups 3 }

batteryAlarmThresholdsGroup OBJECT-GROUP
    OBJECTS {
        batteryAlarmLowCharge,
        batteryAlarmLowVoltage,
        batteryAlarmLowCapacity,
        batteryAlarmHighCycleCount,
        batteryAlarmHighTemperature,
        batteryAlarmLowTemperature
    }
    STATUS      current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        objects contained in this group."
    ::= { batteryGroups 4 }

batteryNotificationsGroup NOTIFICATION-GROUP
    NOTIFICATIONS {
        batteryChargingStateNotification,
        batteryLowNotification,
        batteryCriticalNotification,
        batteryAgingNotification,
        batteryTemperatureNotification,
        batteryConnectedNotification,
        batteryDisconnectedNotification
    }
    STATUS      current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        notifications contained in this group."
    ::= { batteryGroups 5 }

batteryPerCellNotificationsGroup OBJECT-GROUP
    OBJECTS {
        batteryCellIdentifier
    }
    STATUS      current
    DESCRIPTION
        "A compliant implementation does not have to implement the
```



```
        object contained in this group."  
        ::= { batteryGroups 6 }  
END
```

## 5. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

- o `batteryChargingAdminState`  
Setting the battery charging state can be beneficial for an operator for various reasons such as charging batteries when the price of electricity is low. However, setting the charging state can be used by an attacker to discharge batteries of devices and thereby switching these devices off if they are powered solely by batteries. In particular, if the `batteryAlarmLowCharge` and `batteryAlarmLowVoltage` can also be set, this attack will go unnoticed (i.e. no notifications are sent).
- o `batteryAlarmLowCharge` and `batteryAlarmLowVoltage`  
These objects set the threshold for an alarm to be raised when the battery charge or voltage falls below the corresponding one of them. An attacker setting one of these alarm values can switch off the alarm by setting it to the 'off' value 0 or modify the alarm behavior by setting it to any other value. The result may be loss of data if the battery runs empty without warning to a recipient expecting such a notification.
- o `batteryAlarmLowCapacity` and `batteryAlarmHighCycleCount`  
These objects set the threshold for an alarm to be raised when the battery becomes older and less performant than required for stable operation. An attacker setting this alarm value can switch off the alarm by setting it to the 'off' value 0 or modify the alarm behavior by setting it to any other value. This may either lead to a costly replacement of a working battery or too old or too weak batteries being used. The consequence of the latter could e.g. be that a battery cannot provide power long enough between two scheduled charging actions causing the powered device to shut down and potentially lose data.
- o `batteryAlarmHighTemperature` and `batteryAlarmLowTemperature`  
These objects set thresholds for an alarm to be raised when the battery rises above/falls below them. An attacker setting one of



these alarm values can switch off these alarms by setting them to the 'off' value '7fffffff'H or modify the alarm behavior by setting them to any other value. The result may e.g. be an unnecessary shutdown of a device if batteryAlarmHighTemperature is set to too low or damage to the device by too high temperatures if switched off or set to too high values or by damage to the battery when it e.g. is being charged. Batteries can also be damaged e.g. in an attempt to charge them at too low temperatures.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over the network via SNMP. These are the tables and objects and their sensitivity/vulnerability:

All potentially sensible or vulnerable objects of this MIB module are in the batteryTable. In general, there are no serious operational vulnerabilities foreseen in case of an unauthorized read access to this table. However, corporate confidentiality issues need to be considered. It may be a trade secret of the operator

- o how many batteries are installed in a managed node (batteryIndex)
- o how old these batteries are (batteryActualCapacity and batteryChargingCycleCount)
- o when the next replacement cycle for batteries can be expected (batteryAlarmLowCapacity and batteryAlarmHighCycleCount)
- o what battery type and make are used with which firmware version (batteryIdentifier, batteryFirmwareVersion, batteryType, and batteryTechnology)

For any battery-powered device whose use can be correlated to an individual or a small group of individuals, the following objects have the potential to reveal information about those individuals' activities or habits (e.g., if they are near a power outlet, if they have been using their devices heavily, etc.):

- o batteryChargingCycleCount
- o batteryLastChargingCycleTime
- o batteryChargingOperState
- o batteryActualCharge
- o batteryActualVoltage
- o batteryActualCurrent
- o batteryTemperature
- o batteryAlarmLowCharge
- o batteryAlarmLowVoltage
- o batteryAlarmLowCapacity



- o batteryAlarmHighCycleCount
- o batteryAlarmHighTemperature
- o batteryAlarmLowTemperature

Implementers SHOULD use appropriate privacy protections. Battery monitoring of devices used by individuals SHOULD only occur with proper authorization. See the relevant discussion in [Section 9](#) of the Requirements for Energy Management [[RFC6988](#)].

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [[RFC3410](#)], [section 8](#)), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to GET or SET (change/create/delete) them.

## **6. IANA Considerations**

### **6.1. SMI Object Identifier Registration**

The Battery MIB module defined in this document uses the following IANA-assigned OBJECT IDENTIFIER value recorded in the SMI Numbers registry:

Descriptor	OBJECT IDENTIFIER value
-----	-----
batteryMIB	{ mib-2 xxx }

[NOTE for IANA: Please allocate an object identifier at <http://www.iana.org/assignments/smi-numbers> for object batteryMIB.]

### **6.2. Battery Technology Registration**

Object batteryTechnology defined in [Section 4](#) reports battery technologies. Eighteen values for battery technologies have initially been defined. They are listed in a table in [Section 3.2](#).

For ensuring extensibility of this list, IANA has created a registry for battery technologies at <http://www.iana.org/assignments/eman> and filled it with the initial list given in [Section 3.2](#).





New assignments of numbers for battery technologies will be administered by IANA through Expert Review ([RFC5226]). Experts must check for sufficient relevance of a battery technology to be added according to the guidelines in section [Section 3.2.1](#).

[NOTE for IANA: Please create a new registry under <http://www.iana.org/assignments/eman> for battery types. Please fill the registry with values from the table in [Section 3.2](#)]

## **[7.](#) Acknowledgements**

We would like to thank Steven Chew, Bill Mielke, and Alan Luchuk for their valuable input.

## **[8.](#) References**

### **[8.1.](#) Normative References**

- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", [BCP 14](#), [RFC 2119](#), March 1997.
- [RFC5226] Narten, T. and H. Alvestrand, "Guidelines for Writing an IANA Considerations Section in RFCs", [BCP 26](#), [RFC 5226](#), May 2008.
- [RFC2578] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Structure of Management Information Version 2 (SMIv2)", STD 58, [RFC 2578](#), April 1999.
- [RFC2579] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Textual Conventions for SMIv2", STD 58, [RFC 2579](#), April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIv2", STD 58, [RFC 2580](#), April 1999.
- [RFC6933] Bierman, A., Romascanu, D., Quittek, J., and M. Chandramouli, "Entity MIB (Version 4)", [RFC 6933](#), May 2013.

### **[8.2.](#) Informative References**

- [RFC6988] Quittek, J., Chandramouli, M., Winter, R., Dietz, T., and B. Claise, "Requirements for Energy Management", [RFC 6988](#), September 2013.



- [RFC7326] Parello, J., Claise, B., Schoening, B., and J. Quittek, "Energy Management Framework", [RFC 7326](#), September 2014.
- [I-D.ietf-eman-energy-monitoring-mib]  
Chandramouli, M., Claise, B., Schoening, B., Quittek, J., and T. Dietz, "Power, Energy Monitoring and Control MIB", [draft-ietf-eman-energy-monitoring-mib-13](#) (work in progress), November 2014.
- [RFC1628] Case, J., "UPS Management Information Base", [RFC 1628](#), May 1994.
- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", [RFC 3410](#), December 2002.
- [SBS] "Smart Battery Data Specification", Revision 1.1, December 1998.

#### Authors' Addresses

Juergen Quittek  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-115  
Email: [quittek@neclab.eu](mailto:quittek@neclab.eu)

Rolf Winter  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-121  
Email: [Rolf.Winter@neclab.eu](mailto:Rolf.Winter@neclab.eu)



Thomas Dietz  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-128  
Email: Thomas.Dietz@neclab.eu