

Definitions of Managed Objects for the General Switch Management Protocol (GSMP)

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2002). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for the use with the network management protocols in the Internet community. In particular, it describes managed objects for the General Switch Management Protocol (GSMP).

Table of Contents

1.	Introduction.....	2
2.	The SNMP Management Framework.....	2
3.	Structure of the MIB.....	3
3.1	Overview.....	3
3.2	Scope.....	4
3.3	MIB guideline.....	4
3.4	MIB groups.....	5
3.4.1	GSMP Switch Controller group.....	5
3.4.2	GSMP Switch group.....	6
3.4.3	GSMP Encapsulation groups.....	6
3.4.4	GSMP General group.....	7
3.4.5	The GSMP Notifications Group.....	7
3.5	Textual Conventions.....	8
4.	GSMP MIB Definitions.....	9
5.	Acknowledgments.....	42

6.	References.....	42
7.	Intellectual Property Rights.....	44
8.	Security Considerations.....	45
9.	Authors' Addresses.....	46
10.	Full Copyright Statement.....	47

[1.](#) Introduction

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it describes managed objects for the General Switch Management Protocol (GSMP).

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC 2119](#) [[RFC2119](#)].

[2.](#) The SNMP Management Framework

The SNMP Management Framework presently consists of five major components:

- * An overall architecture, described in [RFC 2571](#) [[RFC2571](#)].
- * Mechanisms for describing and naming objects and events for the purpose of management. The first version of this Structure of Management Information (SMI) is called SMIV1 and is described in STD 16, [RFC 1155](#) [[RFC1155](#)], STD 16, [RFC 1212](#) [[RFC1212](#)], and [RFC 1215](#) [[RFC1215](#)]. The second version, called SMIV2, is described in STD 58, [RFC 2578](#) [[RFC2578](#)], [RFC 2579](#) [[RFC2579](#)], and [RFC 2580](#) [[RFC2580](#)].
- * Message protocols for transferring management information. The first version of the SNMP message protocol is called SNMPv1 and is described in STD 15, [RFC 1157](#) [[RFC1157](#)]. A second version of the SNMP message protocol, which is not an Internet standards track protocol, is called SNMPv2c and is described in [RFC 1901](#) [[RFC1901](#)] and [RFC 1906](#) [[RFC1906](#)]. The third version of the message protocol is called SNMPv3 and is described in [RFC 1906](#) [[RFC1906](#)], [RFC 2572](#) [[RFC2572](#)], and [RFC 2574](#) [[RFC2574](#)].
- * Protocol operations for accessing management information. The first set of protocol operations and associated PDU formats are described in STD 15, [RFC 1157](#) [[RFC1157](#)]. A second set of operations and associated PDU formats are described in 1905 [[RFC1905](#)].

- * A set of fundamental applications described in [RFC 2573](#) [[RFC2573](#)], and the view-based access control mechanism is described in [RFC 2575](#) [[RFC2575](#)].

A more detailed introduction to the current SNMP Management Framework can be found in [RFC 2570](#) [[RFC2570](#)].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the mechanisms defined in the SMI.

This memo specifies a MIB module that is compliant to the SMIV2. A MIB conforming to the SMIV1 can be produced through the appropriate translations. The resulting translated MIB must be semantically equivalent, except where objects or events are omitted because no translation is possible (use of Counter64). Some machine readable information in SMIV2 will be converted into textual descriptions in SMIV1 during the translation process. However, this loss of machine readable information is not considered to change the semantics of the MIB.

[3. Structure of the MIB](#)

This memo defines a portion of the Management Information Base (MIB) for the use with network management protocols in the Internet community. In particular, it describes managed objects for the General Switch Management Protocol (GSMP), as defined in [[RFC3292](#)].

[3.1 Overview](#)

The General Switch Management Protocol (GSMP) is a general purpose protocol to control a label switch. GSMP allows a controller to establish and release connections across the switch, to manage switch ports and to request configuration information or statistics. It also allows the switch to inform the controller of asynchronous events such as a link going down.

The GSMP protocol is asymmetric, the controller being the master and the switch being the slave. Multiple switches may be controlled by a single controller using multiple instantiations of the protocol over separate control connections. Also a switch may be controlled by more than one controller by using the technique of partitioning.

Each instance of a (switch controller, switch partition) adjacency is a session between one switch controller entity and one switch entity. The MIB provides objects to configure/setup these entities to form the GSMP sessions. It also provide objects to monitor these GSMP sessions.

3.2 Scope

The GSMP mib is a protocol mib. It contains objects to configure, monitor, and maintain the GSMP protocol entity. It does not provide any information learned via the protocol, such as "all ports config" information.

The relationships between virtual entities, such as Virtual Switch Entities, and "physical" entities, such as Switch Entities, falls outside of the management of GSMP. This also applies for the management of switch partitions. So this is excluded from the GSMP mib.

It is possible to configure which, and how many Switch Controllers are controlling one Switch since every potential session with the switch has to be represented with an Switch entity. It is, however, not possible to define that one Switch Controller shouldn't allow other Switch controllers to control the same switch or partition on the switch. It is assumed that there are mechanisms that synchronise controllers and the configuration of them. This is outside the scope of this mib.

3.3 MIB guideline

Two tables are used to configure potential GSMP sessions depending if you are acting as a GSMP switch controller or a GSMP switch. Each row in these tables initiates a GSMP session.

The entity ID is a 48-bit name that is unique within the operational context of the device. A 48-bit IEEE 802 MAC address, if available, MAY be used for the entity ID. If the Ethernet encapsulation is used, the entity ID MUST be the IEEE 802 MAC address of the interface on which the GSMP session is to be setup.

First, the encapsulation of the potential GSMP session shall be defined. If ATM is used, a row in the `gsmpAtmEncapTable` has to be created with the index set to the entity ID. The specified resources should be allocated to GSMP. If TCP/IP is used, a row in the `gsmpTcpIpEncapTable` has to be created with the index set to the entity ID. The specified port shall be allocated to GSMP. No special action is needed if ethernet encapsulation is used.

Then the entity information shall be defined. To create a Switch Entity, an entry in the `gsmpSwitchTable` is created with the index set to the entity ID. To create a Switch Controller Entity, an entry in the `gsmpControllerTable` is created with the index set to the entity ID.

When the row status of the GsmpControllerEntry or GsmpSwitchEntry is set to active (e.g., in the case with ATM or TCP/IP there are active rows with a corresponding entity ID), the adjacency protocol of GSMP is started.

Another table, the gsmpSessionTable, shows the actual sessions that are established or are in the process of being established. Each row represents a specific session between an Entity and a peer. This table carries information about the peer, the session, and parameters that were negotiated by the adjacency procedures. The gsmpSessionTable also contains statistical information regarding the session.

This creation order SHOULD be used by all GSMP managers. This is to avoid clash situations in multiple SNMP manager scenarios where different managers may create competing entries in the different tables.

Entities may very well be configured by other means than SNMP, e.g., the cli command. Such configured entities SHOULD be represented as entries in the tables of this mib and SHOULD be possible to query, and MAY be possible to alter with SNMP.

3.4 MIB groups

3.4.1 GSMP Switch Controller group

The controller group is used to configure a potential GSMP session on a Switch Controller. A row in the gsmpControllerTable is created for each such session. If ATM or TCP/IP encapsulation is used, a corresponding row has to be created in these tables before the session adjacency protocol is initiated.

If ATM or TCP/IP is used, encapsulation data is defined in the corresponding encapsulation tables. If ethernet is used, the MAC address of the interface defined for the session is set by the Controller ID object.

The adjacency parameters are defined; such as

- Max supported GSMP version.
- Time between the periodic adjacency messages.
- Controller local port number and instance number.
- Whether partitions are being used and the partition ID for the specific partitions this controller is concerned with if partitions are used.
- The resynchronisation strategy for the session is specified.

The notification mapping is set to specify for with events the corresponding SNMP notifications are sent.

3.4.2 GSMP Switch group

The switch group is used to configure a potential GSMP session on a Switch. A row in the gsmpSwitchTable is created for each such session. If ATM or TCP/IP encapsulation is used, a corresponding row has to be created in these tables before the session adjacency protocol is initiated.

If ATM or TCP/IP is used, encapsulation data is defined in the corresponding encapsulation tables. If ethernet is used the MAC address of the interface defined for the session is set by the Switch ID object.

The adjacency parameters are defined; such as

- Max supported GSMP version
- Time between the periodic adjacency messages
- Switch Name, local port number, and instance number.
- Whether partitions are being used and the partition ID for this specific partition if partitions are used.
- The switch type could be set.
- The suggested maximum window size for unacknowledged request messages.

Also, a notification mapping is set to specify for with events the corresponding SNMP notifications are sent.

3.4.3 GSMP Encapsulation groups

The ATM Encapsulation Table and the TCP/IP Encapsulation Table provides a way to configure information that are encapsulation specific. The encapsulation data is further specified in [[RFC3293](#)].

If ATM encapsulation is used, the interface and the virtual channel are specified.

If TCP/IP is used, the IP address and the port number are specified.

No special config data needed if Ethernet encapsulation is used.

This mib MAY be extended with new, standard or proprietary, GSMP encapsulation types. If a new encapsulation type needs to be added, it SHOULD be done in the form of a new table with the entity ID as an index. A row in that encapsulation table SHOULD be created before any row in a GSMP entity table is created that is using this new GSMP encapsulation.

3.4.4 GSMP General group

The GSMP session table provides a way to monitor and maintain GSMP sessions.

The session is defined by a Switch Controller Entity and Switch Entity pair.

3.4.5 The GSMP Notifications Group

The GSMP Notification Group defines notifications for GSMP entities. These notifications provide a mechanism for a GSMP device to inform the management station of status changes. Also a notification is defined for each type of GSMP events.

The group of notifications consists of the following notifications:

- gsmpSessionDown

This notification is generated when a session is terminating and also reports the final accounting statistics of the session.

- gsmpSessionUp

This notification is generated when a new session is established.

- gsmpSendFailureInd

This notification is generated when a message with a failure indication was sent. This means that this notification identifies a change to the gsmpSessionStatFailureInds object in a row of the gsmpSessionTable.

- gsmpReceivedFailureInd

This notification is generated when a message with a failure indication received. This means that this notification identifies a change to the gsmpSessionStatReceivedFailures object in a row of the gsmpSessionTable.

- gsmpPortUpEvent

This notification is generated when a Port Up Event is either received or sent.

- gsmpPortDownEvent

This notification is generated when a Port Down Event is either received or sent.

- gsmpInvalidLabelEvent

This notification is generated when an Invalid Label Event is either received or sent.

- gsmpNewPortEvent

This notification is generated when New Port Event either is received or sent.

- gsmpDeadPortEvent

This notification is generated when a Dead Port Event is either received or sent.

- gsmpAdjacencyUpdateEvent

This notification is generated when an Adjacency Update Event is either received or sent.

To disable or enable the sending of each notification, the bits in the bitmap are set to 0 or 1 in the Notification mapping objects in the Controller Entity or Switch Entity tables.

The GSMP notification map capability should not be seen as a duplication of the filter mechanism in the snmp notification originator application [[RFC2573](#)], but as a compliment, to configure the relation between GSMP events and the SNMP notifications already in the GSMP agent. SNMP notifications and GSMP events operate sometimes on a different timescale, and it may in some applications be devastating for a SNMP application to receive events for each GSMP events. E.g. the invalid label event in a ATM switch scenario may cause mass SNMP notification flooding if mapped to a SNMP notification.

[3.5](#) Textual Conventions

The datatypes GsmpNameType, GsmpLabelType, GsmpVersion, GsmpPartitionType, and GsmpPartitionIdType are used as textual conventions in this document. These textual conventions are used for the convenience of humans reading the MIB. Objects defined using these conventions are always encoded by means of the rules that define their primitive type. However, the textual conventions have

special semantics associated with them. Hence, no changes to the SMI or the SNMP are necessary to accommodate these textual conventions which are adopted merely for the convenience of readers.

4. GSMP MIB Definitions

GSMP-MIB DEFINITIONS ::= BEGIN

IMPORTS

```
    OBJECT-TYPE, MODULE-IDENTITY, NOTIFICATION-TYPE,
    Unsigned32, Integer32, mib-2
        FROM SNMPv2-SMI -- [RFC2578]
    RowStatus, TruthValue, TimeStamp,
    StorageType, TEXTUAL-CONVENTION
        FROM SNMPv2-TC -- [RFC2579]
    MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
        FROM SNMPv2-CONF -- [RFC2580]
    ZeroBasedCounter32
        FROM RMON2-MIB -- [RFC2021]
    InterfaceIndex
        FROM IF-MIB -- [RFC2863]
    AtmVcIdentifier, AtmVpIdentifier
        FROM ATM-TC-MIB -- [RFC2514]
    InetAddressType, InetAddress, InetPortNumber
        FROM INET-ADDRESS-MIB ; -- [RFC3291]
```

gsmpMIB MODULE-IDENTITY

```
    LAST-UPDATED "200205310000Z" -- May 31, 2002
    ORGANIZATION "General Switch Management Protocol (gsmp)
        Working Group, IETF"
```

CONTACT-INFO

```
    "WG Charter:
    http://www.ietf.org/html.charters/gsmp-charter.html
```

```
    WG-email:      gsmp@ietf.org
    Subscribe:      gsmp-request@ietf.org
    Email Archive:
    ftp://ftp.ietf.org/ietf-mail-archive/gsmp/
```

```
    WG Chair:      Avri Doria
    Email:          avri@acm.org
```

```
    WG Chair:      Kenneth Sundell
    Email:          ksundell@nortelnetworks.com
```

```
    Editor:        Hans Sjostrand
    Email:          hans@ipunplugged.com
```


Editor: Joachim Buerkle
 Email: joachim.buerkle@nortelnetworks.com

Editor: Balaji Srinivasan
 Email: balaji@cplane.com"

DESCRIPTION

"This MIB contains managed object definitions for the
 General Switch Management Protocol, GSMP, version 3"

REVISION "200205310000Z"

DESCRIPTION "Initial Version, published as [RFC 3295](#)"

::= { mib-2 98 }

gsmpNotifications OBJECT IDENTIFIER ::= { gsmpMIB 0 }
 gsmpObjects OBJECT IDENTIFIER ::= { gsmpMIB 1 }
 gsmpNotificationsObjects OBJECT IDENTIFIER ::= { gsmpMIB 2 }
 gsmpConformance OBJECT IDENTIFIER ::= { gsmpMIB 3 }

-- *****
 -- GSMP Textual Conventions
 -- *****

GsmpNameType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The Name is a 48-bit quantity.
 A 48-bit IEEE 802 MAC address, if
 available, may be used."

SYNTAX OCTET STRING (SIZE(6))

GsmpPartitionType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Defining if partitions are used and how the partition id
 is negotiated. "

SYNTAX INTEGER {
 noPartition(1),
 fixedPartitionRequest(2),
 fixedPartitionAssigned(3)
 }

GsmpPartitionIdType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"A 8-bit quantity. The format of the Partition ID is not
 defined in GSMP. If desired, the Partition ID can be
 divided into multiple sub-identifiers within a single

partition. For example: the Partition ID could be subdivided into a 6-bit partition number and a 2-bit sub-identifier which would allow a switch to support 64 partitions with 4 available IDs per partition."

SYNTAX OCTET STRING (SIZE(1))

GsmVersion ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The version numbers defined for the GSMP protocol.

The version numbers used are defined in the specifications of the respective protocol,

1 - GSMPv1.1 [[RFC1987](#)]

2 - GSMPv2.0 [[RFC2397](#)]

3 - GSMPv3 [[RFC3292](#)]

Other numbers may be defined for other versions of the GSMP protocol."

SYNTAX Unsigned32

GsmLabelType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The label is structured as a TLV, a tuple, consisting of a Type, a Length, and a Value. The structure is defined in [[RFC 3292](#)]. The label TLV is encoded as a 2 octet type field, followed by a 2 octet Length field, followed by a variable length Value field.

Additionally, a label field can be composed of many stacked labels that together constitute the label."

SYNTAX OCTET STRING

-- *****

-- GSMP Entity Objects

-- *****

--

-- Switch Controller Entity table

--

gsmControllerTable OBJECT-TYPE

SYNTAX SEQUENCE OF GsmControllerEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table represents the Switch Controller Entities. An entry in this table needs to be configured (created) before a GSMP session might be started."

::= { gsmObjects 1 }

gsmpControllerEntry OBJECT-TYPE

SYNTAX GsmpControllerEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the table showing the data for a specific Switch Controller Entity. If partitions are used, one entity corresponds to one specific switch partition. Depending of the encapsulation used, a corresponding row in the gsmpAtmEncapTable or the gsmpTcpIpEncapTable may have been created."

INDEX { gsmpControllerEntityId }

::= { gsmpControllerTable 1 }

GsmpControllerEntry ::= SEQUENCE {

gsmpControllerEntityId	GsmpNameType,
gsmpControllerMaxVersion	GsmpVersion,
gsmpControllerTimer	Unsigned32,
gsmpControllerPort	Unsigned32,
gsmpControllerInstance	Unsigned32,
gsmpControllerPartitionType	GsmpPartitionType,
gsmpControllerPartitionId	GsmpPartitionIdType,
gsmpControllerDoResync	TruthValue,
gsmpControllerNotificationMap	BITS,
gsmpControllerSessionState	INTEGER,
gsmpControllerStorageType	StorageType,
gsmpControllerRowStatus	RowStatus

}

gsmpControllerEntityId OBJECT-TYPE

SYNTAX GsmpNameType

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The Switch Controller Entity Id is unique within the operational context of the device."

::= { gsmpControllerEntry 1 }

gsmpControllerMaxVersion OBJECT-TYPE

SYNTAX GsmpVersion

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The max version number of the GSMP protocol being used in this session. The version is negotiated by the adjacency protocol."

DEFVAL { 3 }


```
::= { gsmpControllerEntry 2 }
```

gsmpControllerTimer OBJECT-TYPE

SYNTAX Unsigned32(1..255)

UNITS "100ms"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The timer specifies the nominal time between periodic adjacency protocol messages. It is a constant for the duration of a GSMP session. The timer is specified in units of 100ms."

DEFVAL { 10 }

```
::= { gsmpControllerEntry 3 }
```

gsmpControllerPort OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The local port number for the Switch Controller Entity."

REFERENCE

"General Switch Management Protocol V3: [Section 3.1.2](#)"

```
::= { gsmpControllerEntry 4 }
```

gsmpControllerInstance OBJECT-TYPE

SYNTAX Unsigned32(1..16777215)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The instance number for the Switch Controller Entity. The Instance number is a 24-bit number that should be guaranteed to be unique within the recent past and to change when the link or node comes back up after going down. Zero is not a valid instance number. "

```
::= { gsmpControllerEntry 5 }
```

gsmpControllerPartitionType OBJECT-TYPE

SYNTAX GsmpPartitionType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"A controller can request the specific partition identifier to the session by setting the Partition Type to fixedPartitionRequest(2). A controller can let the switch decide whether it wants to assign a fixed partition ID or

not, by setting the Partition Type to noPartition(1)."
 ::= { gsmpControllerEntry 6 }

gsmpControllerPartitionId OBJECT-TYPE

SYNTAX GsmpPartitionIdType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The Id for the specific switch partition that this Switch Controller is concerned with.

If partitions are not used or if the controller lets the switch assigns Partition ID, i.e Partition Type = noPartition(1), then this object is undefined."

::= { gsmpControllerEntry 7 }

gsmpControllerDoResync OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object specifies whether the controller should resynchronise or reset in case of loss of synchronisation.

If this object is set to true then the Controller should resync with PFLAG=2 (recovered adjacency)."

DEFVAL { true }

::= { gsmpControllerEntry 8 }

gsmpControllerNotificationMap OBJECT-TYPE

SYNTAX BITS {

sessionDown(0),
 sessionUp(1),
 sendFailureIndication(2),
 receivedFailureIndication(3),
 portUpEvent(4),
 portDownEvent(5),
 invalidLabelEvent(6),
 newPortEvent(7),
 deadPortEvent(8),
 adjacencyUpdateEvent(9)

}

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This bitmap defines whether a corresponding SNMP notification should be sent if a GSMP event is received by the Switch Controller. If the bit is set to 1 a notification should be sent. The handling and filtering of the SNMP notifications are then further specified in the


```
SNMP notification originator application. "
DEFVAL {{ sessionDown, sessionUp,
          sendFailureIndication, receivedFailureIndication }}
::= { gsmpControllerEntry 9 }
```

gsmpControllerSessionState OBJECT-TYPE

```
SYNTAX          INTEGER {
                                null(1),
                                synsent(2),
                                synrcvd(3),
                                estab(4)
                            }
```

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The state for the existing or potential session that this entity is concerned with.
The NULL state is returned if the proper encapsulation data is not yet configured, if the row is not in active status or if the session is in NULL state as defined in the GSMP specification."

```
::= { gsmpControllerEntry 10}
```

gsmpControllerStorageType OBJECT-TYPE

SYNTAX StorageType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The storage type for this controller entity.
Conceptual rows having the value 'permanent' need not allow write-access to any columnar objects in the row."

```
DEFVAL { nonVolatile }
```

```
::= { gsmpControllerEntry 11 }
```

gsmpControllerRowStatus OBJECT-TYPE

SYNTAX RowStatus

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"An object that allows entries in this table to be created and deleted using the RowStatus convention.
While the row is in active state it's not possible to modify the value of any object for that row except the gsmpControllerNotificationMap and the gsmpControllerRowStatus objects."

```
::= { gsmpControllerEntry 12 }
```


--

-- Switch Entity table

--

gsmpSwitchTable OBJECT-TYPE

SYNTAX SEQUENCE OF GsmpSwitchEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table represents the Switch Entities. An entry in this table needs to be configured (created) before a GSMP session might be started."

::= { gsmpObjects 2 }

gsmpSwitchEntry OBJECT-TYPE

SYNTAX GsmpSwitchEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the table showing the data for a specific Switch Entity. If partitions are used, one entity corresponds to one specific switch partition. Depending of the encapsulation used, a corresponding row in the gsmpAtmEncapTable or the gsmpTcpIpEncapTable may have been created."

INDEX { gsmpSwitchEntityId }

::= { gsmpSwitchTable 1 }

GsmpSwitchEntry ::= SEQUENCE {

gsmpSwitchEntityId	GsmpNameType,
gsmpSwitchMaxVersion	GsmpVersion,
gsmpSwitchTimer	Unsigned32,
gsmpSwitchName	GsmpNameType,
gsmpSwitchPort	Unsigned32,
gsmpSwitchInstance	Unsigned32,
gsmpSwitchPartitionType	GsmpPartitionType,
gsmpSwitchPartitionId	GsmpPartitionIdType,
gsmpSwitchNotificationMap	BITS,
gsmpSwitchSwitchType	OCTET STRING,
gsmpSwitchWindowSize	Unsigned32,
gsmpSwitchSessionState	INTEGER,
gsmpSwitchStorageType	StorageType,
gsmpSwitchRowStatus	RowStatus

}

gsmpSwitchEntityId OBJECT-TYPE

SYNTAX GsmpNameType

MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
 "The Switch Entity Id is unique
 within the operational context of the device. "
 ::= { gsmpSwitchEntry 1 }

gsmpSwitchMaxVersion OBJECT-TYPE

SYNTAX GsmVersion
MAX-ACCESS read-create
STATUS current
DESCRIPTION
 "The max version number of the GSMP protocol being
 supported by this Switch. The version is negotiated by
 the adjacency protocol."
DEFVAL { 3 }
 ::= { gsmpSwitchEntry 2 }

gsmpSwitchTimer OBJECT-TYPE

SYNTAX Unsigned32(1..255)
UNITS "100ms"
MAX-ACCESS read-create
STATUS current
DESCRIPTION
 "The timer specifies the nominal time between
 periodic adjacency protocol messages. It is a constant
 for the duration of a GSMP session. The timer is
 specified in units of 100ms."
DEFVAL { 10 }
 ::= { gsmpSwitchEntry 3 }

gsmpSwitchName OBJECT-TYPE

SYNTAX GsmNameType
MAX-ACCESS read-create
STATUS current
DESCRIPTION
 "The name of the Switch. The first three octets must be an
 Organisationally Unique Identifier (OUI) that identifies
 the manufacturer of the Switch. This is by default set to
 the same value as the gsmpSwitchId object if not
 separately specified. "
 ::= { gsmpSwitchEntry 4 }

gsmpSwitchPort OBJECT-TYPE

SYNTAX Unsigned32
MAX-ACCESS read-create
STATUS current
DESCRIPTION

"The local port number for this Switch Entity."

REFERENCE

"General Switch Management Protocol V3: [Section 3.1.2](#)"

::= { gsmpSwitchEntry 5 }

gsmpSwitchInstance OBJECT-TYPE

SYNTAX Unsigned32(1..16777215)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The instance number for the Switch Entity.

The Instance number is a 24-bit number

that should be guaranteed to be unique within

the recent past and to change when the link

or node comes back up after going down. Zero is

not a valid instance number."

::= { gsmpSwitchEntry 6 }

gsmpSwitchPartitionType OBJECT-TYPE

SYNTAX GsmpPartitionType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"A switch can assign the specific partition identifier to

the session by setting the Partition Type to

fixedPartitionAssigned(3). A switch can specify

that no partitions are handled in the session by setting

the Partition Type to noPartition(1)."

::= { gsmpSwitchEntry 7 }

gsmpSwitchPartitionId OBJECT-TYPE

SYNTAX GsmpPartitionIdType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The Id for this specific switch partition that the switch

entity represents. If partitions are not used, i.e.

Partition Type = noPartition(1), then this object is

undefined."

::= { gsmpSwitchEntry 8 }

gsmpSwitchNotificationMap OBJECT-TYPE

SYNTAX BITS {

sessionDown(0),

sessionUp(1),

sendFailureIndication(2),

receivedFailureIndication(3),

portUpEvent(4),


```

        portDownEvent(5),
        invalidLabelEvent(6),
        newPortEvent(7),
        deadPortEvent(8),
        adjacencyUpdateEvent(9)
    }
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This bitmap defines whether a corresponding SNMP
    notification should be sent if an GSMP event is sent
    by the Switch Entity. If the bit is set to 1 a
    notification should be sent. The handling and filtering of
    the SNMP notifications are then further specified in the
    SNMP notification originator application. "
DEFVAL {{ sessionDown, sessionUp,
        sendFailureIndication, receivedFailureIndication }}
::= { gsmpSwitchEntry 9 }

gsmpSwitchSwitchType OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(2))
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "A 16-bit field allocated by the manufacturer
        of the switch. The Switch Type
        identifies the product. When the Switch Type is combined
        with the OUI from the Switch Name the product is
        uniquely identified. "
    ::= { gsmpSwitchEntry 10 }

gsmpSwitchWindowSize OBJECT-TYPE
    SYNTAX      Unsigned32(1..65535)
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "The maximum number of unacknowledged request messages
        that may be transmitted by the controller without the
        possibility of loss. This field is used to prevent
        request messages from being lost in the switch because of
        overflow in the receive buffer. The field is a hint to
        the controller."
    ::= { gsmpSwitchEntry 11 }

gsmpSwitchSessionState OBJECT-TYPE
    SYNTAX      INTEGER {
        null(1),
        synsent(2),

```



```

                                synrcvd(3),
                                estab(4)
                                }
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "The state for the existing or potential session that
    this entity is concerned with.
    The NULL state is returned if the proper encapsulation
    data is not yet configured, if the row is not in active
    status or if the session is in NULL state as defined in
    the GSMP specification."
 ::= { gsmpSwitchEntry 12}

gsmpSwitchStorageType OBJECT-TYPE
    SYNTAX      StorageType
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "The storage type for this switch entity.
        Conceptual rows having the value 'permanent' need not allow
        write-access to any columnar objects in the row."
    DEFVAL { nonVolatile }
    ::= { gsmpSwitchEntry 13 }

gsmpSwitchRowStatus OBJECT-TYPE
    SYNTAX      RowStatus
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "An object that allows entries in this table to
        be created and deleted using the
        RowStatus convention.
        While the row is in active state it's not
        possible to modify the value of any object
        for that row except the gsmpSwitchNotificationMap
        and the gsmpSwitchRowStatus objects."
    ::= { gsmpSwitchEntry 14 }

-- *****
-- GSMP Encapsulation Objects
-- *****

--
-- GSMP ATM Encapsulation Table
--

gsmpAtmEncapTable OBJECT-TYPE

```



```
SYNTAX          SEQUENCE OF GsmAtmEncapEntry
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
    "This table contains the atm encapsulation data
    for the Controller or Switch that uses atm aal5 as
    encapsulation. "
 ::= { gsmObjects 3 }
```

gsmAtmEncapEntry OBJECT-TYPE

```
SYNTAX          GsmAtmEncapEntry
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
    "An entry in the table showing
    the encapsulation data for a specific
    Switch Controller entity or Switch entity."
INDEX { gsmAtmEncapEntityId }
 ::= { gsmAtmEncapTable 1 }
```

```
GsmAtmEncapEntry ::= SEQUENCE {
    gsmAtmEncapEntityId      GsmNameType,
    gsmAtmEncapIfIndex       InterfaceIndex,
    gsmAtmEncapVpi           AtmVpIdentifier,
    gsmAtmEncapVci           AtmVcIdentifier,
    gsmAtmEncapStorageType   StorageType,
    gsmAtmEncapRowStatus     RowStatus
}
```

gsmAtmEncapEntityId OBJECT-TYPE

```
SYNTAX          GsmNameType
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
    "The Controller Id or Switch Id that is unique
    within the operational context of the device. "
 ::= { gsmAtmEncapEntry 1 }
```

gsmAtmEncapIfIndex OBJECT-TYPE

```
SYNTAX          InterfaceIndex
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "The interface index for the virtual channel over which
    the GSMP session is established, i.e., the GSMP control
    channel for LLC/SNAP encapsulated GSMP messages on an
    ATM data link layer."
 ::= { gsmAtmEncapEntry 2 }
```


gsmpAtmEncapVpi OBJECT-TYPE

SYNTAX AtmVpIdentifier

MAX-ACCESS read-create

STATUS current

DESCRIPTION

" The VPI value for the virtual channel over which the GSMP session is established, i.e., the GSMP control channel for LLC/SNAP encapsulated GSMP messages on an ATM data link layer."

DEFVAL { 0 }

::= { gsmpAtmEncapEntry 3 }

gsmpAtmEncapVci OBJECT-TYPE

SYNTAX AtmVcIdentifier

MAX-ACCESS read-create

STATUS current

DESCRIPTION

" The VCI value for the virtual channel over which the GSMP session is established, i.e., the GSMP control channel for LLC/SNAP encapsulated GSMP messages on an ATM data link layer."

DEFVAL { 15 }

::= { gsmpAtmEncapEntry 4 }

gsmpAtmEncapStorageType OBJECT-TYPE

SYNTAX StorageType

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The storage type for this entry. It should have the same value as the StorageType in the referring Switch Controller entity or Switch entity."

DEFVAL { nonVolatile }

::= { gsmpAtmEncapEntry 5 }

gsmpAtmEncapRowStatus OBJECT-TYPE

SYNTAX RowStatus

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"An object that allows entries in this table to be created and deleted using the RowStatus convention. While the row is in active state it's not possible to modify the value of any object for that row except the gsmpAtmEncapRowStatus object."

::= { gsmpAtmEncapEntry 6 }

--

-- GSMP TCP/IP Encapsulation Table

--

gsmpTcpIpEncapTable OBJECT-TYPE

SYNTAX SEQUENCE OF GsmpTcpIpEncapEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains the encapsulation data
for the Controller or Switch that uses TCP/IP as
encapsulation."

::= { gsmpObjects 4 }

gsmpTcpIpEncapEntry OBJECT-TYPE

SYNTAX GsmpTcpIpEncapEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An entry in the table showing
the encapsulation data for a specific
Switch Controller entity or Switch entity."

INDEX { gsmpTcpIpEncapEntityId }

::= { gsmpTcpIpEncapTable 1 }

GsmpTcpIpEncapEntry ::= SEQUENCE {

gsmpTcpIpEncapEntityId	GsmpNameType,
gsmpTcpIpEncapAddressType	InetAddressType,
gsmpTcpIpEncapAddress	InetAddress,
gsmpTcpIpEncapPortNumber	InetPortNumber,
gsmpTcpIpEncapStorageType	StorageType,
gsmpTcpIpEncapRowStatus	RowStatus

}

gsmpTcpIpEncapEntityId OBJECT-TYPE

SYNTAX GsmpNameType

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The Controller or Switch Id is unique
within the operational context of the device. "

::= { gsmpTcpIpEncapEntry 1 }

gsmpTcpIpEncapAddressType OBJECT-TYPE

SYNTAX InetAddressType

MAX-ACCESS read-create

STATUS current

DESCRIPTION


```

    "The type of address in gsmpTcpIpEncapAddress."
    ::= { gsmpTcpIpEncapEntry 2 }

```

```
gsmpTcpIpEncapAddress OBJECT-TYPE
```

```
    SYNTAX      InetAddress
```

```
    MAX-ACCESS   read-create
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "The IPv4 or IPv6 address used for
         the GSMP session peer."
```

```
    ::= { gsmpTcpIpEncapEntry 3 }
```

```
gsmpTcpIpEncapPortNumber OBJECT-TYPE
```

```
    SYNTAX      InetPortNumber
```

```
    MAX-ACCESS   read-create
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "The TCP port number used for the TCP session
         establishment to the GSMP peer."
```

```
    DEFVAL { 6068 }
```

```
    ::= { gsmpTcpIpEncapEntry 4 }
```

```
gsmpTcpIpEncapStorageType OBJECT-TYPE
```

```
    SYNTAX      StorageType
```

```
    MAX-ACCESS   read-create
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "The storage type for this entry. It should have the same
         value as the StorageType in the referring Switch
         Controller entity or Switch entity."
```

```
    DEFVAL { nonVolatile }
```

```
    ::= { gsmpTcpIpEncapEntry 5 }
```

```
gsmpTcpIpEncapRowStatus OBJECT-TYPE
```

```
    SYNTAX      RowStatus
```

```
    MAX-ACCESS   read-create
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "An object that allows entries in this table to
         be created and deleted using the
         RowStatus convention.
         While the row is in active state it's not
         possible to modify the value of any object
         for that row except the gsmpTcpIpEncapRowStatus object."
    ::= { gsmpTcpIpEncapEntry 6 }
```

```
-- *****
```

```
-- GSMP Session Objects
```



```
-- *****
```

```
--
```

```
-- GSMP Session table
```

```
--
```

```
gsmpSessionTable OBJECT-TYPE
```

```
    SYNTAX          SEQUENCE OF GsmpSessionEntry
```

```
    MAX-ACCESS      not-accessible
```

```
    STATUS          current
```

```
    DESCRIPTION
```

```
        "This table represents the sessions between  
        Controller and Switch pairs. "
```

```
    ::= { gsmpObjects 5 }
```

```
gsmpSessionEntry OBJECT-TYPE
```

```
    SYNTAX          GsmpSessionEntry
```

```
    MAX-ACCESS      not-accessible
```

```
    STATUS          current
```

```
    DESCRIPTION
```

```
        "An entry in the table showing  
        the session data for a specific Controller and  
        Switch pair. Also, statistics for this specific  
        session is shown."
```

```
    INDEX { gsmpSessionThisSideId, gsmpSessionFarSideId }
```

```
    ::= { gsmpSessionTable 1 }
```

```
GsmpSessionEntry ::= SEQUENCE {
```

gsmpSessionThisSideId	GsmpNameType,
gsmpSessionFarSideId	GsmpNameType,
gsmpSessionVersion	GsmpVersion,
gsmpSessionTimer	Integer32,
gsmpSessionPartitionId	GsmpPartitionIdType,
gsmpSessionAdjacencyCount	Unsigned32,
gsmpSessionFarSideName	GsmpNameType,
gsmpSessionFarSidePort	Unsigned32,
gsmpSessionFarSideInstance	Unsigned32,
gsmpSessionLastFailureCode	Unsigned32,
gsmpSessionDiscontinuityTime	TimeStamp,
gsmpSessionStartUptime	TimeStamp,
gsmpSessionStatSentMessages	ZeroBasedCounter32,
gsmpSessionStatFailureInds	ZeroBasedCounter32,
gsmpSessionStatReceivedMessages	ZeroBasedCounter32,
gsmpSessionStatReceivedFailures	ZeroBasedCounter32,
gsmpSessionStatPortUpEvents	ZeroBasedCounter32,
gsmpSessionStatPortDownEvents	ZeroBasedCounter32,
gsmpSessionStatInvLabelEvents	ZeroBasedCounter32,
gsmpSessionStatNewPortEvents	ZeroBasedCounter32,


```
gsmSessionStatDeadPortEvents      ZeroBasedCounter32,
gsmSessionStatAdjUpdateEvents     ZeroBasedCounter32
}
```

gsmSessionThisSideId OBJECT-TYPE

```
SYNTAX          GsmNameType
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
```

"This side ID uniquely identifies the entity that this session relates to within the operational context of the device. "

::= { gsmSessionEntry 1 }

gsmSessionFarSideId OBJECT-TYPE

```
SYNTAX          GsmNameType
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
```

"The Far side ID uniquely identifies the entity that this session is established against. "

::= { gsmSessionEntry 2 }

gsmSessionVersion OBJECT-TYPE

```
SYNTAX          GsmVersion
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
```

"The version number of the GSMP protocol being used in this session. The version is the result of the negotiation by the adjacency protocol."

::= { gsmSessionEntry 3 }

gsmSessionTimer OBJECT-TYPE

```
SYNTAX          Integer32
UNITS           "100ms"
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
```

"The timer specifies the time remaining until the adjacency timer expires. The object could take negative values since if no valid GSMP messages are received in any period of time in excess of three times the value of the Timer negotiated by the adjacency protocol loss of synchronisation may be declared. The timer is specified in units of 100ms."

::= { gsmSessionEntry 4 }

gsmpSessionPartitionId OBJECT-TYPE

SYNTAX GsmpPartitionIdType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The Partition Id for the specific switch partition that this session is concerned with."

::= { gsmpSessionEntry 5 }

gsmpSessionAdjacencyCount OBJECT-TYPE

SYNTAX Unsigned32(1..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object specifies the current number of adjacencies that are established with controllers and the switch partition that is used for this session. The value includes this session."

::= { gsmpSessionEntry 6 }

gsmpSessionFarSideName OBJECT-TYPE

SYNTAX GsmpNameType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The name of the far side as advertised in the adjacency message."

::= { gsmpSessionEntry 7 }

gsmpSessionFarSidePort OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The local port number of the link across which the message is being sent."

REFERENCE

"General Switch Management Protocol V3: [Section 3.1.2](#)"

::= { gsmpSessionEntry 8 }

gsmpSessionFarSideInstance OBJECT-TYPE

SYNTAX Unsigned32(1..16777215)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The instance number used for the link during this session. The Instance number is a 24-bit number that should be guaranteed to be unique within

the recent past and to change when the link
or node comes back up after going down. Zero is not
a valid instance number."
::= { gsmpSessionEntry 9 }

gsmpSessionLastFailureCode OBJECT-TYPE

SYNTAX Unsigned32(0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This is the last failure code that was received over
this session. If no failure code have been received, the
value is zero."

::= { gsmpSessionEntry 10 }

gsmpSessionDiscontinuityTime OBJECT-TYPE

SYNTAX TimeStamp

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The value of sysUpTime on the most recent occasion at
which one or more of this session's counters
suffered a discontinuity. If no such discontinuities have
occurred since then, this object contains the same
timestamp as gsmpSessionStartUptime ."

::= { gsmpSessionEntry 11 }

gsmpSessionStartUptime OBJECT-TYPE

SYNTAX TimeStamp

MAX-ACCESS read-only

STATUS current

DESCRIPTION

" The value of sysUpTime when the session came to
established state."

::= { gsmpSessionEntry 12 }

gsmpSessionStatSentMessages OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of messages that have been sent in this
session. All GSMP messages pertaining to this session after
the session came to established state SHALL
be counted, also including adjacency protocol messages
and failure response messages.
When the counter suffers any discontinuity, then
the gsmpSessionDiscontinuityTime object indicates when it

happened."
::= { gsmpSessionEntry 13 }

gsmpSessionStatFailureInds OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of messages that have been sent with a failure indication in this session. Warning messages SHALL NOT be counted.
When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 12.1](#)"

::= { gsmpSessionEntry 14 }

gsmpSessionStatReceivedMessages OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of messages that have been received in this session. All legal GSMP messages pertaining to this session after the session came to established state SHALL be counted, also including adjacency protocol messages and failure response messages.
When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

::= { gsmpSessionEntry 15 }

gsmpSessionStatReceivedFailures OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of messages that have been received in this session with a failure indication. Warning messages SHALL NOT be counted.
When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 12.1](#)"

::= { gsmpSessionEntry 16 }

gsmpSessionStatPortUpEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of Port Up events that have been sent or received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.1](#)"

::= { gsmpSessionEntry 17 }

gsmpSessionStatPortDownEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of Port Down events that have been sent or received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.2](#)"

::= { gsmpSessionEntry 18 }

gsmpSessionStatInvLabelEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of Invalid label events that have been sent or received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.3](#)"

::= { gsmpSessionEntry 19 }

gsmpSessionStatNewPortEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of New Port events that have been sent or

received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.4](#)"

::= { gsmpSessionEntry 20 }

gsmpSessionStatDeadPortEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of Dead Port events that have been sent or received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.5](#)"

::= { gsmpSessionEntry 21 }

gsmpSessionStatAdjUpdateEvents OBJECT-TYPE

SYNTAX ZeroBasedCounter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of Adjacency Update events that have been sent or received on this session.

When the counter suffers any discontinuity, then the gsmpSessionDiscontinuityTime object indicates when it happened."

REFERENCE

"General Switch Management Protocol V3: [Section 9.6](#)"

::= { gsmpSessionEntry 22 }

```
-- *****
-- GSMP Notifications
-- *****
```

```
--
-- Notification objects
--
```

gsmpEventPort OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS accessible-for-notify


```
STATUS          current
DESCRIPTION
    "This object specifies the Port Number that is
    carried in this event."
 ::= { gsmpNotificationsObjects 1 }

gsmpEventPortSessionNumber OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   accessible-for-notify
    STATUS      current
    DESCRIPTION
        "This object specifies the Port Session Number that is
        carried in this event."
    ::= { gsmpNotificationsObjects 2 }

gsmpEventSequenceNumber OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   accessible-for-notify
    STATUS      current
    DESCRIPTION
        "This object specifies the Event Sequence Number that is
        carried in this event."
    ::= { gsmpNotificationsObjects 3 }

gsmpEventLabel OBJECT-TYPE
    SYNTAX      GsmLabelType
    MAX-ACCESS   accessible-for-notify
    STATUS      current
    DESCRIPTION
        "This object specifies the Label that is
        carried in this event."
    ::= { gsmpNotificationsObjects 4 }

--
-- Notifications
--

gsmpSessionDown NOTIFICATION-TYPE
    OBJECTS {
        gsmpSessionStartUptime,
        gsmpSessionStatSentMessages,
        gsmpSessionStatFailureInds,
        gsmpSessionStatReceivedMessages,
        gsmpSessionStatReceivedFailures,
        gsmpSessionStatPortUpEvents,
        gsmpSessionStatPortDownEvents,
        gsmpSessionStatInvLabelEvents,
```



```
    gsmpSessionStatNewPortEvents,  
    gsmpSessionStatDeadPortEvents,  
    gsmpSessionStatAdjUpdateEvents  
}
```

STATUS current

DESCRIPTION

"When it has been enabled, this notification is generated whenever a session is taken down, regardless of whether the session went down normally or not. Its purpose is to allow a management application (primarily an accounting application) that is monitoring the session statistics to receive the final values of these counters, so that the application can properly account for the amounts the counters were incremented since the last time the application polled them. The gsmpSessionStartUptime object provides the total amount of time that the session was active.

This notification is not a substitute for polling the session statistic counts. In particular, the count values reported in this notification cannot be assumed to be the complete totals for the life of the session, since they may have wrapped while the session was up.

The session to which this notification applies is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifiers of the objects contained in the notification.

An instance of this notification will contain exactly one instance of each of its objects, and these objects will all belong to the same conceptual row of the gsmpSessionTable."

```
::= { gsmpNotifications 1 }
```

gsmpSessionUp NOTIFICATION-TYPE

```
    OBJECTS {  
        gsmpSessionFarSideInstance  
    }
```

STATUS current

DESCRIPTION

"When it has been enabled, this notification is generated when new session is established.

The new session is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifier of the gsmpSessionFarSideInstance object


```
        contained in the notification."
 ::= { gsmpNotifications 2 }

gsmpSentFailureInd NOTIFICATION-TYPE
    OBJECTS {
        gsmpSessionLastFailureCode,
        gsmpSessionStatFailureInds
    }
    STATUS current
    DESCRIPTION
        "When it has been enabled, this notification is
        generated when a message with a failure indication was
        sent.

        The notification indicates a change in the value of
        gsmpSessionStatFailureInds. The
        gsmpSessionLastFailureCode contains the failure
        reason.

        The session to which this notification
        applies is identified by the gsmpSessionThisSideId and
        gsmpSessionFarSideId which could be inferred from the
        Object Identifiers of the objects contained in the
        notification."
 ::= { gsmpNotifications 3 }

gsmpReceivedFailureInd NOTIFICATION-TYPE
    OBJECTS {
        gsmpSessionLastFailureCode,
        gsmpSessionStatReceivedFailures
    }
    STATUS current
    DESCRIPTION
        "When it has been enabled, this notification is
        generate when a message with a failure indication
        is received.

        The notification indicates a change in the value of
        gsmpSessionStatReceivedFailures. The
        gsmpSessionLastFailureCode contains the failure
        reason.

        The session to which this notification
        applies is identified by the gsmpSessionThisSideId and
        gsmpSessionFarSideId which could be inferred from the
        Object Identifiers of the objects contained in the
        notification."
 ::= { gsmpNotifications 4 }
```


gsmpPortUpEvent NOTIFICATION-TYPE

```
OBJECTS {  
    gsmpSessionStatPortUpEvents,  
    gsmpEventPort,  
    gsmpEventPortSessionNumber,  
    gsmpEventSequenceNumber  
}
```

STATUS current

DESCRIPTION

"When it has been enabled, this notification is generated when a Port Up Event occurs.

The notification indicates a change in the value of gsmpSessionStatPortUpEvents.

The session to which this notification applies is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifier of the gsmpSessionStatPortUpEvents object contained in the notification."

::= { gsmpNotifications 5 }

gsmpPortDownEvent NOTIFICATION-TYPE

```
OBJECTS {  
    gsmpSessionStatPortDownEvents,  
    gsmpEventPort,  
    gsmpEventPortSessionNumber,  
    gsmpEventSequenceNumber  
}
```

STATUS current

DESCRIPTION

"When it has been enabled, this notification is generated when a Port Down Event occurs.

The notification indicates a change in the value of gsmpSessionStatPortDownEvents.

The session to which this notification applies is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifier of the gsmpSessionStatPortDownEvents object contained in the notification."

::= { gsmpNotifications 6 }

gsmpInvalidLabelEvent NOTIFICATION-TYPE

```
OBJECTS {  
    gsmpSessionStatInvLabelEvents,  
    gsmpEventPort,
```



```
        gsmpEventLabel,  
        gsmpEventSequenceNumber  
    }  
STATUS current  
DESCRIPTION  
    "When it has been enabled, this notification is  
    generated when an Invalid Label Event occurs.  
  
    The notification indicates a change in the value of  
    gsmpSessionStatInvLabelEvents.  
  
    The session to which this notification  
    applies is identified by the gsmpSessionThisSideId and  
    gsmpSessionFarSideId which could be inferred from the  
    Object Identifier of the gsmpSessionStatInvLabelEvents  
    object contained in the notification."  
 ::= { gsmpNotifications 7 }  
  
gsmpNewPortEvent NOTIFICATION-TYPE  
    OBJECTS {  
        gsmpSessionStatNewPortEvents,  
        gsmpEventPort,  
        gsmpEventPortSessionNumber,  
        gsmpEventSequenceNumber  
    }  
STATUS current  
DESCRIPTION  
    "When it has been enabled, this notification is  
    generated when a New Port Event occurs.  
  
    The notification indicates a change in the value of  
    gsmpSessionStatNewPortEvents.  
  
    The session to which this notification  
    applies is identified by the gsmpSessionThisSideId and  
    gsmpSessionFarSideId which could be inferred from the  
    Object Identifier of the gsmpSessionStatNewPortEvents  
    object contained in the notification."  
 ::= { gsmpNotifications 8 }  
  
gsmpDeadPortEvent NOTIFICATION-TYPE  
    OBJECTS {  
        gsmpSessionStatDeadPortEvents,  
        gsmpEventPort,  
        gsmpEventPortSessionNumber,  
        gsmpEventSequenceNumber  
    }  
STATUS current
```


DESCRIPTION

"When it has been enabled, this notification is generated when a Dead Port Event occurs.

The notification indicates a change in the value of gsmpSessionStatDeadPortEvents.

The session to which this notification applies is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifier of the gsmpSessionStatDeadPortEvents object contained in the notification."

::= { gsmpNotifications 9 }

gsmpAdjacencyUpdateEvent NOTIFICATION-TYPE

OBJECTS {
 gsmpSessionAdjacencyCount,
 gsmpSessionStatAdjUpdateEvents,
 gsmpEventSequenceNumber
}

STATUS current

DESCRIPTION

"When it has been enabled, this notification is generated when an Adjacency Update Event occurs.

The gsmpSessionAdjacencyCount contains the new value of the number of adjacencies that are established with controllers and the switch partition that is used for this session.

The notification indicates a change in the value of gsmpSessionStatAdjUpdateEvents.

The session to which this notification applies is identified by the gsmpSessionThisSideId and gsmpSessionFarSideId which could be inferred from the Object Identifier of the gsmpSessionAdjacencyCount or the gsmpSessionStatAdjUpdateEvents object contained in the notification."

::= { gsmpNotifications 10 }


```

_ _*****
-- GSMP Compliance
_ _*****

gsmpGroups          OBJECT IDENTIFIER ::= { gsmpConformance 1 }
gsmpCompliances     OBJECT IDENTIFIER ::= { gsmpConformance 2 }

gsmpModuleCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "The compliance statement for agents that support
        the GSMP MIB."
    MODULE -- this module
    MANDATORY-GROUPS { gsmpGeneralGroup
                        }
    GROUP gsmpControllerGroup
    DESCRIPTION
        "This group is mandatory for all Switch
        Controllers"

    GROUP gsmpSwitchGroup
    DESCRIPTION
        "This group is mandatory for all Switches"

    GROUP gsmpAtmEncapGroup
    DESCRIPTION
        "This group must be supported if ATM is used for GSMP
        encapsulation. "

    GROUP gsmpTcpIpEncapGroup
    DESCRIPTION
        "This group must be supported if TCP/IP is used for GSMP
        encapsulation. "

    OBJECT gsmpTcpIpEncapAddressType
    SYNTAX InetAddressType { unknown(0), ipv4(1), ipv6(2),
                            ipv4z(3), ipv6z(4) }
    DESCRIPTION
        "An implementation is only required to support
        'unknown(0)', and IPv4 addresses. Supporting addresses with
        zone index or IPv6 addresses are optional. Defining
        Internet addresses by using DNS domain names are not
        allowed."

    OBJECT gsmpTcpIpEncapAddress
    SYNTAX InetAddress (SIZE(0|4|8|16|20))
    DESCRIPTION
        "An implementation is only required to support

```


IPv4 addresses. Supporting addresses with zone index or IPv6 addresses are optional."

GROUP gsmpNotificationObjectsGroup

DESCRIPTION

"This group must be supported if notifications are supported. "

GROUP gsmpNotificationsGroup

DESCRIPTION

"This group must be supported if notifications are supported. "

::= { gsmpCompliances 1 }

-- units of conformance

gsmpGeneralGroup OBJECT-GROUP

OBJECTS {

gsmpSessionVersion,
gsmpSessionTimer,
gsmpSessionPartitionId,
gsmpSessionAdjacencyCount,
gsmpSessionFarSideName,
gsmpSessionFarSidePort,
gsmpSessionFarSideInstance,
gsmpSessionLastFailureCode,
gsmpSessionDiscontinuityTime,
gsmpSessionStartUptime,
gsmpSessionStatSentMessages,
gsmpSessionStatFailureInds,
gsmpSessionStatReceivedMessages,
gsmpSessionStatReceivedFailures,
gsmpSessionStatPortUpEvents,
gsmpSessionStatPortDownEvents,
gsmpSessionStatInvLabelEvents,
gsmpSessionStatNewPortEvents,
gsmpSessionStatDeadPortEvents,
gsmpSessionStatAdjUpdateEvents
}

STATUS current

DESCRIPTION

"Objects that apply to all GSMP implementations."

::= { gsmpGroups 1 }

gsmpControllerGroup OBJECT-GROUP

OBJECTS {

gsmpControllerMaxVersion,


```
    gsmpControllerTimer,
    gsmpControllerPort,
    gsmpControllerInstance,
    gsmpControllerPartitionType,
    gsmpControllerPartitionId,
    gsmpControllerDoResync,
    gsmpControllerNotificationMap,
    gsmpControllerSessionState,
    gsmpControllerStorageType,
    gsmpControllerRowStatus
  }
STATUS      current
DESCRIPTION
    "Objects that apply GSMP implementations of
    Switch Controllers."
 ::= { gsmpGroups 2 }
```

```
gsmpSwitchGroup OBJECT-GROUP
  OBJECTS {
    gsmpSwitchMaxVersion,
    gsmpSwitchTimer,
    gsmpSwitchName,
    gsmpSwitchPort,
    gsmpSwitchInstance,
    gsmpSwitchPartitionType,
    gsmpSwitchPartitionId,
    gsmpSwitchNotificationMap,
    gsmpSwitchSwitchType,
    gsmpSwitchWindowSize,
    gsmpSwitchSessionState,
    gsmpSwitchStorageType,
    gsmpSwitchRowStatus
  }
STATUS      current
DESCRIPTION
    "Objects that apply GSMP implementations of
    Switches."
 ::= { gsmpGroups 3 }
```

```
gsmpAtmEncapGroup OBJECT-GROUP
  OBJECTS {
    gsmpAtmEncapIfIndex,
    gsmpAtmEncapVpi,
    gsmpAtmEncapVci,
    gsmpAtmEncapStorageType,
    gsmpAtmEncapRowStatus
  }
STATUS      current
```


DESCRIPTION

"Objects that apply to GSMP implementations that supports ATM for GSMP encapsulation."

::= { gsmpGroups 4 }

gsmpTcpIpEncapGroup OBJECT-GROUP

OBJECTS {
gsmpTcpIpEncapAddressType,
gsmpTcpIpEncapAddress,
gsmpTcpIpEncapPortNumber,
gsmpTcpIpEncapStorageType,
gsmpTcpIpEncapRowStatus
}

STATUS current

DESCRIPTION

"Objects that apply to GSMP implementations that supports TCP/IP for GSMP encapsulation."

::= { gsmpGroups 5 }

gsmpNotificationObjectsGroup OBJECT-GROUP

OBJECTS {
gsmpEventPort,
gsmpEventPortSessionNumber,
gsmpEventSequenceNumber,
gsmpEventLabel
}

STATUS current

DESCRIPTION

"Objects that are contained in the notifications."

::= { gsmpGroups 6 }

gsmpNotificationsGroup NOTIFICATION-GROUP

NOTIFICATIONS {
gsmpSessionDown,
gsmpSessionUp,
gsmpSentFailureInd,
gsmpReceivedFailureInd,
gsmpPortUpEvent,
gsmpPortDownEvent,
gsmpInvalidLabelEvent,
gsmpNewPortEvent,
gsmpDeadPortEvent,
gsmpAdjacencyUpdateEvent
}

STATUS current

DESCRIPTION

"The notifications which indicate specific changes in the value of objects gsmpSessionTable"


```
::= { gsmpGroups 7 }
```

END

5. Acknowledgments

The authors would like to thank Avri Doria and Kenneth Sundell for their contributions to this specification. Also thanks to David Partain, Michael MacFaden and Bert Wijnen who have contributed significantly with their SNMP expertise.

6. References

- [RFC1155] Rose, M. and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based Internets", STD 16, [RFC 1155](#), May 1990.
- [RFC1212] Rose, M. and K. McCloghrie, "Concise MIB Definitions", STD 16, [RFC 1212](#), March 1991.
- [RFC1215] Rose, M., "A Convention for Defining Traps for use with the SNMP", [RFC 1215](#), March 1991.
- [RFC1157] Case, J., Fedor, M., Schoffstall, M. and J. Davin, "Simple Network Management Protocol", STD 15, [RFC 1157](#), May 1990.
- [RFC1901] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Introduction to Community-based SNMPv2", [RFC 1901](#), January 1996.
- [RFC1905] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)", [RFC 1905](#), January 1996.
- [RFC1906] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)", [RFC 1906](#), January 1996.
- [RFC1987] Newman, P, Edwards, W., Hinden, R., Hoffman, E., Ching Liaw, F., Lyon, T. and Minshall, G., "Ipsilon's General Switch Management Protocol Specification," Version 1.1, [RFC 1987](#), August 1996.
- [RFC2021] Waldbusser, S., "Remote Network Monitoring Management Information Base Version 2 using SMIV2", [RFC 2021](#), January 1997.

- [RFC2026] Bradner, S., "The Internet Standards Process - Revision 3", [BCP 9](#), [RFC 2026](#), October 1996.
- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", [BCP 14](#), [RFC 2119](#), March 1997.
- [RFC2397] Newman, P, Edwards, W., Hinden, R., Hoffman, E., Ching Liaw, F., Lyon, T. and Minshall, G., "Ipsilon's General Switch Management Protocol Specification," Version 2.0, [RFC 2397](#), March 1998.
- [RFC2434] Narten, T. and H. Alvestrand, "Guidelines for Writing an IANA Considerations Section in RFCs.", [BCP 26](#), [RFC 2434](#), October 1998.
- [RFC2514] Noto, M., E. Spiegel, K. Tesink, "Definition of Textual Conventions and OBJECT-IDENTITIES for ATM Management", [RFC 2514](#), February 1999.
- [RFC2570] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction to Version 3 of the Internet-standard Network Management Framework", [RFC 2570](#), April 1999.
- [RFC2571] Harrington, D., Presuhn, R. and B. Wijnen, "An Architecture for Describing SNMP Management Frameworks", [RFC 2571](#), April 1999.
- [RFC2572] Case, J., Harrington D., Presuhn R. and B. Wijnen, "Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)", [RFC 2572](#), April 1999.
- [RFC2573] Levi, D., Meyer, P. and B. Stewart, "SNMP Applications", [RFC 2573](#), April 1999.
- [RFC2574] Blumenthal, U. and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", [RFC 2574](#), April 1999.
- [RFC2575] Wijnen, B., Presuhn, R. and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", [RFC 2575](#), April 1999.
- [RFC2578] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Structure of Management Information Version 2 (SMIv2)", STD 58, [RFC 2578](#), April 1999.

- [RFC2579] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Textual Conventions for SMIV2", STD 58, [RFC 2579](#), April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Conformance Statements for SMIV2", STD 58, [RFC 2580](#), April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB" [RFC 2863](#), June 2000.
- [RFC3291] Daniele, M., Haberman, B., Routhier, S. and J., Schoenwaelder "Textual Conventions for Internet Network Addresses", [RFC 3291](#), May 2002.
- [RFC3292] Doria, A., Hellstrand, F., Sundell, K. and T. Worster, "General Switch Management Protocol V3", [RFC 3292](#), June 2002.
- [RFC3293] Worster, T., Doria, A. and J. Buerkle, "General Switch Management Protocol (GSMP) Packet Encapsulations for Asynchronous Transfer Mode (ATM), Ethernet and Transmission Control Protocol (TCP)", [RFC 3293](#), June 2002.

7. Intellectual Property Rights

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in [BCP-11](#). Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

8. Security Considerations

Assuming that secure network management (such as SNMP v3) is implemented, the objects represented in this MIB do not pose a threat to the security of the network.

There are a number of management objects defined in this MIB that have a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

There are a number of managed objects in this MIB that may contain sensitive information. They are contained in the `gsmpControllerTable` and `gsmpSwitchTable`. It is thus important to control even GET access to these objects and possibly to even encrypt the values of these object when sending them over the network via SNMP. Not all versions of SNMP provide features for such a secure environment.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is recommended that the implementers consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model [RFC 2574](#) [[RFC2574](#)] and the View-based Access Control Model [RFC 2575](#) [[RFC2575](#)] is recommended.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to the objects, only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

9. Authors' Addresses

Hans Sjostrand
ipUnplugged
P.O. Box 101 60
S-121 28 Stockholm, Sweden

Phone: +46 8 725 5930
EMail: hans@ipunplugged.com

Joachim Buerkle
Nortel Networks Germany GmbH & Co. KG
Hahnstrasse 37-39
D-60528 Frankfurt am Main, Germany

Phone: +49 69 6697 3281
EMail: joachim.buerkle@nortelnetworks.com

Balaji Srinivasan
CPlane Inc.
897 Kifer Road
Sunnyvale, CA 94086

Phone: +1 408 789 4099
EMail: balaji@cplane.com

10. Full Copyright Statement

Copyright (C) The Internet Society (2002). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.

