

Network Working Group  
Internet-Draft  
Intended status: Standards Track  
Expires: January 16, 2014

J. Quittek  
R. Winter  
T. Dietz  
NEC Europe Ltd.  
July 15, 2013

Definition of Managed Objects for Battery Monitoring  
draft-ietf-eman-battery-mib-09

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines managed objects that provide information on the status of batteries in managed devices.

Status of this Memo

This Internet-Draft is submitted in full conformance with the provisions of BCP 78 and BCP 79.

Internet-Drafts are working documents of the Internet Engineering Task Force (IETF). Note that other groups may also distribute working documents as Internet-Drafts. The list of current Internet-Drafts is at <http://datatracker.ietf.org/drafts/current/>.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet-Drafts as reference material or to cite them other than as "work in progress."

This Internet-Draft will expire on January 16, 2014.

Copyright Notice

Copyright (c) 2013 IETF Trust and the persons identified as the document authors. All rights reserved.

This document is subject to BCP 78 and the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>) in effect on the date of publication of this document. Please review these documents carefully, as they describe your rights and restrictions with respect to this document. Code Components extracted from this document must include Simplified BSD License text as described in Section 4.e of the Trust Legal Provisions and are provided without warranty as described in the Simplified BSD License.

## Table of Contents

1. Introduction . . . . .	3
2. The Internet-Standard Management Framework . . . . .	4
3. Design of the Battery MIB Module . . . . .	5
3.1. MIB Module Structure . . . . .	5
3.2. Battery Technologies . . . . .	7
3.3. Charging Cycles . . . . .	8
4. Definitions . . . . .	8
5. Security Considerations . . . . .	28
6. IANA Considerations . . . . .	30
6.1. SMI Object Identifier Registration . . . . .	30
6.2. Battery Technology Registration . . . . .	30
7. Open Issues . . . . .	30
7.1. Battery replacement . . . . .	31
7.2. Compliance statements for notifications . . . . .	31
8. Acknowledgements . . . . .	31
9. References . . . . .	31
9.1. Normative References . . . . .	31
9.2. Informative References . . . . .	32
Authors' Addresses . . . . .	32

## 1. Introduction

Today, more and more managed devices contain batteries that supply them with power when disconnected from electrical power distribution grids. Common examples are nomadic and mobile devices, such as notebook computers, netbooks, and smart phones. The status of batteries in such a device, particularly the charging status is typically controlled by automatic functions that act locally on the device and manually by users of the device.

In addition to this, there is a need to monitor battery status of these devices by network management systems. This document defines a portion of the Management Information Base (MIB) that provides a means for monitoring batteries in or attached to managed devices. The Battery MIB module defined in Section 4 meets the requirements for monitoring the status of batteries specified in [I-D.ietf-eman-requirements].

The Battery MIB module provides for monitoring the battery status. According to the framework for energy management [I-D.ietf-eman-framework] it is an Energy Managed Object, and thus, MIB modules such as the Power and Energy Monitoring MIB [I-D.ietf-eman-energy-monitoring-mib] could in principle be implemented for batteries. The Battery MIB extends the more generic aspects of energy management by adding battery-specific information. Amongst other things, the Battery MIB enables the monitoring of:

- o the current charge of a battery,
- o the age of a battery (charging cycles),
- o the state of a battery (e.g. being re-charged),
- o last usage of a battery,
- o maximum energy provided by a battery (remaining and total capacity).

Further, means are provided for battery-powered devices to send notifications when the current battery charge has dropped below a certain threshold to inform the management system of needed replacement. The same applies to the age of a battery.

Many battery-driven devices have existing instrumentation for monitoring the battery status, because this is already needed for local control of the battery by the device. This reduces the effort for implementing the managed objects defined in this document. For many devices only additional software will be needed but no additional hardware instrumentation for battery monitoring.

Since there are a lot of devices in use that contain more than one battery, means for battery monitoring defined in this document

support addressing multiple batteries within a single device. Also, batteries today often come in packages that can include identification and might contain additional hardware and firmware. The former allows tracing a battery and allows continuous monitoring even if the battery is e.g. installed in another device. The firmware version is useful information as the battery behavior might be different for different firmware versions.

Not explicitly in scope of definitions in this document are very small backup batteries, such as for example, batteries used on PC motherboard to run the clock circuit and retain configuration memory while the system is turned off. Other means may be required for reporting on these batteries. However, the MIB module defined in Section 3.1 can be used for this purpose.

A traditional type of managed device containing batteries is an Uninterruptible Power Supply (UPS) system; these supply other devices with electrical energy when the main power supply fails. There is already a MIB module for managing UPS systems defined in RFC 1628 [RFC1628]. The UPS MIB module includes managed objects for monitoring the batteries contained in an UPS system. However, the information provided by the UPS MIB objects is limited and tailored the particular needs of UPS systems.

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "NOT RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119 [RFC2119].

## 2. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies MIB modules that are compliant to the SMIV2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

### 3. Design of the Battery MIB Module

#### 3.1. MIB Module Structure

The Battery MIB module defined in this document defines objects for reporting information about batteries. All managed objects providing information of the status of a battery are contained in a single table called `batteryTable`. The `batteryTable` contains one conceptual row per battery.

Batteries are indexed by the `entPhysicalIndex` of the `entPhysicalTable` defined in the ENTITY-MIB module [RFC6933]. An implementation of the ENTITY-MIB module complying with the `entity4CRCompliance MODULE-COMPLIANCE` statement is required for compliant implementations of the BATTERY-MIB module.

If batteries are replaced with the replacing battery using the same physical connector as the replaced battery had used, then the replacing battery SHOULD be indexed with the same value of object `entPhysicalIndex` as the replaced battery.

The kind of entity in the `entPhysicalTable` of the Entity MIB module is indicated by the value of enumeration object `entPhysicalClass`. All batteries SHOULD have the value of object `entPhysicalClass` set to `battery(14)` in their row of the `entPhysicalTable`.

The `batteryTable` contains three groups of objects. The first group (OIDs ending with 1-10) provides information on static properties of the battery. The second group of objects (OIDs ending with 11-18) provides information on the current battery state, if it is charging or discharging, how much it is charged, its remaining capacity, the number of experienced charging cycles, etc.

```

batteryTable(1)
+--batteryEntry(1) [entPhysicalIndex]
+-- r-n SnmpAdminString batteryIdentifier(1)
+-- r-n SnmpAdminString batteryFirmwareVersion(2)
+-- r-n Enumeration batteryType(3)
+-- r-n Unsigned32 batteryTechnology(4)
+-- r-n Unsigned32 batteryDesignVoltage(5)
+-- r-n Unsigned32 batteryNumberOfCells(6)
+-- r-n Unsigned32 batteryDesignCapacity(7)
+-- r-n Unsigned32 batteryMaxChargingCurrent(8)
+-- r-n Unsigned32 batteryTrickleChargingCurrent(9)
+-- r-n Unsigned32 batteryActualCapacity(10)
+-- r-n Unsigned32 batteryChargingCycleCount(11)
+-- r-n DateAndTime batteryLastChargingCycleTime(12)
+-- r-n Enumeration batteryChargingOperState(13)
+-- rwn Enumeration batteryChargingAdminState(14)
+-- r-n Unsigned32 batteryActualCharge(15)
+-- r-n Unsigned32 batteryActualVoltage(16)
+-- r-n Integer32 batteryActualCurrent(17)
+-- r-n Integer32 batteryTemperature(18)
+-- r-n SnmpAdminString batteryCellIdentifier(19)
+-- rwn Unsigned32 batteryAlarmLowCharge(20)
+-- rwn Unsigned32 batteryAlarmLowVoltage(21)
+-- rwn Unsigned32 batteryAlarmLowCapacity(22)
+-- rwn Unsigned32 batteryAlarmHighCycleCount(23)
+-- rwn Integer32 batteryAlarmHighTemperature(24)
+-- rwn Integer32 batteryAlarmLowTemperature(25)

```

The third group of objects in this table (OIDs ending with 20-25) indicates thresholds which can be used to raise an alarm if a property of the battery exceeds one of them. Raising an alarm may include sending a notification.

The Battery MIB defines seven notifications for indicating

1. a battery charging state change that was not triggered by writing to object batteryChargingAdminState,
2. a low battery charging state,
3. a critical battery that cannot be used anymore for power supply,
4. an aged battery that may need to be replaced,
5. a battery exceed a temperature threshold,
6. a battery that has been connected,
7. disconnection of one or more batteries.

Notifications 2.-5. can use object batteryCellIdentifier to indicate a specific cell or a set of cells within the battery that have triggered the notification.

### 3.2. Battery Technologies

Static information in the batteryTable includes battery type and technology. The battery type distinguishes primary (not rechargeable) batteries from rechargeable (secondary) batteries and capacitors. The battery technology describes the actual technology of a battery, which typically is a chemical technology.

Since battery technologies are subject of intensive research and widely used technologies are often replaced by successor technologies within an few years, the list of battery technologies was not chosen as a fixed list. Instead, IANA has created a registry for battery technologies at <http://www.iana.org/assignments/eman> where numbers are assigned to battery technologies (TBD).

The table below shows battery technologies known today that are in commercial use with the numbers assigned to them by IANA. New entries can be added to the IANA registry if new technologies are developed or if missing technologies are identified. Note that there exists a huge number of battery types that are not listed in the IANA registry. Many of them are experimental or cannot be used in an economically useful way. New entries should be added to the IANA registry only if the respective technologies are in commercial use and relevant to standardized battery monitoring over the Internet.

battery technology	assigned number
Unknown	1
Other	2
Zinc-carbon	3
Zinc chloride	4
Nickel oxyhydroxide	5
Lithium-copper oxide	6
Lithium-iron disulfide	7
Lithium-manganese dioxide	8
Zinc-air	9
Silver oxide	10
Alkaline	11
Lead acid	12
Nickel-cadmium	13
Nickel-metal hydride	14
Nickel-zinc	15
Lithium-ion	16
Lithium polymer	17
Double layer capacitor	18

### 3.3. Charging Cycles

The lifetime of a battery can be approximated using the measure of charging cycles. A commonly used definition of a charging cycle is the amount of discharge equal to the design (or nominal) capacity of the battery [SBS]. This means that a single charging cycle may include several steps of partial charging and discharging until the amount of discharging has reached the design capacity of the battery. After that the next charging cycle immediately starts.

## 4. Definitions

```
BATTERY-MIB DEFINITIONS ::= BEGIN
```

```
IMPORTS
```

```
    MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE,
    mib-2, Integer32, Unsigned32
        FROM SNMPv2-SMI                                -- RFC2578
    SnmpAdminString
        FROM SNMP-FRAMEWORK-MIB                        -- RFC3411
    DateAndTime
        FROM SNMPv2-TC                                -- RFC2579
    MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
        FROM SNMPv2-CONF                                -- RFC2580
    entPhysicalIndex
        FROM ENTITY-MIB                                -- RFC6933
    Unsigned64TC
        FROM APPLICATION-MIB;                          -- RFC2564
```

```
batteryMIB MODULE-IDENTITY
```

```
    LAST-UPDATED "201307151200Z"                      -- 15 july 2013
    ORGANIZATION "IETF EMAN Working Group"
    CONTACT-INFO
        "General Discussion: eman@ietf.org
        To Subscribe: http://www.ietf.org/mailman/listinfo/eman
        Archive: http://www.ietf.org/mail-archive/web/eman
```

```
    Editor:
```

```
        Juergen Quittek
        NEC Europe Ltd.
        NEC Laboratories Europe
        Kurfuersten-Anlage 36
        69115 Heidelberg
        Germany
        Tel: +49 6221 4342-115
        Email: quittek@neclab.eu"
```



## DESCRIPTION

"This MIB module defines a set of objects for monitoring batteries of networked devices and of their components.

Copyright (c) 2010 IETF Trust and the persons identified as authors of the code. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, is permitted pursuant to, and subject to the license terms contained in, the Simplified BSD License set forth in Section 4.c of the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>).

This version of this MIB module is part of RFC yyyy; see the RFC itself for full legal notices."

-- replace yyyy with actual RFC number & remove this notice

-- Revision history

REVISION "201307151200Z" -- 15 July 2013

## DESCRIPTION

"Initial version, published as RFC yyyy."

-- replace yyyy with actual RFC number & remove this notice

::= { mib-2 zzz }

-- zzz to be assigned by IANA.

--\*\*\*\*\*

-- Top Level Structure of the MIB module

--\*\*\*\*\*

batteryNotifications OBJECT IDENTIFIER ::= { batteryMIB 0 }  
 batteryObjects OBJECT IDENTIFIER ::= { batteryMIB 1 }  
 batteryConformance OBJECT IDENTIFIER ::= { batteryMIB 2 }

--=====

-- 1. Object Definitions

--=====

-----  
 -- 1.1. Battery Table  
 -----

batteryTable OBJECT-TYPE  
 SYNTAX SEQUENCE OF BatteryEntry  
 MAX-ACCESS not-accessible  
 STATUS current  
 DESCRIPTION

"This table provides information on batteries. It contains one conceptual row per battery.

Batteries are indexed by the entPhysicalIndex of the entPhysicalTable defined in the ENTITY-MIB (RFC6933).

For implementations of the BATTERY-MIB an implementation of the ENTITY-MIB complying with the entity4CRCompliance MODULE-COMPLIANCE statement of the ENTITY-MIB is required.

If batteries are replaced with the replacing battery using the same physical connector as the replaced battery had used, then the replacing battery SHOULD be indexed with the same value of object entPhysicalIndex as the replaced battery."

```
::= { batteryObjects 1 }
```

```
batteryEntry OBJECT-TYPE
```

```
SYNTAX      BatteryEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

```
"An entry providing information on a battery."
```

```
INDEX { entPhysicalIndex }
```

```
::= { batteryTable 1 }
```

```
BatteryEntry ::=
```

```
SEQUENCE {
```

batteryIdentifier	SnmpAdminString,
batteryFirmwareVersion	SnmpAdminString,
batteryType	INTEGER,
batteryTechnology	Unsigned32,
batteryDesignVoltage	Unsigned32,
batteryNumberOfCells	Unsigned32,
batteryDesignCapacity	Unsigned32,
batteryMaxChargingCurrent	Unsigned32,
batteryTrickleChargingCurrent	Unsigned32,
batteryActualCapacity	Unsigned32,
batteryChargingCycleCount	Unsigned32,
batteryLastChargingCycleTime	DateAndTime,
batteryChargingOperState	INTEGER,
batteryChargingAdminState	INTEGER,
batteryActualCharge	Unsigned64TC,
batteryActualVoltage	Unsigned32,
batteryActualCurrent	Integer32,
batteryTemperature	Integer32,
batteryCellIdentifier	SnmpAdminString,
batteryAlarmLowCharge	Unsigned32,

```
        batteryAlarmLowVoltage      Unsigned32,
        batteryAlarmLowCapacity     Unsigned32,
        batteryAlarmHighCycleCount  Unsigned32,
        batteryAlarmHighTemperature Integer32,
        batteryAlarmLowTemperature  Integer32
    }

batteryIdentifier OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object contains an identifier for the battery.

        Many manufacturers deliver not only simple batteries but
        battery packages including additional hardware and firmware.
        Typically, these modules include an identifier that can be
        retrieved by a device in which a battery has been installed.
        The identifier is useful when batteries are removed and
        re-installed in the same or other devices. Then the device
        or the network management system can trace batteries and
        achieve continuity of battery monitoring.

        If the battery identifier cannot be represented using the
        ISO/IEC IS 10646-1 character set, then a hexadecimal
        encoding of a binary representation of the battery
        identifier must be used.

        The value of this object must be an empty string if there
        is no battery identifier or if the battery identifier is
        unknown."
    ::= { batteryEntry 1 }

batteryFirmwareVersion OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object indicates the version number of the firmware
        that is included in a battery module.

        Many manufacturers deliver not pure batteries but battery
        packages including additional hardware and firmware.

        Since the behavior of the battery may change with the
        firmware, it may be useful to retrieve the firmware version
        number.
```

The value of this object must be an empty string if there is no firmware or if the version number of the firmware is unknown."

::= { batteryEntry 2 }

batteryType OBJECT-TYPE

SYNTAX INTEGER {  
    unknown(1),  
    other(2),  
    primary(3),  
    rechargeable(4),  
    capacitor(5)  
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the type of battery. It distinguishes between primary (not rechargeable) batteries, rechargeable (secondary) batteries and capacitors which are not really batteries but often used in the same way as a battery.

The value other(2) can be used if the battery type is known but none of the ones above. Value unknown(1) is to be used if the type of battery cannot be determined."

::= { batteryEntry 3 }

batteryTechnology OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object indicates the technology used by the battery. Numbers identifying battery types are registered at IANA. A current list of assignments can be found at <<http://www.iana.org/assignments/eman>>.

Value 0 (unknown) MUST be used if the type of battery cannot be determined.

Value 1 (other) can be used if the battery type is known but not one of the types already registered at IANA."

::= { batteryEntry 4 }

batteryDesignVoltage OBJECT-TYPE

SYNTAX Unsigned32

UNITS "millivolt"

MAX-ACCESS read-only

STATUS current  
DESCRIPTION  
"This object provides the design (or nominal) voltage of the battery in units of millivolt (mV).

Note that the design voltage is a constant value and typically different from the actual voltage of the battery.

A value of 0 indicates that the design voltage is unknown."  
::= { batteryEntry 5 }

batteryNumberOfCells OBJECT-TYPE

SYNTAX Unsigned32  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION

"This object indicates the number of cells contained in the battery.

A value of 0 indicates that the number of cells is unknown."  
::= { batteryEntry 6 }

batteryDesignCapacity OBJECT-TYPE

SYNTAX Unsigned32  
UNITS "milliamperere hours"  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION

"This object provides the design (or nominal) capacity of the battery in units of milliamperere hours (mAh).

Note that the design capacity is a constant value and typically different from the actual capacity of the battery. Usually, this is a value provided by the manufacturer of the battery.

A value of 0 indicates that the design capacity is unknown."  
::= { batteryEntry 7 }

batteryMaxChargingCurrent OBJECT-TYPE

SYNTAX Unsigned32  
UNITS "milliamperere"  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION

"This object provides the maximal current to be used for charging the battery in units of milliamperere (mA).

Note that the maximal charging current may not lead to optimal charge of the battery and that some batteries can only be charged with the maximal current for a limited amount of time.

A value of 0 indicates that the maximal charging current is unknown."

::= { batteryEntry 8 }

batteryTrickleChargingCurrent OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the recommended current to be used for trickle charging the battery in units of milliampere (mA).

Typically, this is a value recommended by the manufacturer of the battery or by the manufacturer of the charging circuit.

A value of 0 indicates that the recommended trickle charging current is unknown."

::= { batteryEntry 9 }

batteryActualCapacity OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere hours"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the actual capacity of the battery in units of milliampere hours (mAh).

Typically, the actual capacity of a battery decreases with time and with usage of the battery. It is usually lower than the design capacity

Note that the actual capacity needs to be measured and is typically an estimate based on observed discharging and charging cycles of the battery.

A value of 'ffffffff'H indicates that the actual capacity cannot be determined."

::= { batteryEntry 10 }

batteryChargingCycleCount OBJECT-TYPE

SYNTAX           Unsigned32  
 MAX-ACCESS   read-only  
 STATUS         current  
 DESCRIPTION

"This object indicates the number of completed charging cycles that the battery underwent. In line with the Smart Battery Data Specification Revision 1.1, a charging cycle is defined as the process of discharging the battery by a total amount equal to the battery design capacity as given by object batteryDesignCapacity. A charging cycle may include several steps of charging and discharging the battery until the discharging amount given by batteryDesignCapacity has been reached. As soon as a charging cycle has been completed the next one starts immediately independent of the battery's current charge at the end of the cycle.

For batteries of type primary(1) the value of this object is always 0.

A value of 'ffffffff'H indicates that the number of charging cycles cannot be determined."

::= { batteryEntry 11 }

batteryLastChargingCycleTime OBJECT-TYPE

SYNTAX           DateAndTime  
 MAX-ACCESS   read-only  
 STATUS         current  
 DESCRIPTION

"The date and time of the last charging cycle. The value '0000000000000000'H is returned if the battery has not been charged yet or if the last charging time cannot be determined.

For batteries of type primary(1) the value of this object is always '0000000000000000'H."

::= { batteryEntry 12 }

batteryChargingOperState OBJECT-TYPE

SYNTAX           INTEGER {  
                   unknown(1),  
                   charging(2),  
                   fastCharging(3),  
                   maintainingCharge(4),  
                   noCharging(5),  
                   discharging(6)  
                   }  
 }

MAX-ACCESS read-only  
STATUS current  
DESCRIPTION

"This object indicates the current charging state of the battery.

Value unknown(1) indicates that the charging state of the battery cannot be determined.

Value charging(2) indicates that the battery is being charged in a way that the charge of the battery increases.

Value fastCharging(3) indicated that the battery is being charged rapidly, i.e. faster than in the charging(2) state. If multiple fast charging states exist, all of these states are indicated by fastCharging(3).

Value maintainingCharge(4) indicates that the battery is being charged with a low current that compensates self-discharging. This includes trickle charging, float charging and other methods for maintaining the current charge of a battery.

Value noCharging(5) indicates that the battery is not being charged or discharged by electric current between the battery and electric circuits external to the battery. Note that the battery may still be subject to self-discharging.

Value discharging(6) indicates that the battery is being discharged and that the charge of the battery decreases."

::= { batteryEntry 13 }

batteryChargingAdminState OBJECT-TYPE

SYNTAX INTEGER {  
    charging(2),  
    fastCharging(3),  
    maintainingCharge(4),  
    noCharging(5),  
    discharging(6),  
    notSet(7)  
}

MAX-ACCESS read-write  
STATUS current

DESCRIPTION

"The value of this object indicates the desired status of the charging state of the battery. The real state is indicated by object batteryChargingOperState. See the



definition of object batteryChargingOperState for a description of the values.

When this object is initialized by an implementation of the BATTERY-MIB module, its value is set to notSet(7).

However, a SET request can only set this object to either charging(2), fastCharging(3), maintainingCharge(4), noCharging(5), or discharging(6). Attempts to set this object to notSet(7) will always fail with an 'inconsistentValue' error. In case multiple fast charging states exist, the battery logic can choose an appropriate fast charging state - preferably the fastest.

When the batteryChargingAdminState object is set, then the BATTERY-MIB implementation must try to set the battery to the indicated state. The result will be indicated by object batteryChargingOperState.

Due to operational conditions and limitations of the implementation of the BATTERY-MIB module, changing the battery status according to a set value of object batteryChargingAdminState may not be possible.

Setting the value of object batteryChargingAdminState may result in not changing the state of the battery to this value or even in setting the charging state to another value. For example, setting batteryChargingAdminState to value fastCharging(3) may have no effect when the battery logic is not allowing fast charging due to temperature constraints."

```
::= { batteryEntry 14 }
```

batteryActualCharge OBJECT-TYPE

SYNTAX Unsigned64TC

UNITS "milliampere hours"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object provides the actual charge of the battery in units of milliampere hours (mAh).

Note that the actual charge needs to be measured and is typically an estimate based on observed discharging and charging cycles of the battery.

A value of 'ffffffff'H indicates that the actual charge

```
        cannot be determined."
 ::= { batteryEntry 15 }

batteryActualVoltage OBJECT-TYPE
    SYNTAX      Unsigned32
    UNITS       "millivolt"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object provides the actual voltage of the battery
        in units of millivolt (mV).

        A value of 'ffffffff'H indicates that the actual voltage
        cannot be determined."
 ::= { batteryEntry 16 }

batteryActualCurrent OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "milliampere"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object provides the actual charging or discharging
        current of the battery in units of milliampere (mA).
        Charging current is represented by positive values,
        discharging current is represented by negative values.

        A value of '7fffffff'H indicates that the actual current
        cannot be determined."
 ::= { batteryEntry 17 }

batteryTemperature OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "deci-degrees Celsius"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The ambient temperature at or near the battery.

        A value of '7fffffff'H indicates that the temperature
        cannot be determined."
 ::= { batteryEntry 18 }

batteryCellIdentifier OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
```

"The value of this object identifies one or more cells of a battery. The format of the cell identifier may vary between different implementations. It should uniquely identify one or more cells of the indexed battery.

This object can be used for batteries, such as, for example, lithium polymer batteries for which battery controllers monitor cells individually.

This object is used by notifications of type `batteryLowNotification`, `batteryTemperatureNotification`, `batteryCriticalNotification`, and `batteryAgingNotification`. These notifications can use the value of this object to indicate the event that triggered the generation of the notification in more details by specifying a single cell or a set of cells within the battery which are specifically addressed by the notification.

An example use case for this object is a single cell in a battery that exceeds the temperature indicated by object `batteryAlarmHighTemperature`. In such a case, a `batteryTemperatureNotification` can be generated that not just indicates the battery for which the temperature is exceeded but also the particular cell.

The initial value of this object is the empty string. The value of this object is set at each time a `batteryLowNotification`, a `batteryTemperatureNotification`, a `batteryCriticalNotification`, or a `batteryAgingNotification` is generated.

When a notification is generated that does not indicate a specific cell or set of cells, the value of this object is set to the empty string."

::= { batteryEntry 19 }

`batteryAlarmLowCharge` OBJECT-TYPE

SYNTAX        Unsigned32  
UNITS         "milliampere hours"  
MAX-ACCESS    read-write  
STATUS        current  
DESCRIPTION

"This object provides the lower threshold value for object `batteryActualCharge`. If the value of object `batteryActualCharge` falls below this threshold, a low battery alarm will be raised. The alarm procedure may include generating a `batteryLowNotification`.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualCharge."

::= { batteryEntry 20 }

batteryAlarmLowVoltage OBJECT-TYPE

SYNTAX Unsigned32

UNITS "millivolt"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the lower threshold value for object batteryActualVoltage. If the value of object batteryActualVoltage falls below this threshold, a low battery alarm will be raised. The alarm procedure may include generating a batteryLowNotification.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualVoltage."

::= { batteryEntry 21 }

batteryAlarmLowCapacity OBJECT-TYPE

SYNTAX Unsigned32

UNITS "milliampere hours"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the lower threshold value for object batteryActualCapacity. If the value of object batteryActualCapacity falls below this threshold, a battery aging alarm will be raised. The alarm procedure may include generating a batteryAgingNotification.

A value of 0 indicates that no alarm will be raised for any value of object batteryActualCapacity."

::= { batteryEntry 22 }

batteryAlarmHighCycleCount OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This object provides the upper threshold value for object batteryChargingCycleCount. If the value of object batteryChargingCycleCount rises above this threshold, a battery aging alarm will be raised. The alarm procedure may include generating a batteryAgingNotification.

A value of 0 indicates that no alarm will be raised for any

```
        value of object batteryChargingCycleCount."
 ::= { batteryEntry 23 }
```

batteryAlarmHighTemperature OBJECT-TYPE

```
SYNTAX      Integer32
UNITS       "deci-degrees Celsius"
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "This object provides the upper threshold value for object
    batteryTemperature.  If the value of object
    batteryTemperature rises above this threshold, a battery
    high temperature alarm will be raised.  The alarm procedure
    may include generating a batteryTemperatureNotification.
```

```
    A value of '7fffffff'H indicates that no alarm will be
    raised for any value of object batteryTemperature."
 ::= { batteryEntry 24 }
```

batteryAlarmLowTemperature OBJECT-TYPE

```
SYNTAX      Integer32
UNITS       "deci-degrees Celsius"
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "This object provides the lower threshold value for object
    batteryTemperature.  If the value of object
    batteryTemperature falls below this threshold, a battery
    low temperature alarm will be raised.  The alarm procedure
    may include generating a batteryTemperatureNotification.
```

```
    A value of '7fffffff'H indicates that no alarm will be
    raised for any value of object batteryTemperature."
 ::= { batteryEntry 25 }
```

```
-----
-- 2. Notifications
-----
```

batteryChargingStateNotification NOTIFICATION-TYPE

```
OBJECTS     {
    batteryChargingOperState
}
STATUS      current
DESCRIPTION
    "This notification can be generated when a charging state
    of the battery (indicated by the value of object
```

batteryChargingOperState) is triggered by an event other than a write action to object batteryChargingAdminState. Such an event may, for example, be triggered by a local battery controller."

```
::= { batteryNotifications 1 }
```

batteryLowNotification NOTIFICATION-TYPE

```
OBJECTS      {
    batteryActualCharge,
    batteryActualVoltage,
    batteryCellIdentifier
}
STATUS       current
DESCRIPTION
    "This notification can be generated when the current charge
    (batteryActualCharge) or the current voltage
    (batteryActualVoltage) of the battery falls below a
    threshold defined by object batteryAlarmLowCharge or object
    batteryAlarmLowVoltage, respectively.
```

The notification should not be sent again before the current voltage or the current charge becomes higher than the respective thresholds through charging before falling below the thresholds again.

If the low charge or voltage has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object batteryCellIdentifier should be set to a value that identifies the cell or set of cells. Otherwise, the value of object batteryCellIdentifier should be set to the empty string when this notification is generated."

```
::= { batteryNotifications 2 }
```

batteryCriticalNotification NOTIFICATION-TYPE

```
OBJECTS      {
    batteryActualCharge,
    batteryActualVoltage,
    batteryCellIdentifier
}
STATUS       current
DESCRIPTION
    "This notification can be generated when the current charge
    of the battery falls so low that it cannot provide a power
    supply function anymore and below and needs to be charged
    first before it can be used for power supply again.
    threshold defined by object batteryAlarmLowCharge or object
    batteryAlarmLowVoltage, respectively.
```

The notification should not be sent again before the battery charge has increased to a non-critical value.

If the critical state is caused a single cell or a set of cells of the battery, then object `batteryCellIdentifier` should be set to a value that identifies the cell or set of cells. Otherwise, the value of object `batteryCellIdentifier` should be set to the empty string when this notification is generated."

::= { batteryNotifications 3 }

`batteryTemperatureNotification` NOTIFICATION-TYPE

OBJECTS {  
    **batteryTemperature**,  
    **batteryCellIdentifier**  
}

STATUS current

DESCRIPTION

"This notification can be generated when the measured temperature (`batteryTemperature`) rises above the threshold defined by object `batteryAlarmHighTemperature` or falls below the threshold defined by object `batteryAlarmLowTemperature`.

If the low or high temperature has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object `batteryCellIdentifier` should be set to a value that identifies the cell or set of cells. Otherwise, the value of object `batteryCellIdentifier` should be set to the empty string when this notification is generated."

::= { batteryNotifications 4 }

`batteryAgingNotification` NOTIFICATION-TYPE

OBJECTS {  
    **batteryActualCapacity**,  
    **batteryChargingCycleCount**,  
    **batteryCellIdentifier**  
}

STATUS current

DESCRIPTION

"This notification can be generated when the actual capacity (`batteryActualCapacity`) falls below a threshold defined by object `batteryAlarmLowCapacity` or when the charging cycle count of the battery (`batteryChargingCycleCount`) exceeds the threshold defined by object `batteryAlarmHighCycleCount`.

If the aging has been detected for a single cell or a set of cells of the battery and not for the entire battery, then object batteryCellIdentifier should be set to a value that identifies the cell or set of cells. Otherwise, the value of object batteryCellIdentifier should be set to the empty string when this notification is generated."

```
::= { batteryNotifications 5 }
```

```
batteryConnectedNotification NOTIFICATION-TYPE
```

```
  OBJECTS      {
    batteryIdentifier
  }
```

```
  STATUS      current
```

```
  DESCRIPTION
```

"This notification can be generated when it has been detected that a battery has been connected. The battery can be identified by the value of object batteryIdentifier as well as by the value of index entPhysicalIndex that is contained in the OID of object batteryIdentifier."

```
::= { batteryNotifications 6 }
```

```
batteryDisconnectedNotification NOTIFICATION-TYPE
```

```
  STATUS      current
```

```
  DESCRIPTION
```

"This notification can be generated when it has been detected that one or more batteries have been disconnected."

```
::= { batteryNotifications 7 }
```

```
-----
-- 3. Conformance Information
-----
```

```
batteryCompliances OBJECT IDENTIFIER ::= { batteryConformance 1 }
batteryGroups      OBJECT IDENTIFIER ::= { batteryConformance 2 }
```

```
-----
-- 3.1. Compliance Statements
-----
```

```
batteryCompliance MODULE-COMPLIANCE
```

```
  STATUS      current
```

```
  DESCRIPTION
```

"The compliance statement for implementations of the BATTERY-MIB module.

A compliant implementation MUST implement the objects defined in the mandatory groups batteryDescriptionGroup



and batteryStatusGroup.

Note that compliance with this compliance statement requires compliance with the entity4CRCompliance MODULE-COMPLIANCE statement of the ENTITY-MIB (RFC6933)."

MODULE -- this module

```
MANDATORY-GROUPS {  
    batteryDescriptionGroup,  
    batteryStatusGroup  
}
```

GROUP batteryAlarmThresholdsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryAlarmThresholdsGroup."

GROUP batteryNotificationsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryNotificationsGroup."

GROUP batteryPerCellNotificationsGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryPerCellNotificationsGroup."

GROUP batteryAdminGroup

DESCRIPTION

"A compliant implementation does not have to implement the batteryAdminGroup."

OBJECT batteryAlarmLowCharge

MIN-ACCESS read-only

DESCRIPTION

"The agent is not required to support set operations to this object."

OBJECT batteryAlarmLowVoltage

MIN-ACCESS read-only

DESCRIPTION

"The agent is not required to support set operations to this object."

OBJECT batteryAlarmLowCapacity

MIN-ACCESS read-only

DESCRIPTION

"The agent is not required to support set

operations to this object."

OBJECT batteryAlarmHighCycleCount

MIN-ACCESS read-only

DESCRIPTION

"The agent is not required to support set  
operations to this object."

OBJECT batteryTemperatureNotification

MIN-ACCESS read-only

DESCRIPTION

"The agent is not required to support set  
operations to this object."

::= { batteryCompliances 1 }

---

-- 3.2. MIB Grouping

---

batteryDescriptionGroup OBJECT-GROUP

OBJECTS {

batteryIdentifier,  
batteryFirmwareVersion,  
batteryType,  
batteryTechnology,  
batteryDesignVoltage,  
batteryNumberOfCells,  
batteryDesignCapacity,  
batteryMaxChargingCurrent,  
batteryTrickleChargingCurrent

}

STATUS current

DESCRIPTION

"A compliant implementation MUST implement the objects  
contained in this group."

::= { batteryGroups 1 }

batteryStatusGroup OBJECT-GROUP

OBJECTS {

batteryActualCapacity,  
batteryChargingCycleCount,  
batteryLastChargingCycleTime,  
batteryChargingOperState,  
batteryActualCharge,  
batteryActualVoltage,  
batteryActualCurrent,  
batteryTemperature

```
    }
    STATUS          current
    DESCRIPTION
        "A compliant implementation MUST implement the objects
        contained in this group."
    ::= { batteryGroups 2 }

batteryAdminGroup OBJECT-GROUP
    OBJECTS {
        batteryChargingAdminState
    }
    STATUS          current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        object contained in this group."
    ::= { batteryGroups 3 }

batteryAlarmThresholdsGroup OBJECT-GROUP
    OBJECTS {
        batteryAlarmLowCharge,
        batteryAlarmLowVoltage,
        batteryAlarmLowCapacity,
        batteryAlarmHighCycleCount,
        batteryAlarmHighTemperature,
        batteryAlarmLowTemperature
    }
    STATUS          current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        objects contained in this group."
    ::= { batteryGroups 4 }

batteryNotificationsGroup NOTIFICATION-GROUP
    NOTIFICATIONS {
        batteryChargingStateNotification,
        batteryLowNotification,
        batteryCriticalNotification,
        batteryAgingNotification,
        batteryTemperatureNotification,
        batteryConnectedNotification,
        batteryDisconnectedNotification
    }
    STATUS          current
    DESCRIPTION
        "A compliant implementation does not have to implement the
        notifications contained in this group."
    ::= { batteryGroups 5 }
```

```
batteryPerCellNotificationsGroup OBJECT-GROUP
  OBJECTS {
    batteryCellIdentifier
  }
  STATUS      current
  DESCRIPTION
    "A compliant implementation does not have to implement the
    object contained in this group."
  ::= { batteryGroups 6 }
END
```

## 5. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

- o batteryChargingAdminState  
Setting the battery charging state can be beneficial for an operator for various reasons such as charging batteries when the price of electricity is low. However, setting the charging state can be used by an attacker to discharge batteries of devices and thereby switching these devices off if they are powered solely by batteries. In particular, if the batteryAlarmLowCharge and batteryAlarmLowVoltage can also be set, this attack will go unnoticed (i.e. no notifications are sent).
- o batteryAlarmLowCharge and batteryAlarmLowVoltage  
These objects set the threshold for an alarm to be raised when the battery charge or voltage falls below the corresponding one of them. An attacker setting one of these alarm values can switch off the alarm by setting it to the 'off' value 0 or modify the alarm behavior by setting it to any other value. The result may be loss of data if the battery runs empty without warning to a recipient expecting such a notification.
- o batteryAlarmLowCapacity and batteryAlarmHighCycleCount  
These objects set the threshold for an alarm to be raised when the battery becomes older and less performant than required for stable operation. An attacker setting this alarm value can switch off the alarm by setting it to the 'off' value 0 or modify the alarm behavior by setting it to any other value. This may either lead to a costly replacement of a working battery or too old or too weak batteries being used. The consequence of the latter could

e.g. be that a battery cannot provide power long enough between two scheduled charging actions causing the powered device to shut down and potentially lose data.

- o batteryAlarmHighTemperature and batteryAlarmLowTemperature  
These objects set thresholds for an alarm to be raised when the battery rises above/falls below them. An attacker setting one of these alarm values can switch off these alarms by setting them to the 'off' value '7fffffff'H or modify the alarm behavior by setting them to any other value. The result may e.g. be an unnecessary shutdown of a device if batteryAlarmHighTemperature is set to too low or damage to the device by too high temperatures if switched off or set to too high values or by damage to the battery when it e.g. is being charged. Batteries can also be damaged e.g. in an attempt to charge them at too low temperatures.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over the network via SNMP. These are the tables and objects and their sensitivity/vulnerability:

All potentially sensible or vulnerable objects of this MIB module are in the batteryTable. In general, there are no serious operational vulnerabilities foreseen in case of an unauthorized read access to this table. However, privacy issues need to be considered. It may be a trade secret of the operator

- o how many batteries are installed in a managed node (batteryIndex)
- o how old these batteries are (batteryActualCapacity and batteryChargingCycleCount)
- o when the next replacement cycle for batteries can be expected (batteryAlarmLowCapacity and batteryAlarmHighCycleCount)
- o what battery type and make are used with which firmware version (batteryIdentifier, batteryFirmwareVersion, batteryType, and batteryTechnology)

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPsec), there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [RFC3410], section 8), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to GET or SET (change/create/delete) them.

## 6. IANA Considerations

### 6.1. SMI Object Identifier Registration

The Battery MIB module defined in this document uses the following IANA-assigned OBJECT IDENTIFIER value recorded in the SMI Numbers registry:

Descriptor	OBJECT IDENTIFIER value
-----	-----
batteryMIB	{ mib-2 xxx }

[NOTE for IANA: Please allocate an object identifier at <http://www.iana.org/assignments/smi-numbers> for object batteryMIB.]

### 6.2. Battery Technology Registration

Object batteryTechnology defined in Section 4 reports battery technologies. Eighteen values for battery technologies have initially been defined. They are listed in a table in Section 3.2.

For ensuring extensibility of this list, IANA has created a registry for battery technologies at <http://www.iana.org/assignments/eman> and filled it with the initial list given in Section 3.2.

New assignments of numbers for battery technologies will be administered by IANA through Expert Review ([RFC5226]). Experts must check for sufficient relevance of a battery technology to be added.

[NOTE for IANA: Please create a new registry under <http://www.iana.org/assignments/eman> for battery types. Please fill the registry with values from the table in Section 3.2]

## 7. Open Issues

### 7.1. Battery replacement

How to deal with IDs in case of replacement of a battery? If a battery is replaced, shall the UUID in the entPhysicalTable be replaced by a new one?. Proposal: keep the UUID for the entity and use the batteryIdentifier to identify moving batteries.

### 7.2. Compliance statements for notifications

Compliance statements for Notifications need to be revisited and if necessary elaborated.

## 8. Acknowledgements

We would like to thank Steven Chew and Bill Mielke for their valuable input.

## 9. References

### 9.1. Normative References

- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [RFC5226] Narten, T. and H. Alvestrand, "Guidelines for Writing an IANA Considerations Section in RFCs", BCP 26, RFC 5226, May 2008.
- [RFC2578] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [RFC2579] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [RFC6933] Bierman, A., Romascanu, D., Quittek, J., and M. Chandramouli, "Entity MIB (Version 4)", RFC 6933, May 2013.

## 9.2. Informative References

- [I-D.ietf-eman-requirements]  
Quittek, J., Chandramouli, M., Winter, R., Dietz, T., and  
B. Claise, "Requirements for Energy Management",  
draft-ietf-eman-requirements-14 (work in progress),  
May 2013.
- [I-D.ietf-eman-framework]  
Claise, B., Parello, J., Schoening, B., Quittek, J., and  
B. Nordman, "Energy Management Framework",  
draft-ietf-eman-framework-07 (work in progress),  
February 2013.
- [I-D.ietf-eman-energy-monitoring-mib]  
Chandramouli, M., Schoening, B., Quittek, J., Dietz, T.,  
and B. Claise, "Power and Energy Monitoring MIB",  
draft-ietf-eman-energy-monitoring-mib-05 (work in  
progress), April 2013.
- [RFC1628] Case, J., "UPS Management Information Base", RFC 1628,  
May 1994.
- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart,  
"Introduction and Applicability Statements for Internet-  
Standard Management Framework", RFC 3410, December 2002.
- [SBS] "Smart Battery Data Specification", Revision 1.1,  
December 1998.

## Authors' Addresses

Juergen Quittek  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-115  
Email: quittek@neclab.eu



Rolf Winter  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-121  
Email: Rolf.Winter@neclab.eu

Thomas Dietz  
NEC Europe Ltd.  
NEC Laboratories Europe  
Network Research Division  
Kurfuersten-Anlage 36  
Heidelberg 69115  
DE

Phone: +49 6221 4342-128  
Email: Thomas.Dietz@neclab.eu

