

Internet Draft

Avi Berger
PowerDsine Inc.
Dan Romascanu
Avaya Inc.
20 November 2001

Power Ethernet (DTE Power via MDI) MIB

<[draft-ietf-hubmib-power-ethernet-mib-01.txt](#)>

Status of this Memo

This document is an Internet-Draft and is in full conformance with all provisions of [Section 10 of RFC2026](#). Internet-Drafts are working documents of the Internet Engineering Task Force (IETF), its areas, and its working groups. Note that other groups may also distribute working documents as Internet-Drafts.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet- Drafts as reference material or to cite them other than as "work in progress."

To view the list Internet-Draft Shadow Directories, see <http://www.ietf.org/shadow.html>.

Copyright Notice

Copyright (C) The Internet Society (2001). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. The document proposes an extension to the Ethernet-like Interfaces MIB [[RFC2665](#)] with a set of objects for managing a power Ethernet Powered Device (PD) and/or Power Source Equipment (PSE).

Distribution of this memo is unlimited.

Table of Contents

Status of this Memo	1
Abstract	1
1 Introduction	2
2 The SNMP Management Framework	2

INTERNET DRAFT

Power Ethernet MIB

November 2001

3 Overview	3
4 MIB Structure	4
5 Evolution of the Document, Limitations and Future Work	4
6 Changes log	4
7 Definitions	7
8 References	23
9 Intellectual Property	24
10 Security Considerations	25
11 Authors Addresses	25
A Full Copyright Statement	26

1. Introduction

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines a set of MIB objects to manage a Power Ethernet (DTE Power via MDI) Powered Device (PD) and/or power Source Equipment (PSE).

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [[RFC2863](#)].

2. The SNMP Management Framework

The SNMP Management Framework presently consists of five major components:

- o An overall architecture, described in [RFC 2571](#) [[RFC2571](#)].
- o Mechanisms for describing and naming objects and events for the purpose of management. The first version of this Structure of Management Information (SMI) is called SMIV1 and described in STD 16, [RFC 1155](#) [[RFC1155](#)], STD 16, [RFC 1212](#) [[RFC1212](#)] and [RFC 1215](#) [[RFC1215](#)]. The second version, called SMIV2, is described in STD 58, [RFC 2578](#) [[RFC2578](#)], STD 58, [RFC 2579](#) [[RFC2579](#)] and STD 58, [RFC 2580](#) [[RFC2580](#)].
- o Message protocols for transferring management information. The first version of the SNMP message protocol is called SNMPv1 and described in STD 15, [RFC 1157](#) [[RFC1157](#)]. A second version of the SNMP message protocol, which is not an Internet standards track protocol, is called SNMPv2c and described in [RFC 1901](#)

[[RFC1901](#)] and [RFC 1906](#) [[RFC1906](#)]. The third version of the message protocol is called SNMPv3 and described in [RFC 1906](#) [[RFC1906](#)], [RFC 2572](#) [[RFC2572](#)] and [RFC 2574](#) [[RFC2574](#)].

- o Protocol operations for accessing management information. The

first set of protocol operations and associated PDU formats is described in STD 15, [RFC 1157](#) [[RFC1157](#)]. A second set of protocol operations and associated PDU formats is described in [RFC 1905](#) [[RFC1905](#)].

- o A set of fundamental applications described in [RFC 2573](#) [[RFC2573](#)] and the view-based access control mechanism described in [RFC 2575](#) [[RFC2575](#)].

A more detailed introduction to the current SNMP Management Framework can be found in [RFC 2570](#) [[RFC2570](#)].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the mechanisms defined in the SMI.

This memo specifies a MIB module that is compliant to the SMIV2. A MIB conforming to the SMIV1 can be produced through the appropriate translations. The resulting translated MIB must be semantically equivalent, except where objects or events are omitted because no translation is possible (use of Counter64). Some machine readable information in SMIV2 will be converted into textual descriptions in SMIV1 during the translation process. However, this loss of machine readable information is not considered to change the semantics of the MIB.

[3.](#) Overview

The emergence of IP telephony as an application that allows for voice applications to be run over the same infrastructure as data applications led to the emergence of Ethernet IP phones, with similar functions and characteristics as the traditional phones. Powering a phone is one of these functions that are being taken as granted. The IEEE 802.3 Working Group initiated a standard work on this subject, currently known as the IEEE 802.3af work [[IEEE-802.3af](#)].

The IEEE 802.3af WG will not define a full management interface, but only the hardware registers that will allow for a management interfaces to be built for a powered Ethernet device. The MIB module defined in this document extends the Ethernet-like Interfaces MIB [[RFC2665](#)] with the management objects required for the management of the powered Ethernet devices and ports.

The following abbreviations are defined in [[IEEE-802.3af](#)] and will be used with the same significance in this document: PSE - Power Sourcing Equipment; PD - Powered Device

[4.](#) MIB Structure

This MIB objects are included in four MIB groups - three of them include MIB tables, and the fourth scalar objects

The pethPsePortTable defines the objects used for the configuration and describing the status of ports on a PSE device. Examples of PSE devices are Ethernet switches that support power Ethernet and mid-span boxes.

The pethPdPortTable defines the objects used for the configuration and describing the status of ports on a PD device. Examples of PD devices are Ethernet phones.

The pethMainPseObjects MIB group defines the management objects for a managed main power source in a PSE device. Ethernet switches are one example of boxes that would support these objects.

The pethTrapsControlTable includes objects that control the transmission of traps by the agent to a management application.

[5.](#) Evolution of the Document, Limitations and Future Work

The IEEE 802.3af is at this stage work in progress. The scope of this document is to do the standards work in the IETF in parallel with the IEEE standardization activity, in order to allow for the publication of a standard track document containing an SNMP MIB simultaneously or close to the date of the publication of the IEEE revised standard. It is expected that changes may be brought to the IEEE proposal, and

the Ethernet MIB Working Group will work in order to ensure consistency between the two standards proposals.

6. Changes Log

The following changes were introduced relative to the first proposal for a Power Ethernet MIB [[PWR-MIB](#)]

- a. pethPsePortTable has to index pethPsePortGroupIndex & pethPsePortIndex
- b. pethPsePortIndex INTEGER instead of InterfaceIndex
- c. Name change pethPsePortStatus insted of pethPsePortFaultError
- d. Name change pethPsePortStatusClear instead of pethPsePortFaultErrorClear
- e. DESCRIPTION update for pethPsePortPowerDetectionStatus test(3)

- f. DESCRIPTION update pethPsePortDetectionOperStatus off(2)
- g. Adding to pethPsePortStatus one more item both(4)
- h. Adding pethMainPseTable with a pethMainPseGroupIndex
- i. Deletting to objects pethMainPseMaxVoltage & pethMainPseMinVoltage
- j. Change SYNTAX of pethMainPseUsagePower form INTEGER to Gauge32
- k. Change SYNTAX of pethMainPseUsageCurrent form INTEGER to Gauge32
- l. Adding pethMainPseBackupActivated & pethMainPseBackupPresent
- m. Adding Traps Control Objects
- n. Adding Notifications Section (5 notifications)
- o. Adding pethTrapsControlGroup to Conformance Section
- p. Adding pethPsePortPowerClassifications to pethPsePortTable Class 1-5

- q. Adding pethPsePortPowerClassifications to pethPsePortGroup
- r. Change in pethPsePortStatus none(1) to ok(1)
- s. Change in DESCRIPTION of pethMainPseUsagePower from mW to Watt
- t. Change pethMainPseUsagePower to pethMainPseConsumptionPower
- u. Delete of pethMainPseUsageCurrent

The following changes were introduced between [draft-ietf-hubmib-power-ethernet-mib-00.txt](#) and [draft-ietf-hubmib-power-ethernet-mib-01.txt](#):

1. change pethMainPowerUsageTrap to pethMainPowerUsageOnTrap
2. add pethMainPowerUsageOffTrap
3. change pethMainPowerTrapGroup
4. change pethPsePorPowerEnable to pethPsePortAdminEnable
5. pethPsePortPowerIdPairsControl to pethPsePortPowerPairsControlAbility

6. pethPsePortPowerIdPairs to pethPsePortPowerPairs
7. delete both from pethPsePortPowerPairs object
8. change pethPsePortPowerDetectionStatus to pethPsePortPowerDetectionControl
9. delete from pethPsePortPowerDetectionControl off , and change test to 2
10. change pethPsePortDetectionOperStatus to pethPsePortDetectionStatus
11. change pethPsePortDetectionStatus to:
 - disabled(1),

```
    searching(2),
    detected(3),
    deliveringPower(4),
    fault(5),
    invalidPD(6),
    test(7),
    denyLowPriority(8)
```

12. change description for pethPsePortPowerClassifications
13. change pethPsePortStatus to pethPsePortCurrentStatus
14. Update description for pethPsePortCurrentStatus
15. change pethPsePortStatusClear to pethPsePortCurrentStatusClear
16. change pethPdPortDetectionOperStatus to pethPdPortDetectionStatus
17. change in description of pethPdPortPowerPairs
18. change in pethPdPortDetectionStatus description
19. delete pethPdPortPowerClassifications object
20. change in pethPsePortGroup
21. change in pethPdPortGroup
22. change pethPsePortOnOffTrap with pethPsePortDetectionStatus object
23. change pethPsePortStatusTrap to pethPsePortCurrentStatusTrap

24. change pethPsePortTrapGroup

[7.](#) Definitions

```
POWER-ETHERNET-MIB DEFINITIONS ::= BEGIN
```

IMPORTS

MODULE-IDENTITY, OBJECT-TYPE, Integer32 , Gauge32,NOTIFICATION-TYPE
FROM SNMPv2-SMI

dot3

FROM EtherLike-MIB

TruthValue

FROM SNMPv2-TC

MODULE-COMPLIANCE, OBJECT-GROUP ,NOTIFICATION-GROUP
FROM SNMPv2-CONF;

powerEthernetMIB MODULE-IDENTITY

LAST-UPDATED "200111200000Z" -- November 20, 2001

ORGANIZATION "IETF Ethernet Interfaces and Hub MIB
Working Group"

CONTACT-INFO

"

Chair: Dan Romascanu

Avaya Inc.

Tel: +972-3-645-8414

Email: dromasca@avaya.com

Editor: Avi Berger

PowerDsine Inc.

Tel: +972-9-7755100 Ext 307

Fax: +972-9-7755120

E-mail: avib@PowerDsine.com

"

DESCRIPTION

"The MIB module for managing Powered Devices (PD) or
Power Source Equipment (PSE) working according to the IEEE
802.af Power Ethernet (DTE Power via MDI) standard.

The following terms are used throughout this
MIB module. For complete formal definitions,
the IEEE 802.3 standards should be consulted
wherever possible:

defined by the IEEE 802.3 management standard, in order to support a modular numbering scheme. The classical example allows an implementor to represent field-replaceable units as groups of ports, with the port numbering matching the modular hardware implementation.

Port - This entity identifies the port within the group for which this entry contains information. The numbering scheme for ports is implementation specific.

```
::= { dot3 20 }
```

```
pethObjects      OBJECT IDENTIFIER ::= { powerEthernetMIB 1 }
pethNotifications OBJECT IDENTIFIER ::= { powerEthernetMIB 2 }
pethConformance OBJECT IDENTIFIER ::= { powerEthernetMIB 3 }
```

```
-- PSE Objects
```

```
pethPsePortTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PethPsePortEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "A table of objects that display and control the power
        characteristics power Ethernet ports on a Power Source
        Entity (PSE) device. This group will be implemented in
        managed power Ethernet switches and mid-span devices."
    ::= { pethObjects 1 }
```

```
pethPsePortEntry OBJECT-TYPE
    SYNTAX      PethPsePortEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "A set of objects that display and control the power
        characteristics of a power Ethernet PSE port."
    INDEX      { pethPsePortGroupIndex , pethPsePortIndex }
    ::= { pethPsePortTable 1 }
```

```
PethPsePortEntry ::= SEQUENCE {
    pethPsePortGroupIndex
        INTEGER,
    pethPsePortIndex
        INTEGER,
    pethPsePortAdminEnable
```

```
        INTEGER,
    pethPsePortPowerPairsControlAbility
        TruthValue,
    pethPsePortPowerPairs
        INTEGER,
    pethPsePortPowerDetectionControl
        INTEGER,
    pethPsePortDetectionStatus
        INTEGER,
    pethPsePortPowerPriority
        INTEGER,
    pethPsePortCurrentStatus
        INTEGER,
    pethPsePortCurrentStatusClear
        INTEGER,
    pethPsePortType
        INTEGER,
    pethPsePortPowerClassifications
        INTEGER
}

pethPsePortGroupIndex OBJECT-TYPE
    SYNTAX      INTEGER (1..2147483647)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the group
        containing the port to which power Ethernet PSE is connected.
        Group means (box in the stack, module in a rack) and the value 1
        MUST be used for non-modular devices "
    ::= { pethPsePortEntry 1 }

pethPsePortIndex OBJECT-TYPE
    SYNTAX      INTEGER(1..2147483647)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the power Ethernet PSE
        port within group pethPseGroupIndex to which the
        power Ethernet PSE entry is connected."
    ::= { pethPsePortEntry 2 }

pethPsePortAdminEnable OBJECT-TYPE
    SYNTAX      INTEGER {
        enable(1),
```

```
        disable(2)
    }
```

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Enables power supply on this port.

Setting this object at a value enable(1) enables power and detection mechanism for this port.

Setting this object at a value disable(2) disables power for this port."

::= { pethPsePortEntry 3 }

pethPsePortPowerPairsControlAbility OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Describes the capability of controlling the power pairs functionality to switch pins for sourcing power.

The value true indicate that the device has the capability to control the power pairs"

::= { pethPsePortEntry 4 }

pethPsePortPowerPairs OBJECT-TYPE

SYNTAX INTEGER {
 signal(1),
 spare(2)

}

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Describes or controls the pairs in use. If the value of pethPsePortPowerPairsControl is true, this object is writable.

A value of signal(1) means that the signal pairs only are in use.

A value of spare(2) means that the spare pairs only are in use."

::= { pethPsePortEntry 5 }

pethPsePortPowerDetectionControl OBJECT-TYPE

```
SYNTAX INTEGER {
    auto(1),
    test(2)
}
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "Controls the power detection mechanism of the port.
    Setting the value auto(1) enables the power detection
```

```
mechanism of the port.
Setting the value test(2) puts the port in a
testmode: force continuous discovery without applying
power regardless of whether PD detected."
 ::= { pethPsePortEntry 6 }
```

pethPsePortDetectionStatus OBJECT-TYPE

```
SYNTAX INTEGER {
    disabled(1),
    searching(2),
    detected(3),
    deliveringPower(4),
    fault(5),
    invalidPD(6),
    test(7),
    denyLowPriority(8)
}
```

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Describes the operational status of the port PD detection.
A value of disabled(1) indicates that the PD Detection function has been disabled.
A value of searching(2) indicates that the PD Detection function is enabled and is searching for a valid PD.
A value of detected(3) indicates that the PD Detection function has detected a valid PD but the PSE is not supplying power.
A value of deliveringPower(4) indicates that the port executed the detection algorithm, found a PD connection and is currently delivering power.
A value of fault(5) indicates that a fault was detected

on the port , faults detected are vendor-specific.
A value of invalidPD(6) indicates that the PD Detection function has detected a invalid PD.
A value of test(7) indicates that the PD Detection function has been placed in test mode.
A value of denyLowPriority(8) indicates that the port was disabled by the power management system, in order to keep active higher priority ports.
"

::= { pethPsePortEntry 7 }

pethPsePortPowerPriority OBJECT-TYPE
SYNTAX INTEGER {
 critical(1),
 high(2),
 low(3)

}
MAX-ACCESS read-write
STATUS current
DESCRIPTION
 "This object controls the priority of the port from the point of view of a power management algorithm. The priority that is set by this variable could be used by a control mechanism that prevents over current situations by disconnecting first ports with lower power priority. Ports that connect devices critical to the operation of the network - like the E911 telephones ports - should be set to higher priority."

::= { pethPsePortEntry 8 }

pethPsePortCurrentStatus OBJECT-TYPE
SYNTAX INTEGER {
 ok(1),
 underCurrent(2),
 overCurrent(3),
 both(4)

}
MAX-ACCESS read-only
STATUS current
DESCRIPTION

 "Describes a current port status related to the power generation
 The value ok(1) indicates neither an undercurrent or an overcurrent

condition was detected since the attribute was last cleared. The value underCurrent(2) indicates that the port current is below the minimal value since the attribute was last cleared. The value overCurrent(3) indicates that the port current exceeds the maximal value since the attribute was last cleared. The value both(4) indicates that both underCurrent and overCurrent since the attribute was last cleared. This attribute is cleared through the pethPsePortCurrentStatusClear action.

An undercurrent condition is detected when the current drawn from the PSE at the MDI is less than Off-mode current 2 for a duration greater than Under load time limit.

An overcurrent condition is detected when the current drawn from the PSE at the MDI is greater than the overload current limit for a duration greater than Overload time limit.

The values Overload current limit, Overload time limit, Off-mode current 2 and Under load time limit are specified in Table 33-5. If a Clause 22 MII or Clause 35 GMII is present, then this will map to the Under Current and Over Current bits specified in 33.6.1.2.2 and 33.6.1.2.3.;"

REFERENCE "[IEEE DRAFT STANDARD FOR DTE POWER VIA MDI P802.3af/D1.2]"
 ::= { pethPsePortEntry 10 }

 pethPsePortCurrentStatusClear OBJECT-TYPE
SYNTAX INTEGER {
 clear(1),
 off(2)
}

MAX-ACCESS read-write

STATUS current

DESCRIPTION

 "Setting the value of this object to clear(1) clears the value of the pethPsePortStatus and enable the agent to update the pethPsePortStatus.
 Read operation this value will be off(2)."

::= { pethPsePortEntry 11 }

pethPsePortType OBJECT-TYPE

```

SYNTAX INTEGER {
    other(1),
    telephone(2),
    webcam(3),
    wireless(4)
}
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "A manager will set the value of this variable to a value
    that indicates the type of the device that is connected
    to theport. This value can be the result of the mapping
    the address of the station connected to the port and of
    the value of the pethPdPortType of the respective PD port."
 ::= { pethPsePortEntry 12 }

```

pethPsePortPowerClassifications OBJECT-TYPE

```

SYNTAX INTEGER {
    class0(1),
    class1(2),
    class2(3),
    class3(4),
    class4(5),
    class5(6)
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "Classification is a way to tag different terminals on the
    Power over LAN network according to their power consumption.

```

Devices such as IP telephones, WLAN access points and others, will be classified according to their power requirements. A read-only value that indicates the PD Class of a detected PD as specified in IEEE Draft P802.3af/D2.1 Supplement to IEEE Std.802.3 November 14 2001 cclause 33.2.5 and 33.2.6.

The value is only valid while a valid PD is being detected as indicated by the attribute pethPsePortDetectionStatus reporting the enumeration (detected) or (deliveringPower).

```

"
 ::= { pethPsePortEntry 13 }

```

-- PD Port table

pethPdPortTable OBJECT-TYPE

SYNTAX SEQUENCE OF PethPdPortEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table of objects that display and control the power characteristics power Ethernet ports on a Powered Device(PD) device. This group will be implemented in managed powered and mid-span devices."

::= { pethObjects 2 }

pethPdPortEntry OBJECT-TYPE

SYNTAX PethPdPortEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A set of objects that display and control the power characteristics of a Powered Device port."

INDEX { pethPdPortIndex }

::= { pethPdPortTable 1 }

PethPdPortEntry ::= SEQUENCE {

pethPdPortIndex

INTEGER,

pethPdPortPowerPairs

INTEGER,

pethPdPortDetectionStatus

INTEGER,

pethPdPortType

INTEGER

}

pethPdPortIndex OBJECT-TYPE

SYNTAX INTEGER (0..65535)

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An index value that uniquely identifies an

interface to a PD device. The interface identified by a particular value of this index is the same interface as identified by the same value of ifIndex. The mapping between the ifIndex values and the numbering of the port on the device is an implementation issue."

::= { pethPdPortEntry 1 }

pethPdPortPowerPairs OBJECT-TYPE

SYNTAX INTEGER {
 signal(1),
 spare(2),
 both(3)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Describes the pairs in use by the PD to derive power.

A value of signal(1) indicates that only PD Pinout Mode A is supported by the PD.

A value of spare(2) indicates that only PD Pinout Mode B is supported by the PD.

A value of both(3) means indicates that both PD Pinout Mode A and Pinout Mode B are supported by the PD."

::= { pethPdPortEntry 2 }

pethPdPortDetectionStatus OBJECT-TYPE

SYNTAX INTEGER {
 off(1),
 receivingPower(2)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Describes the operational status of the port detection.

The value off(1) indicates that the PD is drawing a current less than I

Port as specified in IEEE Draft P802.3af/D2.1 Supplement to IEEE Std.802.3 November 14 2001 Table 33-10.

The value receivingPower(2) indicates that the PD is drawing a current greater I Port as specified in

IEEE Draft P802.3af/D2.1 Supplement to IEEE Std.802.3 November 14 2001 Table 33-10.

"

::= { pethPdPortEntry 3 }

pethPdPortType OBJECT-TYPE

```
SYNTAX INTEGER {
    other(1),
    telephone(2),
    webcam(3),
    wireless(4)
}
```

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The type of the device. A management application may read the value of this variable and use it for setting the corresponding value of pethPsePortType of the port that connects the device."

::= { pethPdPortEntry 4 }

-- Main PSE Objects

pethMainPseObjects OBJECT IDENTIFIER ::= { pethObjects 3 }

pethMainPseTable OBJECT-TYPE

SYNTAX SEQUENCE OF PethMainPseEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table of objects that display and control the Main power on a PSE device. Example internet switch midspan device can control an Internet port and the Main Power supply unit's."

::= { pethMainPseObjects 1 }

pethMainPseEntry OBJECT-TYPE

SYNTAX PethMainPseEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A set of objects that display and control the Main power of a PSE. "

INDEX { pethMainPseGroupIndex }

::= { pethMainPseTable 1 }

PethMainPseEntry ::= SEQUENCE {

pethMainPseGroupIndex

INTEGER,

```

        Integer32,
    pethMainPseOperStatus
        INTEGER,
    pethMainPseConsumptionPower
        Gauge32,
    pethMainPseBackupPresent
        INTEGER,
    pethMainPseBackupActivated
        TruthValue,
    pethMainPseUsageThreshold
        INTEGER,
    pethMainPseMaximumDcPower
        INTEGER
}
pethMainPseGroupIndex OBJECT-TYPE
    SYNTAX      INTEGER (0..65535)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the group to which
        power Ethernet PSE is connected. Group means (box in the stack,
        module in a rack) and the value 1 MUST be used for non-modular
        devices "
    ::= { pethMainPseEntry 1 }

pethMainPsePower OBJECT-TYPE
    SYNTAX      Integer32 (0..65535)
    UNITS       "Watts"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The nominal power of the PSE expressed in Watts."
    ::= { pethMainPseEntry 2 }

pethMainPseOperStatus OBJECT-TYPE
    SYNTAX      INTEGER {
        on(1),
        off(2),
        faulty(3)
    }

```

```
    }
    MAX-ACCESS    read-only
    STATUS        current
    DESCRIPTION
        "The operational status of the main PSE."
    ::= { pethMainPseEntry 3 }
```

pethMainPseConsumptionPower OBJECT-TYPE

```
    SYNTAX        Gauge32
    UNITS         "Watts"
    MAX-ACCESS    read-only
    STATUS        current
    DESCRIPTION
        "Measured usage power expressed in Watts."
    ::= { pethMainPseEntry 4 }
```

pethMainPseBackupPresent OBJECT-TYPE

```
    SYNTAX    INTEGER {
        present(1),
        notPresent(2),
        faulty(3)
    }
    MAX-ACCESS    read-only
    STATUS        current
    DESCRIPTION
        "reflects the presence of a backup PSE ."
    ::= { pethMainPseEntry 5 }
```

pethMainPseBackupActivated OBJECT-TYPE

```
    SYNTAX        TruthValue
    MAX-ACCESS    read-only
    STATUS        current
    DESCRIPTION
        "Reflects the activation status of the backup PSE .
         The value true Backup is activated."
    ::= { pethMainPseEntry 6 }
```

pethMainPseUsageThreshold OBJECT-TYPE

```
    SYNTAX    INTEGER (1..99)
    UNITS     "%"
```

```
MAX-ACCESS    read-write
STATUS        current
DESCRIPTION
    "The usage threshold expressed in percens for
    comparing the measured power and initiating
    an alarm if the threshold is exceeded."
 ::= { pethMainPseEntry 7 }
```

```
pethMainPseMaximumDcPower OBJECT-TYPE
SYNTAX        INTEGER
UNITS         "Watts"
MAX-ACCESS    read-write
STATUS        current
DESCRIPTION
    "Describes the maximum available power in
```

```
    Watt to be supplied by the DC backup source to this
    device."
 ::= { pethMainPseEntry 8 }
```

-- Traps Control Objects

```
pethTrapsControl          OBJECT IDENTIFIER ::= { pethObjects 4 }
```

```
pethTrapsControlTable OBJECT-TYPE
SYNTAX        SEQUENCE OF PethTrapsControlEntry
MAX-ACCESS    not-accessible
STATUS        current
DESCRIPTION
    "A table of objects that display and control the Traps
    on a PSE device."
 ::= { pethTrapsControl 1 }
```

```
pethTrapsControlEntry OBJECT-TYPE
SYNTAX        PethTrapsControlEntry
MAX-ACCESS    not-accessible
STATUS        current
DESCRIPTION
    "A set of objects that control the Trap events."
INDEX        { pethTrapsControlGroupIndex }
 ::= { pethTrapsControlTable 1 }
```

```

PethTrapsControlEntry ::= SEQUENCE {
    pethTrapsControlGroupIndex
        INTEGER,
    pethTrapsControlEnable
        INTEGER
}
pethTrapsControlGroupIndex OBJECT-TYPE
    SYNTAX      INTEGER (0..65535)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the group. Group means
        box in the stack, module in a rack and it is recommended
        that the value 1 MUST be used for non-modular devices "
    ::= { pethTrapsControlEntry 1 }

```

```

pethTrapsControlEnable OBJECT-TYPE
    SYNTAX      INTEGER
    {
        enable(1),

```

```

        disable(2)
    }
    MAX-ACCESS      read-write
    STATUS          current
    DESCRIPTION
        "Enable Traps from Agent"
    ::= { pethTrapsControlEntry 2 }

```

```

--
-- Notifications Section
--
--

```

```

pethPsePortOnOffTrap NOTIFICATION-TYPE
    OBJECTS      { pethPsePortGroupIndex,pethPsePortIndex,pethPsePortDet
    STATUS      current
    DESCRIPTION " This trap indicate if Pse Port is delivering or not
    ::= { pethNotifications 1 }

```

pethPsePortCurrentStatusTrap NOTIFICATION-TYPE
OBJECTS { pethPsePortGroupIndex,pethPsePortIndex,pethPsePortCur
STATUS current
DESCRIPTION
"This trap indicate Port Change Status and it will be
sent on every status change."
 ::= { pethNotifications 2 }

pethMainPseBackUpActivatedTrap NOTIFICATION-TYPE
OBJECTS { pethPsePortGroupIndex,pethMainPseBackupActivated }
STATUS current
DESCRIPTION
"This trap indicate BackUp is Activated or BackUp
is released."
 ::= { pethNotifications 3 }

pethMainPowerUsageOnTrap NOTIFICATION-TYPE
OBJECTS { pethPsePortGroupIndex }
STATUS current
DESCRIPTION
"This trap indicate PSE Threshold usage indication is on ,
the useage power is above the treshold."
 ::= { pethNotifications 4 }

pethMainPowerUsageOffTrap NOTIFICATION-TYPE
OBJECTS { pethPsePortGroupIndex }

STATUS current
DESCRIPTION
"This trap indicate PSE Threshold usage indication off ,
the useage power is below the treshold.."
 ::= { pethNotifications 5 }
pethPsePortTrapGroup NOTIFICATION-GROUP
NOTIFICATIONS { pethPsePortOnOffTrap, pethPsePortCurrentStatusTrap
STATUS current
DESCRIPTION
"Pse trap indications"
 ::= { pethNotifications 6 }

```

pethMainPowerTrapGroup NOTIFICATION-GROUP
    NOTIFICATIONS { pethMainPseBackUpActivatedTrap, pethMainPowerUsag
    STATUS        current
    DESCRIPTION   "Pse trap indications"
    ::= { pethNotifications 7 }

--
-- Conformance Section
--
pethCompliances OBJECT IDENTIFIER ::= { pethConformance 1 }
pethGroups      OBJECT IDENTIFIER ::= { pethConformance 2 }

pethCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to the
        Power Ethernet MIB."
    MODULE -- this module
        GROUP pethPsePortGroup
        DESCRIPTION
            "The pethPsePortGroup is mandatory for systems which
            implement PSE ports."
        GROUP pethPdPortGroup
        DESCRIPTION
            "The pethPdPortGroup is mandatory for systems which
            implement PD Ports."
        GROUP pethMainPseGroup
        DESCRIPTION
            "The pethMainPseGroup is mandatory for systems which
            implement main power supply within a PSE Device."
        GROUP pethTrapsControlGroup
        DESCRIPTION
            "The pethTrapsControlGroup is mandatory for systems which
            implement PSE ports."

```

```

::= { pethCompliances 1 }

```

```

pethPseCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION

```



```

        "Describes the requirements for conformance to the PSE and MidSp
MODULE -- this module
MANDATORY-GROUPS {pethPsePortGroup, pethMainPseGroup,pethTrapsControlGro
 ::= { pethCompliances 2 }

pethPdCompliance MODULE-COMPLIANCE
STATUS current
DESCRIPTION
    "Describes the requirements for conformance to the PSE
    and MidSpan."
MODULE -- this module
MANDATORY-GROUPS {pethPdPortGroup}
 ::= { pethCompliances 3 }

pethPsePortGroup OBJECT-GROUP
OBJECTS {
    pethPsePortGroupIndex,
    pethPsePortIndex,
    pethPsePortAdminEnable,
    pethPsePortPowerPairsControlAbility,
    pethPsePortPowerPairs,
    pethPsePortDetectionStatus,
    pethPsePortPowerPriority,
    pethPsePortCurrentStatus,
    pethPsePortCurrentStatusClear,
    pethPsePortType,
    pethPsePortPowerClassifications
}
STATUS current
DESCRIPTION
    "PSE Port Objects."
 ::= { pethGroups 1 }

pethPdPortGroup OBJECT-GROUP
OBJECTS {
    pethPdPortPowerPairs,
    pethPdPortDetectionStatus,
    pethPdPortType
}
STATUS current
DESCRIPTION
    "PD Port Objects."
 ::= { pethGroups 2 }

```

```

pethMainPseGroup OBJECT-GROUP
  OBJECTS {
    pethMainPsePower,
    pethMainPseOperStatus,
    pethMainPseConsumptionPower,
    pethMainPseBackupPresent,
    pethMainPseBackupActivated,
    pethMainPseUsageThreshold,
    pethMainPseMaximumDcPower
  }
  STATUS current
  DESCRIPTION
    "Main PSE Objects. "
  ::= { pethGroups 3 }

pethTrapsControlGroup OBJECT-GROUP
  OBJECTS {
    pethTrapsControlEnable
  }
  STATUS current
  DESCRIPTION
    "Trap Control Objects. "
  ::= { pethGroups 4 }
END

```

8. References

- [RFC2571] Harrington, D., Presuhn, R., and B. Wijnen, "An Architecture for Describing SNMP Management Frameworks", [RFC 2571](#), April 1999.
- [RFC1155] Rose, M., and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based Internets", STD 16, [RFC 1155](#), May 1990.
- [RFC1212] Rose, M., and K. McCloghrie, "Concise MIB Definitions", STD 16, [RFC 1212](#), March 1991.
- [RFC1215] M. Rose, "A Convention for Defining Traps for use with the SNMP", [RFC 1215](#), March 1991.
- [RFC2578] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M., and S. Waldbusser, "Structure of Management Information Version 2 (SMIv2)", STD 58, [RFC 2578](#), April 1999.

INTERNET DRAFT

Power Ethernet MIB

November 2001

- [RFC2579] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M., and S. Waldbusser, "Textual Conventions for SMIV2", STD 58, [RFC 2579](#), April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M., and S. Waldbusser, "Conformance Statements for SMIV2", STD 58, [RFC 2580](#), April 1999.
- [RFC1157] Case, J., Fedor, M., Schoffstall, M., and J. Davin, "Simple Network Management Protocol", STD 15, [RFC 1157](#), May 1990.
- [RFC1901] Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Introduction to Community-based SNMPv2", [RFC 1901](#), January 1996.
- [RFC1906] Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)", [RFC 1906](#), January 1996.
- [RFC2572] Case, J., Harrington D., Presuhn R., and B. Wijnen, "Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)", [RFC 2572](#), April 1999.
- [RFC2574] Blumenthal, U., and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", [RFC 2574](#), April 1999.
- [RFC1905] Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)", [RFC 1905](#), January 1996.
- [RFC2573] Levi, D., Meyer, P., and B. Stewart, "SNMPv3 Applications", [RFC 2573](#), April 1999.
- [RFC2575] Wijnen, B., Presuhn, R., and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", [RFC 2575](#), April 1999.
- [RFC2570] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction to Version 3 of the Internet-standard Network Management Framework", [RFC 2570](#), April 1999.

- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", [BCP 14](#), [RFC 2119](#), March 1997.
- [RFC2665] Flick, J., and J. Johnson, "Definitions of Managed Objects for the Ethernet-like Interface Types", [RFC 2665](#), August 1999.

- [IEEE-802.3af] IEEE 802.3af Working Group, "Data Terminal Equipment (DTE) Power via Media Dependent Interface (MDI)", Draft D2.1, November 2001.
- [PWR-MIB] Romascanu, D., " Power Ethernet (DTE Power via MDI) MIB", Internet-Draft, [draft-romascanu-hubmib-power-ethernet-mib-00.txt](#), February 2001.

9. Intellectual Property

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in [BCP-11](#). Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

[10.](#) Security Considerations

There are a number of management objects defined in this MIB that have a MAX-ACCESS clause of read-write and/or read-create.

Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

There are a number of managed objects in this MIB that may contain sensitive information. These are:

It is thus important to control even GET access to these objects and possibly to even encrypt the values of these object when sending them over the network via SNMP. Not all versions of SNMP provide features for such a secure environment.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is RECOMMENDED that the implementers consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model [[RFC2274](#)] and the View-based Access Control Model [[RFC2275](#)] is RECOMMENDED.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

11. Authors Addresses

Avi Berger
PowerDsine Inc.
1, Hanagar St., P.O. Box 7220
Hod Hasharon 45421,
Israel
Tel: +972-9-7755100 Ext 307
Fax: +972-9-7755120
E-mail: avib@PowerDsine.com

Dan Romascanu
Avaya Inc.
Atidim Technology Park, Bldg. #3
Tel Aviv, 61131
Israel
Tel: +972-3-645-8414
Email: dromasca@avaya.com

A. Full Copyright Statement

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other

Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

