

Networking Working Group
Internet-Draft
Intended status: Informational
Expires: September 12, 2013

JP. Vasseur
Cisco Systems, Inc
March 11, 2013

Terminology in Low power And Lossy Networks
draft-ietf-roll-terminology-12.txt

Abstract

The documents defines a terminology for discussing routing requirements and solutions for networks referred to as Low power and Lossy Networks (LLN). An LLN is typically composed of many embedded devices with limited power, memory, and processing resources interconnected by a variety of links. There is a wide scope of application areas for LLNs, including industrial monitoring, building automation (e.g. Heating, Ventilating, Air Conditioning, lighting, access control, fire), connected home, healthcare, environmental monitoring, urban sensor networks, energy management, assets tracking, refrigeration.

Status of This Memo

This Internet-Draft is submitted to IETF in full conformance with the provisions of [BCP 78](#) and [BCP 79](#).

Internet-Drafts are working documents of the Internet Engineering Task Force (IETF). Note that other groups may also distribute working documents as Internet-Drafts. The list of current Internet-Drafts is at <http://datatracker.ietf.org/drafts/current/>.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet-Drafts as reference material or to cite them other than as "work in progress."

This Internet-Draft will expire on September 12, 2013.

Copyright Notice

Copyright (c) 2013 IETF Trust and the persons identified as the document authors. All rights reserved.

This document is subject to [BCP 78](#) and the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>) in effect on the date of publication of this document. Please review these documents carefully, as they describe your rights and restrictions with respect to this document. Code Components extracted from this document must include Simplified BSD License text as described in Section 4.e of the [Trust Legal Provisions](#) and are provided without warranty as described in the Simplified BSD License.

Table of Contents

1.	Introduction	2
2.	Terminology	3
3.	IANA Considerations	6
4.	Security Considerations	7
5.	Acknowledgements	7
6.	References	7
6.1.	Normative References	7
6.2.	Informative References	7
	Author's Address	7

[1.](#) Introduction

This document defines a terminology for discussing routing requirements and solutions for networks referred to as Low power and Lossy Networks (LLN).

Low power and Lossy networks (LLNs) are typically composed of many embedded devices with limited power, memory, and processing resources interconnected by a variety of links, such as IEEE 802.15.4, Low Power WiFi. There is a wide scope of application areas for LLNs, including industrial monitoring, building automation (HVAC, lighting, access control, fire), connected home, healthcare, environmental monitoring, urban sensor networks, energy management, assets tracking and refrigeration.

Since these applications are usually highly specific (for example Industrial Automation, Building Automation, ...), it is not uncommon to see a number of disparate terms to describe the same device or functionality. Thus in order to avoid confusion or discrepancies, this document specifies the common terminology to be used in all ROLL Working Group documents. The terms defined in this document are used in [[RFC5548](#)], [[RFC5673](#)], [[RFC5826](#)] and [[RFC5867](#)].

Terminology specific to a particular application are out of the scope of this document.

Vasseur

Expires September 12, 2013

[Page 2]

Internet-Draft

[draft-ietf-roll-terminology-12.txt](#)

March 2013

It is expected that all routing requirements documents defining requirements or specifying routing solutions for LLN will use the common terminology specified in this document. This document should be listed as an informative reference.

[2.](#) Terminology

Actuator: a field device that controls a set of equipment. For example, an actuator might control and/or modulate the flow of a gas or liquid, control electricity distribution, perform a mechanical operation, ...

AMI: Advanced Metering Infrastructure that makes use of Smart Grid technologies. A canonical Smart Grid application is smart-metering.

Channel: Radio frequency sub-band used to transmit a modulated signal carrying packets.

Channel Hopping: A procedure by which field devices synchronously change channels during operation.

Commissioning Tool: Any physical or logical device temporarily added to the network for the express purpose of setting up the network and device operational parameters. The commissioning tool can also be temporarily added to the LLN for scheduled or unscheduled maintenance.

Closed Loop Control: A procedure whereby a device controller controls an actuator based on input information sensed by one or more field devices.

Controller: A field device that can receive sensor input and automatically change the environment in the facility by manipulating digital or analog actuators.

DA: Distribution Automation, part of Smart Grid. Encompasses technologies for maintenance and management of electrical

distribution systems.

Directed Acyclic Graph: A directed graph with no directed cycles (a graph formed by a collection of vertices and directed edges where each edge connects one vertex to another, such that there is no way to start at some vertex *v* and follow a sequence of edges that eventually loops back to the edge *v* again)

Data sink: A device that collects data from nodes in an LLN.

Downstream: Data direction traveling from outside of the LLN (e.g. traffic coming from a LAN, WAN or the Internet) via a LBR, or in general "deeper" in the Directed Acyclic Graph computed by the routing protocol.

Field Device: A field device is a physical device placed in the network's operating environment (e.g. plant, urban or home). Field devices include sensors, actuators as well as routers and Low power and Lossy Network Border Router (LBR). A field device is usually (but not always) a device with constrained CPU, memory footprint, storage capacity, bandwidth and sometimes power (battery operated). At the time of writing, for the sake of illustration, a typical sensor or actuator would have a few KBytes of RAM, a few dozens of KBytes of ROM/Flash memory, a 8/16/32 bit microcontroller and communication capabilities ranging from a few Kbits/s to a few hundreds of Kbits/s. Although it is expected to see continuous improvements of hardware and software technologies, such devices will likely continue to be seen as resource constrained devices compared to computers and routers used in the rest of the Internet.

Flash memory: non-volatile memory that can be re-programmed.

FMS: Facility Management System. A global term applied across all the vertical designations within a building including, Heating, Ventilating, and Air Conditioning also referred to as HVAC, Fire, Security, Lighting and Elevator control.

HART: "Highway Addressable Remote Transducer", a group of specifications for industrial process and control devices administered by the HART Foundation (see [\[HART\]](#)). The latest version

for the specifications is HART7 which includes the additions for WirelessHART.

HVAC: Heating, Ventilation and Air Conditioning. A term applied to the comfort level of an internal space.

ISA: "International Society of Automation". ISA is an ANSI accredited standards-making society. ISA100 is an ISA committee whose charter includes defining a family of standards for industrial automation. [ISA100.11a] is a working group within ISA100 that is working on a standard for monitoring and non-critical process control applications.

LAN: Local Area Network.

LBR: Low power and Lossy Network Border Router. The LBR is a device that connects the Low power and Lossy Network to another routing domain such as a Local Area Network (LAN), Wide Area Network (WAN) or

the Internet where a possibly different routing protocol is in operation. The LBR acts as a routing device and may possibly host other functions such as data collector or aggregator.

LLN: Low power and Lossy networks (LLNs) are typically composed of many embedded devices with limited power, memory, and processing resources interconnected by a variety of links, such as IEEE 802.15.4 or Low Power WiFi. There is a wide scope of application areas for LLNs, including industrial monitoring, building automation (HVAC, lighting, access control, fire), connected home, healthcare, environmental monitoring, urban sensor networks, energy management, assets tracking and refrigeration..

MP2P: Multipoint-to-Point is used to describe a particular traffic pattern (e.g. MP2P flows collecting information from many nodes flowing upstream towards a collecting sink or an LBR).

MAC: Medium Access Control. Refers to algorithms and procedures used by the data link layer to coordinate use of the physical layer.

Non-sleepy Node: A non-sleepy node is a node that always remains in a fully powered on state (i.e. always awake) where it has the capability to perform communication.

Open Loop Control: A process whereby a plant operator manually manipulates an actuator over the network where the decision is influenced by information sensed by field devices.

PER: Packet Error Rate. A ratio of the number of unusable packets (not received at all, or received in error- even after any applicable error correction has been applied) to the total number of packets that would have been received in the absence of errors.

P2P: Point To Point. This refers to traffic exchanged between two nodes (regardless of the number of hops between the two nodes).

P2MP: Point-to-Multipoint traffic refers to traffic between one node and a set of nodes. This is similar to the P2MP concept in Multicast or MPLS Traffic Engineering ([[RFC4461](#)] and [[RFC4875](#)]). A common RPL use case involves P2MP flows from or through a DAG root outward towards other nodes contained in the DAG.

RAM: Random Access Memory. The RAM is a volatile memory.

RFID: Radio Frequency IDentification.

ROM: Read Only Memory.

ROLL: Routing Over Low power and Lossy networks.

RPL: An IPv6 Routing Protocol for Low-Power and Lossy Networks that provides a mechanism whereby multipoint-to-point traffic from devices inside the LLN towards a central control point as well as point-to-multipoint traffic from the central control point to the devices inside the LLN are supported. RPL also support point-to-point traffic between any arbitrary node in the LLN.

RPL Domain: A RPL routing domain is a collection of RPL routers under the control of a single administration. The boundaries of routing domains are defined by network management by setting some links to be exterior, or inter-domain, links.

Schedule: An agreed execution, wake-up, transmission, reception, etc., time-table between two or more field devices.

Sensor: A sensor is a device that measures a physical quantity and converts it to an analog or digital signal that can be read by a program or a user. Sensed data can be of many types: electromagnetic (e.g. current, voltage, power, resistance, ...) , mechanical (e.g. pressure, flow, liquid density, humidity, ...), chemical (e.g. oxygen, carbon monoxide, ...), acoustic (e.g. noise, ultrasound), ...

Sleepy Node: A sleepy node is a node that may sometimes go into a sleep mode (i.e. go into a low power state to conserve power) and temporarily suspend protocol communication. When not in a sleep mode, the sleepy node is in a fully powered on state where it has the capability to perform communication.

Smart Grid: A Smart Grid is a broad class of applications to network and automate utility infrastructure.

Timeslot: A Timeslot is a fixed time interval that may be used for the transmission or reception of a packet between two field devices. A timeslot used for communications is associated with a slotted-link

Upstream: Data direction traveling from the LLN via the LBR to outside of the LLN (LAN, WAN, Internet) or general closer to the root of the Directed Acyclic Graph computed by the routing protocol.

WAN: Wide Area Network.

[3.](#) IANA Considerations

This document includes no request for IANA action.

Vasseur

Expires September 12, 2013

[Page 6]

Internet-Draft

[draft-ietf-roll-terminology-12.txt](#)

March 2013

[4.](#) Security Considerations

Since this document specifies terminology and does not specify new procedure or protocols, it raises no new security issue.

[5.](#) Acknowledgements

The authors would like to thank Christian Jacquenet, Tim Winter, Pieter De Mil, David Meyer, Mukul Goyal and Abdussalam Baryun for

their valuable feed-back.

6. References

6.1. Informative References

- [HART] HART Communication Foundation (<http://www.hartcomm.org>)
- [RFC4461] Yasukawa, S., "Signaling Requirements for Point-to-Multipoint Traffic-Engineered MPLS Label Switched Paths (LSPs)", [RFC 4461](#), April 2006.
- [RFC4875] Aggarwal, R., Papadimitriou, D., and S. Yasukawa, "Extensions to Resource Reservation Protocol - Traffic Engineering (RSVP-TE) for Point-to-Multipoint TE Label Switched Paths (LSPs)", [RFC 4875](#), May 2007.
- [RFC5548] Dohler, M., Watteyne, T., Winter, T., and D. Barthel, "Routing Requirements for Urban Low-Power and Lossy Networks", [RFC 5548](#), May 2009.
- [RFC5673] Pister, K., Thubert, P., Dwars, S., and T. Phinney, "Industrial Routing Requirements in Low-Power and Lossy Networks", [RFC 5673](#), October 2009.
- [RFC5826] Brandt, A., Buron, J., and G. Porcu, "Home Automation Routing Requirements in Low-Power and Lossy Networks", [RFC 5826](#), April 2010.
- [RFC5867] Martocci, J., De Mil, P., Riou, N., and W. Vermeylen, "Building Automation Routing Requirements in Low-Power and Lossy Networks", [RFC 5867](#), June 2010.

Author's Address

Vasseur

Expires September 12, 2013

[Page 7]

Internet-Draft

[draft-ietf-roll-terminology-12.txt](#)

March 2013

JP Vasseur
Cisco Systems, Inc
1414 Massachusetts Avenue
Boxborough, MA 01719
USA

Email: jpv@cisco.com