

TRILL Working Group
Internet-Draft
Intended status: Proposed Standard
Expires: June 6, 2013

A. Rijhsinghani
Hewlett-Packard
K. Zebrose
HW Embedded
December 3, 2012

Definitions of Managed Objects for RBridges (Routing Bridges)
draft-ietf-trill-rbridge-mib-10.txt

Status of This Document

This Internet-Draft is submitted to IETF in full conformance with the provisions of [BCP 78](#) and [BCP 79](#).

This document is intended to become a Proposed Standard. Distribution of this document is unlimited. Comments should be sent to the author.

Internet-Drafts are working documents of the Internet Engineering Task Force (IETF), its areas, and its working groups. Note that other groups may also distribute working documents as Internet-Drafts.

Internet-Drafts are draft documents valid for a maximum of six months and may be updated, replaced, or obsoleted by other documents at any time. It is inappropriate to use Internet-Drafts as reference material or to cite them other than as "work in progress."

The list of current Internet-Drafts can be accessed at <http://www.ietf.org/1id-abstracts.html>

The list of Internet-Draft Shadow Directories can be accessed at <http://www.ietf.org/shadow.html>

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols. In particular it defines objects for managing an RBridge (Routing Bridge), also known as a TRILL Switch, based on the IETF TRILL (Transparent Interconnection of Lots of Links) protocol.

Table of Contents

| | | |
|----------------------|--|--------------------|
| 1. | Introduction | 3 |
| 2. | The Internet-Standard Management Framework | 3 |
| 3. | Overview | 3 |
| 4. | Conventions | 4 |
| 5. | Structure of the MIB Module | 4 |
| 5.1 | Textual Conventions | 4 |
| 5.2 | The rbridgeBase Subtree | 4 |
| 5.3 | The rbridgeFdb Subtree | 4 |
| 5.4 | The rbridgeVlan subtree | 4 |
| 5.5 | The rbridgeEsadi subtree | 5 |
| 5.6 | The rbridgeCounters subtree | 5 |
| 5.7 | The rbridgeSnooping subtree | 5 |
| 5.8 | The rbridgeDtree subtree | 5 |
| 5.9 | The rbridgeTrill subtree | 5 |
| 5.10 | The Notifications Subtree | 5 |
| 6. | Relationship to Other MIB Modules | 5 |
| 6.1 | Relationship to IF-MIB | 6 |
| 6.2 | Relationship to BRIDGE-MIB | 6 |
| 6.3 | Relationship to P-BRIDGE-MIB | 6 |
| 6.4 | Relationship to Q-BRIDGE-MIB | 6 |
| 6.5 | Relationship to IEEE8021-BRIDGE-MIB | 7 |
| 6.7 | Relationship to ISIS-MIB | 7 |
| 6.8 | MIB modules required for IMPORTS | 8 |
| 7. | Definition of the RBridge MIB module | 8 |
| 8. | Security Considerations | 52 |
| 9. | IANA Considerations | 54 |
| 10. | Contributors | 54 |
| 11. | References | 54 |
| 11.1 | Normative References | 54 |
| 11.2 | Informative References | 55 |
| | Authors' Addresses | 56 |
| | Copyright and License Notice | 56 |

1. Introduction

This document describes a model for managing RBridges (Routing Bridges), also known as TRILL Switches, as defined in [\[RFC6325\]](#). RBridges provide optimal pair-wise forwarding without configuration using IS-IS routing and encapsulation of traffic. RBridges are compatible with previous IEEE 802.1 customer bridges as well as IPv4 and IPv6 routers and end nodes. They are as invisible to current IP routers as bridges are and, like routers, they terminate the bridge spanning tree protocol. In creating an RBridge management model the device is viewed primarily as a customer bridge. For a discussion of the problem addressed by TRILL (Transparent Interconnection of Lots of Links) see [\[RFC5556\]](#).

RBridges support features specified for transparent bridges in IEEE 802.1, and the corresponding MIB modules are used to manage those features. For IS-IS purposes, the corresponding MIB module is used to manage the protocol. This MIB module specifies those objects which are TRILL-specific and hence not available in other MIB modules.

2. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to [section 7 of RFC 3410](#) [\[RFC3410\]](#).

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIV2, which is described in STD 58, which consists of [\[RFC2578\]](#), [\[RFC2579\]](#) and [\[RFC2580\]](#).

3. Overview

The RBridge MIB module is intended as an overall framework for managing RBridges, also known as TRILL Switches. Where possible the MIB references existing MIB definitions in order to maximize reuse. This results in a considerable emphasis on the relationship with other MIB modules.

Starting with the physical interfaces, there are requirements for certain elements of the IF-MIB to be implemented. These elements are required in order to connect the per-port parameters to higher level functions of the physical device.

Transparent bridging, VLANs, Traffic classes and Multicast Filtering

are supported by the TRILL protocol, and the corresponding management is expected to conform to the BRIDGE-MIB [[RFC4188](#)], P-BRIDGE-MIB and Q-BRIDGE-MIB [[RFC4363](#)] modules.

The IS-IS routing protocol is used in order to determine the optimum pair-wise forwarding path. This protocol is managed using the IS-IS MIB module defined in [[RFC4444](#)]. Since the TRILL protocol specifies use of a single level and a fixed area address of zero, some IS-IS MIB objects are not applicable. Some IS-IS MIB objects are used in the TRILL protocol.

[4. Conventions](#)

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "NOT RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC 2119](#) [[RFC2119](#)].

[5. Structure of the MIB Module](#)

Objects in this MIB module are arranged into subtrees. Each subtree is organized as a set of related objects. The various subtrees are shown below. These are supplemented with required elements of the IF-MIB, ISIS-MIB, BRIDGE-MIB, P-BRIDGE-MIB, Q-BRIDGE-MIB and IEEE Bridge MIB modules.

[5.1 Textual Conventions](#)

Textual conventions are defined to represent object types relevant to TRILL.

[5.2 The rbridgeBase Subtree](#)

This subtree contains system and port specific objects applicable to all RBridges.

[5.3 The rbridgeFdb Subtree](#)

This subtree contains objects applicable to the Forwarding database used by the RBridge in making packet forwarding decisions. Because it contains additional information used by the TRILL protocol not applicable to 802.1D/Q bridges, it is a superset of the corresponding subtrees defined in the BRIDGE-MIB and Q-BRIDGE-MIB.

[5.4 The rbridgeVlan subtree](#)

This subtree describes objects applicable to VLANs configured on the RBridge.

5.5 The rbridgeEsadi subtree

This subtree describes objects relevant to RBridges that support the optional ESADI protocol.

5.6 The rbridgeCounters subtree

This subtree contains statistics maintained by RBridges that can aid in monitoring and troubleshooting networks connected by them.

5.7 The rbridgeSnooping subtree

This subtree describes objects applicable to RBridges capable of snooping IPv4 and/or IPv6 Multicast control frames and pruning IP multicast traffic based on detection of IP multicast routers and listeners.

5.8 The rbridgeDtree subtree

This subtree contains objects relevant to Distribution Trees computed by RBridges for the forwarding of multi-destination frames.

5.9 The rbridgeTrill subtree

This subtree contains objects applicable to the TRILL IS-IS protocol, beyond what is available in ISIS-MIB.

5.10 The Notifications Subtree

The defined notifications are focused on the TRILL protocol functionality. Notifications are defined for changes in the Designated RBridge status and the topology.

6. Relationship to Other MIB Modules

The IF-MIB, BRIDGE-MIB, P-BRIDGE-MIB, Q-BRIDGE-MIB, IEEE8021-BRIDGE-MIB, IEEE8021-Q-BRIDGE-MIB and ISIS-MIB modules all contain objects relevant to the RBridge MIB. Management objects contained in these modules are not duplicated here, to reduce overlap to the extent possible.

The Bridge MIB modules were originally written in the IETF, and implemented by many vendors. Per [\[RFC4663\]](#), this has recently been transferred to the IEEE 802.1 group. As vendors may have implemented either the IETF or IEEE Bridge MIB modules, this RBridge MIB module is designed to work with either one.

6.1 Relationship to IF-MIB

The port identification elements MUST be implemented in order to allow them to be cross referenced. The Interface MIB [[RFC2863](#)] requires that any MIB module which is an adjunct of the Interface MIB clarify specific areas within the Interface MIB module. These areas were intentionally left vague in the Interface MIB module to avoid over-constraining the MIB, thereby precluding management of certain media types. [Section 4 of \[RFC2863\]](#) enumerates several areas which a media-specific MIB module must clarify. The implementor is referred to [[RFC2863](#)] in order to understand the general intent of these areas.

6.2 Relationship to BRIDGE-MIB

The following subtrees in the BRIDGE-MIB [[RFC4188](#)] contain information relevant to RBridges when the corresponding functionality is implemented.

- o dot1dBase
- o dot1dTp
- o dot1dStatic

6.3 Relationship to P-BRIDGE-MIB

The following subtrees in the P-BRIDGE-MIB [[RFC4363](#)] contain information relevant to RBridges when the corresponding functionality is implemented.

- o dot1dExtBase
- o dot1dPriority
- o dot1dGarp
- o dot1dGmrp
- o dot1dTpHCPortTable
- o dot1dTpPortOverflowTable

6.4 Relationship to Q-BRIDGE-MIB

The following groups in the Q-BRIDGE-MIB [[RFC4363](#)] contain information relevant to RBridges when the corresponding functionality is implemented. This functionality is also contained in IEEE8021-Q-BRIDGE-MIB.

- o dot1qBase
- o dot1qTp
- o dot1qStatic
- o dot1qVlan
- o dot1vProtocol

6.5 Relationship to IEEE8021-BRIDGE-MIB

The following subtrees in the IEEE8021-BRIDGE-MIB contain information relevant to RBridges when the corresponding functionality is implemented.

- o ieee8021BridgeBase
- o ieee8021BridgeTp
- o ieee8021BridgePriority
- o ieee8021BridgeMrp
- o ieee8021BridgeMmrp
- o ieee8021BridgeInternalLan
- o ieee8021BridgeDot1d

6.6 Relationship to IEEE8021-Q-BRIDGE-MIB

The following subtrees in the IEEE8021-Q-BRIDGE-MIB contain information relevant to RBridges when the corresponding functionality is implemented.

- o ieee8021QBridgeBase
- o ieee8021QBridgeTp
- o ieee8021QBridgeStatic
- o ieee8021QBridgeVlan
- o ieee8021QBridgeProtocol

6.7 Relationship to ISIS-MIB

The Management Information Base for Intermediate System to Intermediate System (IS-IS) [[RFC4444](#)] defines a MIB module for the IS-IS Routing protocol when it is used to construct routing tables for IP networks. While most of these objects are applicable to the TRILL layer 2 implementation, note the IS-IS constraints for the current version of TRILL [[RFC6325](#)]:

- o The TRILL IS-IS instance uses a single Level 1 IS-IS area.
- o The TRILL Level 1 IS-IS area uses the fixed area address zero.
- o The TRILL IS-IS instance is not used for IP address advertisement.
- o The TRILL IS-IS instance is used for only a single protocol: TRILL.

Accordingly, tables which report IP address reachability and tables which allow configuration or reporting of multiple IS-IS areas, multiple IS-IS levels or multiple protocols, will be empty in the ISIS-MIB module for the current version of TRILL.

Note also that when more than one instance of the IS-IS protocol is running on a device, as in the case of a device performing both RBridge and IS-IS IP router functions, multiple instances of the ISIS-MIB module can be distinguished by the use of SNMPv3 contexts or SNMPv1 communities.

6.8 MIB modules required for IMPORTS

The following MIB module IMPORTS objects from SNMPv2-SMI [[RFC2578](#)], SNMPv2-TC [[RFC2579](#)], SNMPv2-CONF [[RFC2580](#)], IF-MIB [[RFC2863](#)], INET-ADDRESS-MIB[RFC4001], BRIDGE-MIB[RFC4188] and Q-BRIDGE-MIB[RFC4363]. (The IEEE Bridge MIB modules import similar TCs.)

7. Definition of the RBridge MIB module

```
RBRIDGE-MIB DEFINITIONS ::= BEGIN
```

```
-- -----  
-- MIB for RBRIDGE devices, also known as TRILL Switches  
-- -----
```

```
IMPORTS
```

```
    MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE,  
    Counter32, Counter64, Unsigned32, mib-2  
        FROM SNMPv2-SMI                -- RFC2578  
    TEXTUAL-CONVENTION, TruthValue, MacAddress, RowStatus  
        FROM SNMPv2-TC                -- RFC2579  
    MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP  
        FROM SNMPv2-CONF                -- RFC2580  
    VlanId, PortList  
        FROM Q-BRIDGE-MIB              -- RFC4363  
    InetAddress, InetAddressType  
        FROM INET-ADDRESS-MIB          -- RFC4001  
    BridgeId  
        FROM BRIDGE-MIB                -- RFC4188  
    InterfaceIndex  
        FROM IF-MIB                    -- RFC2863  
    ;
```

```
rbridgeMIB MODULE-IDENTITY
```

```
    LAST-UPDATED "201212030000Z"
```

```
    ORGANIZATION "IETF TRILL Working Group"
```

```
    CONTACT-INFO
```

```
        "http://www.ietf.org/dyn/wg/charter/trill-charter.html"
```

```
        Email: rbridge@postel.org
```

Anil Rijhsinghani

Hewlett-Packard
Tel: +1 508 323 1251
Email: anil@charter.net

Kate Zebroze
H.W. Embedded
Tel: +1 617 840 9673
Email: kate.zebroze@alum.mit.edu"

DESCRIPTION

"The RBridge MIB module for managing switches that support
the TRILL protocol."

REVISION "201212030000Z"

DESCRIPTION

"Initial version, published as RFC yyyy"

-- RFC Ed.: replace yyyy with actual RFC number & remove this note

::= { mib-2 xxx }

-- RFC Ed.: replace xxx with IANA-assigned number & remove this note

-- -----
-- subtrees in the RBridge MIB
-- -----

rbridgeNotifications OBJECT IDENTIFIER ::= { rbridgeMIB 0 }
rbridgeObjects OBJECT IDENTIFIER ::= { rbridgeMIB 1 }
rbridgeConformance OBJECT IDENTIFIER ::= { rbridgeMIB 2 }

rbridgeBase OBJECT IDENTIFIER ::= { rbridgeObjects 1 }
rbridgeFdb OBJECT IDENTIFIER ::= { rbridgeObjects 2 }
rbridgeVlan OBJECT IDENTIFIER ::= { rbridgeObjects 3 }
rbridgeEsadi OBJECT IDENTIFIER ::= { rbridgeObjects 4 }
rbridgeCounter OBJECT IDENTIFIER ::= { rbridgeObjects 5 }
rbridgeSnooping OBJECT IDENTIFIER ::= { rbridgeObjects 6 }
rbridgeDtree OBJECT IDENTIFIER ::= { rbridgeObjects 7 }
rbridgeTrill OBJECT IDENTIFIER ::= { rbridgeObjects 8 }

-- -----
-- type definitions
-- -----

RbridgeAddress ::= TEXTUAL-CONVENTION

DISPLAY-HINT "1x:"

STATUS current

DESCRIPTION

"The MAC address used by an RBridge port. This may match the
RBridge ISIS SystemID."

SYNTAX OCTET STRING (SIZE (6))

RbridgeNickname ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d"

STATUS current

DESCRIPTION

"The 16-bit identifier used in TRILL as an abbreviation for the RBridge's 48-bit IS-IS System ID. The value 0 means a nickname is not specified, the values 0xffco through 0xfffe are reserved for future allocation, and the value 0xffff is permanently reserved."

REFERENCE

["RFC 6325 section 3.7"](#)

SYNTAX Unsigned32 (0..65471)

--

-- the rbridgeBase subtree

--

-- Implementation of the rbridgeBase subtree is mandatory for all

-- RBridges.

--

rbridgeBaseTrillVersion OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The maximum TRILL version number that this Rbridge supports."

REFERENCE

["RFC 6325 section 3.2"](#)

::= { rbridgeBase 1 }

rbridgeBaseNumPorts OBJECT-TYPE

SYNTAX Unsigned32

UNITS "ports"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of ports controlled by this RBridge."

REFERENCE

["RFC 6325 section 2.6.1"](#)

::= { rbridgeBase 2 }

rbridgeBaseForwardDelay OBJECT-TYPE

SYNTAX Unsigned32 (4..30)

UNITS "seconds"

MAX-ACCESS read-write
STATUS current
DESCRIPTION
 "Modified aging time for address entries after an appointed
 forwarder change.

 The value of this object MUST be retained across
 reinitializations of the management system."
REFERENCE
 "[RFC 6325 section 4.8.3](#)"
::= { rbridgeBase 3 }

rbridgeBaseUniMultipathEnable OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-write
STATUS current
DESCRIPTION
 "The enabled status of unicast TRILL multipathing.
 It is enabled when true.

 The value of this object MUST be retained across
 reinitializations of the management system."
REFERENCE
 "[RFC 6325 Appendix C](#)"
::= { rbridgeBase 4 }

rbridgeBaseMultiMultipathEnable OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-write
STATUS current
DESCRIPTION
 "The enabled status of multidestination TRILL multipathing.
 It is enabled when true.

 The value of this object MUST be retained across
 reinitializations of the management system."
REFERENCE
 "[RFC 6325 Appendix C](#)"
::= { rbridgeBase 5 }

rbridgeBaseAcceptEncapNonadj OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-write
STATUS current
DESCRIPTION
 "Accept TRILL-encapsulated frames from a neighbor with which
 this RBridge does not have an IS-IS adjacency, when the value
 of this object is 'true'.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.6.2"](#)

::= { rbridgeBase 6 }

rbridgeBaseNicknameNumber OBJECT-TYPE

SYNTAX Unsigned32 (1..256)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The number of nicknames this RBridge should acquire. These can be acquired dynamically or configured statically. This value represents the maximum number of entries in rbridgeBaseNicknameTable."

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 3.7.3"](#)

::= { rbridgeBase 7 }

-- -----
-- The RBridge Base Nickname Table
-- -----

rbridgeBaseNicknameTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeBaseNicknameEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about nicknames configured by an operator or learned dynamically by this RBridge."

REFERENCE

["RFC 6325 section 3.7"](#)

::= { rbridgeBase 8 }

rbridgeBaseNicknameEntry OBJECT-TYPE

SYNTAX RbridgeBaseNicknameEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A list of information for each nickname of the RBridge."

REFERENCE

["RFC 6325 section 3.7"](#)

INDEX { rbridgeBaseNicknameName }

::= { rbridgeBaseNicknameTable 1 }

RbridgeBaseNicknameEntry ::=

```
SEQUENCE {
    rbridgeBaseNicknameName
        RbridgeNickname,
    rbridgeBaseNicknamePriority
        Unsigned32,
    rbridgeBaseNicknameDtrPriority
        Unsigned32,
    rbridgeBaseNicknameType
        INTEGER,
    rbridgeBaseNicknameRowStatus
        RowStatus
}
```

rbridgeBaseNicknameName OBJECT-TYPE

SYNTAX RbridgeNickname

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Nicknames are 16-bit quantities that act as abbreviations for RBridge's 48-bit IS-IS System ID to achieve a more compact encoding."

REFERENCE

["RFC 6325 section 3.7"](#)

::= { rbridgeBaseNicknameEntry 1 }

rbridgeBaseNicknamePriority OBJECT-TYPE

SYNTAX Unsigned32 (0..255)

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This RBridge's priority to hold this nickname. When the nickname is configured, the default value of this object is 192. When nickname is configured, the most significant bit (0x80) must be set and the bottom 7 bits have the default value of 0x40, so 0x80 + 0x40 == 0xC0 which is 192 decimal. Additionally, the bottom 7 bits could be configured to a value other than 0x40."

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 3.7"](#)

DEFVAL { 192 }

::= { rbridgeBaseNicknameEntry 2 }

rbridgeBaseNicknameDtrPriority OBJECT-TYPE

SYNTAX Unsigned32 (1..65535)

MAX-ACCESS read-create
STATUS current
DESCRIPTION
 "The Distribution tree root priority for this nickname.
 The default value of this object is 32768.

 The value of this object MUST be retained across
 reinitializations of the management system."
REFERENCE
 "[RFC 6325 section 4.5](#)"
DEFVAL { 32768 }
::= { rbridgeBaseNicknameEntry 3 }

rbridgeBaseNicknameType OBJECT-TYPE
SYNTAX INTEGER {
 static(1),
 dynamic(2)
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "This object indicates the status of the entry. The
 default value is static(1).
 static(1) - this entry has been configured and
 will remain after the next reset of the RBridge.
 dynamic(2) - this entry has been acquired by the
 RBridge nickname acquisition protocol."
REFERENCE
 "[RFC 6325 section 3.7](#)"
DEFVAL { static }
::= { rbridgeBaseNicknameEntry 4 }

rbridgeBaseNicknameRowStatus OBJECT-TYPE
SYNTAX RowStatus
MAX-ACCESS read-create
STATUS current
DESCRIPTION
 "This object indicates the status of the entry."
::= { rbridgeBaseNicknameEntry 5 }

-- -----
-- The RBridge Port Table
-- -----

rbridgeBasePortTable OBJECT-TYPE
SYNTAX SEQUENCE OF RbridgeBasePortEntry
MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains generic information about every port that is associated with this RBridge."

REFERENCE

["RFC 6325 section 5.3"](#)

::= { rbridgeBase 9 }

rbridgeBasePortEntry OBJECT-TYPE

SYNTAX RbridgeBasePortEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A list of information for each port of the bridge."

REFERENCE

["RFC 6325 section 5.3"](#)

INDEX { rbridgeBasePort }

::= { rbridgeBasePortTable 1 }

RbridgeBasePortEntry ::=

SEQUENCE {

rbridgeBasePort

Unsigned32,

rbridgeBasePortIfIndex

InterfaceIndex,

rbridgeBasePortDisable

TruthValue,

rbridgeBasePortTrunkPort

TruthValue,

rbridgeBasePortAccessPort

TruthValue,

rbridgeBasePortP2pHellos

TruthValue,

rbridgeBasePortState

INTEGER,

rbridgeBasePortInhibitionTime

Unsigned32,

rbridgeBasePortDisableLearning

TruthValue,

rbridgeBasePortDesiredDesigVlan

VlanId,

rbridgeBasePortDesigVlan

VlanId,

rbridgeBasePortStpRoot

BridgeId,

rbridgeBasePortStpRootChanges

Counter32,

rbridgeBasePortStpWiringCloset


```
        BridgeId
    }

rbridgeBasePort OBJECT-TYPE
    SYNTAX      Unsigned32 (1..65535)
    MAX-ACCESS   not-accessible
    STATUS       current
    DESCRIPTION
        "The port number of the port for which this entry
        contains RBridge management information."
    REFERENCE
        "RFC 6325 section 5.2"
    ::= { rbridgeBasePortEntry 1 }

rbridgeBasePortIfIndex OBJECT-TYPE
    SYNTAX      InterfaceIndex
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "The value of the instance of the ifIndex object,
        defined in IF-MIB, for the interface corresponding
        to this port. The Rbridge port sits on top of
        this interface."
    ::= { rbridgeBasePortEntry 2 }

rbridgeBasePortDisable OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Disable port bit. When this bit is set (true), all frames
        received or to be transmitted are discarded, with the
        possible exception of some layer 2 control frames that may
        be generated and transmitted or received and processed
        locally. Default value is false.

        The value of this object MUST be retained across
        reinitializations of the management system."
    REFERENCE
        "RFC 6325 section 4.9.1"
    DEFVAL      { false }
    ::= { rbridgeBasePortEntry 3 }

rbridgeBasePortTrunkPort OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
```


"End station service disable (trunk port) bit. When this bit is set (true), all native frames received on the port and all native frames that would have been sent on the port are discarded. Default value is false.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325](#) 4.9.1"

DEFVAL { false }

::= { rbridgeBasePortEntry 4 }

rbridgeBasePortAccessPort OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"TRILL traffic disable (access port) bit. If this bit is set, the goal is to avoid sending any TRILL frames, except TRILL-Hello frames, on the port since it is intended only for native end station traffic. This ensures that the link is not on the shortest path for any destination. Default value is false.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325](#) 4.9.1"

DEFVAL { false }

::= { rbridgeBasePortEntry 5 }

rbridgeBasePortP2pHellos OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Use P2P Hellos bit. If this bit is set, Hellos sent on this port are IS-IS P2P Hellos, not the default TRILL-Hellos. In addition, the IS-IS P2P three-way handshake is used on P2P RBridge links. Default value is false.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325](#) 4.9.1"

DEFVAL { false }

::= { rbridgeBasePortEntry 6 }

rbridgeBasePortState OBJECT-TYPE

SYNTAX INTEGER {
 uninhibited(1),
 portInhibited(2),
 vlanInhibited(3),
 disabled(4),
 broken(5)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The port's current state. If the entire port is inhibited, its state is portInhibited(2). If specific VLANs are inhibited, the state is vlanInhibited(3) and rbridgeVlanTable will tell which VLANs are inhibited. For ports that are disabled (see rbridgeBasePortDisable), this object will have a value of disabled(4). If the RBridge has detected a port that is malfunctioning, it will place that port into the broken(5) state."

REFERENCE

["RFC 6325 section 4.2.4.3"](#)

::= { rbridgeBasePortEntry 7 }

rbridgeBasePortInhibitionTime OBJECT-TYPE

SYNTAX Unsigned32

UNITS "seconds"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Time in seconds that this RBridge will inhibit forwarding on this port after it observes a spanning tree root bridge change on a link, or receives conflicting VLAN forwarder information. The default value is 30.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.2.4.3"](#)

DEFVAL { 30 }

::= { rbridgeBasePortEntry 8 }

rbridgeBasePortDisableLearning OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Disable learning of MAC addresses seen on this port. To disable learning, the value of this object must be

set to 'true'. The default is 'false'.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.8"](#)

DEFVAL { false }

::= { rbridgeBasePortEntry 9 }

rbridgeBasePortDesiredDesigVlan OBJECT-TYPE

SYNTAX VlanId

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The VLAN that a DRB will specify in its TRILL-Hellos as the VLAN to be used by all RBridges on the link for TRILL frames. This VLAN must be enabled on this port.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.4.3"](#)

::= { rbridgeBasePortEntry 10 }

rbridgeBasePortDesigVlan OBJECT-TYPE

SYNTAX VlanId

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The VLAN being used on this link for TRILL frames."

REFERENCE

["RFC 6325 section 4.4.3"](#)

::= { rbridgeBasePortEntry 11 }

rbridgeBasePortStpRoot OBJECT-TYPE

SYNTAX BridgeId

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The bridge identifier of the root of the spanning tree, as learned from a BPDU received on this port. For MSTP, this is the root bridge of the CIST. If no BPDU has been heard, the value returned is a string of zeros."

REFERENCE

["RFC 6325 section 4.2.4.3"](#)

::= { rbridgeBasePortEntry 12 }

rbridgeBasePortStpRootChanges OBJECT-TYPE

SYNTAX Counter32

UNITS "changes"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times a change in the root bridge is seen from spanning tree BPDUs received on this port, indicating a change in bridged LAN topology. Each such change may cause the port to be inhibited for a period of time. This counter should be synchronized with ifCounterDiscontinuityTime.

Discontinuities in the value of this counter can occur at re-initialization of the management system."

REFERENCE

["RFC 6325 section 4.9.3.2"](#)

::= { rbridgeBasePortEntry 13 }

rbridgeBasePortStpWiringCloset OBJECT-TYPE

SYNTAX BridgeId

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The Bridge ID to be used as Spanning Tree root in BPDUs sent for the Wiring Closet topology solution described in [[RFC6325](#)]. Note that the same value of this object must be set on all RBridge ports participating in this solution. The default value is all 0s. A non-zero value configured into this object indicates that this solution is in use.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section A.3.3"](#)

::= { rbridgeBasePortEntry 14 }

-- -----
-- RBridge Forwarding Database
-- -----

rbridgeConfidenceNative OBJECT-TYPE

SYNTAX Unsigned32 (0..255)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The confidence level associated with MAC addresses learned from native frames. This is applicable to all Rbridge ports.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325 section 4.8.1](#)"

::= { rbridgeFdb 1 }

rbridgeConfidenceDecap OBJECT-TYPE

SYNTAX Unsigned32 (0..255)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The confidence level associated with inner MAC addresses learned after decapsulation of a TRILL data frame. This is applicable to all Rbridge ports.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325 Appendix section 4.8.1](#)"

::= { rbridgeFdb 2 }

rbridgeConfidenceStatic OBJECT-TYPE

SYNTAX Unsigned32 (0..255)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The confidence level associated with MAC addresses that are statically configured. The default value is 255.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

"[RFC 6325 section 4.8.2](#)"

DEFVAL { 255 }

::= { rbridgeFdb 3 }

-- -----
-- Multiple Forwarding Databases for RBridges
--
-- This allows for an instance per FdbId, as defined in the
-- Bridge MIB.
--
-- Each VLAN may have an independent Fdb, or multiple VLANs may
-- share one.
-- -----

rbridgeUniFdbTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeUniFdbEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about unicast entries for which the device has forwarding and/or filtering information. This information is used by the transparent bridging function in determining how to propagate a received frame."

REFERENCE

["RFC 6325 section 4.8"](#)

::= { rbridgeFdb 4 }

rbridgeUniFdbEntry OBJECT-TYPE

SYNTAX RbridgeUniFdbEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Information about a specific unicast MAC address for which the rbridge has some forwarding and/or filtering information."

INDEX { rbridgeFdbId, rbridgeUniFdbAddr }

::= { rbridgeUniFdbTable 1 }

RbridgeUniFdbEntry ::=

SEQUENCE {

rbridgeFdbId

Unsigned32,

rbridgeUniFdbAddr

MacAddress,

rbridgeUniFdbPort

Unsigned32,

rbridgeUniFdbNickname

RbridgeNickname,

rbridgeUniFdbConfidence

Unsigned32,

rbridgeUniFdbStatus

INTEGER

}

rbridgeFdbId OBJECT-TYPE

SYNTAX Unsigned32 (0..4294967295)

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The identity of this Filtering Database."

::= { rbridgeUniFdbEntry 1 }

rbridgeUniFdbAddr OBJECT-TYPE

SYNTAX MacAddress

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A unicast MAC address for which the device has forwarding information."

::= { rbridgeUniFdbEntry 2 }

rbridgeUniFdbPort OBJECT-TYPE

SYNTAX Unsigned32 (0..65535)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Either the value '0', or the Rbridge port number of the port on which a frame having a source address equal to the value of the corresponding instance of rbridgeUniFdbAddr has been seen. A value of '0' indicates that the port number has not been learned but that the device does have some information about this MAC address.

Implementors are encouraged to assign the port value to this object whenever it is available, even for addresses for which the corresponding value of rbridgeUniFdbStatus is not learned(3)."

::= { rbridgeUniFdbEntry 3 }

rbridgeUniFdbNickname OBJECT-TYPE

SYNTAX RbridgeNickname

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The RBridge nickname which is placed in the Egress Nickname field of a TRILL frame sent to this rbridgeFdbAddress in this rbridgeFdbId."

REFERENCE

["RFC 6325 section 4.8.1"](#)

::= { rbridgeUniFdbEntry 4 }

rbridgeUniFdbConfidence OBJECT-TYPE

SYNTAX Unsigned32 (0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The confidence level associated with this entry."

REFERENCE

["RFC 6325 section 4.8.1"](#)

::= { rbridgeUniFdbEntry 5 }

rbridgeUniFdbStatus OBJECT-TYPE

```
SYNTAX      INTEGER {
                other(1),
                invalid(2),
                learned(3),
                self(4),
                mgmt(5),
                esadi(6)
            }
```

```
MAX-ACCESS  read-only
```

```
STATUS      current
```

DESCRIPTION

"The status of this entry. The meanings of the values are:

other(1) - none of the following.

invalid(2) - this entry is no longer valid (e.g., it was learned but has since aged out), but has not yet been flushed from the table.

learned(3) - the information in this entry was learned and is being used.

self(4) - the value of the corresponding instance of rbridgeFdbAddress represents one of the device's addresses. The corresponding instance of rbridgeFdbPort indicates which of the device's ports has this address.

mgmt(5) - the value of the corresponding instance of rbridgeFdbAddress was configured by management.

esadi(6) - the value of the corresponding instance of rbridgeFdbAddress was learned from ESADI."

```
::= { rbridgeUniFdbEntry 6 }
```

```
-- -----
-- RBridge FIB
-- -----
```

rbridgeUniFibTable OBJECT-TYPE

```
SYNTAX      SEQUENCE OF RbridgeUniFibEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

DESCRIPTION

"A table that contains information about nicknames known by the RBridge. If ECMP is implemented, there are as many entries for a nickname as ECMP paths available for it."

```
::= { rbridgeFdb 5 }
```

rbridgeUniFibEntry OBJECT-TYPE

```
SYNTAX      RbridgeUniFibEntry
```



```
MAX-ACCESS    not-accessible
STATUS        current
DESCRIPTION
    "A list of information about nicknames known by the RBridge.
    If ECMP is implemented, there are as many entries as ECMP
    paths available for a given nickname."
INDEX { rbridgeUniFibNickname, rbridgeUniFibPort,
        rbridgeUniFibNextHop }
 ::= { rbridgeUniFibTable 1 }
```

```
RbridgeUniFibEntry ::=
    SEQUENCE {
        rbridgeUniFibNickname
            RbridgeNickname,
        rbridgeUniFibPort
            Unsigned32,
        rbridgeUniFibNextHop
            RbridgeNickname,
        rbridgeUniFibHopCount
            Unsigned32
    }
```

```
rbridgeUniFibNickname OBJECT-TYPE
    SYNTAX      RbridgeNickname
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "An RBridge nickname for which this RBridge has
        forwarding information."
    ::= { rbridgeUniFibEntry 1 }
```

```
rbridgeUniFibPort OBJECT-TYPE
    SYNTAX      Unsigned32 (0..65535)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "The Rbridge port number of the port attached to the
        next-hop RBridge for the path towards the RBridge whose
        nickname is specified in this entry."
    ::= { rbridgeUniFibEntry 2 }
```

```
rbridgeUniFibNextHop OBJECT-TYPE
    SYNTAX      RbridgeNickname
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "The nickname of the next-hop RBridge for the path
        towards the RBridge whose nickname is specified in this
```



```
        entry."
    ::= { rbridgeUniFibEntry 3 }

rbridgeUniFibHopCount OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "The hop count from this ingress Rbridge to the egress
        RBridge whose nickname is specified in
        rbridgeUniFibNickname."
    ::= { rbridgeUniFibEntry 4 }

rbridgeMultiFibTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF RbridgeMultiFibEntry
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "A table that contains information about egress nicknames
        used for multi-destination frame forwarding by this
        RBridge."
    ::= { rbridgeFdb 6 }

rbridgeMultiFibEntry OBJECT-TYPE
    SYNTAX      RbridgeMultiFibEntry
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "A list of information about egress nicknames used for
        multi-destination frame forwarding by this RBridge."
    INDEX       { rbridgeMultiFibNickname }
    ::= { rbridgeMultiFibTable 1 }

RbridgeMultiFibEntry ::=
    SEQUENCE {
        rbridgeMultiFibNickname
            RbridgeNickname,
        rbridgeMultiFibPorts
            PortList
    }

rbridgeMultiFibNickname OBJECT-TYPE
    SYNTAX      RbridgeNickname
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "The nickname of the multicast distribution tree."
    ::= { rbridgeMultiFibEntry 1 }
```


rbridgeMultiFibPorts OBJECT-TYPE

SYNTAX PortList

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The list of ports to which a frame destined to this multicast distribution tree is flooded. This may be pruned further based on other forwarding information."

::= { rbridgeMultiFibEntry 2 }

-- -----
-- The RBridge VLAN Table
-- -----

rbridgeVlanTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeVlanEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about VLANs on the RBridge."

::= { rbridgeVlan 1 }

rbridgeVlanEntry OBJECT-TYPE

SYNTAX RbridgeVlanEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A list of information about VLANs on the RBridge."

INDEX { rbridgeVlanIndex }

::= { rbridgeVlanTable 1 }

RbridgeVlanEntry ::=

SEQUENCE {

rbridgeVlanIndex

Unsigned32,

rbridgeVlanForwarderLosses

Counter32,

rbridgeVlanDisableLearning

TruthValue,

rbridgeVlanSnooping

INTEGER

}

rbridgeVlanIndex OBJECT-TYPE

SYNTAX Unsigned32 (1..4094|4096..4294967295)

MAX-ACCESS not-accessible

STATUS current
DESCRIPTION
"The VLAN-ID referring to this VLAN."
::= { rbridgeVlanEntry 1 }

rbridgeVlanForwarderLosses OBJECT-TYPE

SYNTAX Counter32
UNITS "times"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times this RBridge has lost appointed
forwarder status for this VLAN on any of its ports.

Discontinuities in the value of this counter can occur
at re-initialization of the management system."
REFERENCE
"[RFC 6325 section 4.8.2](#)"
::= { rbridgeVlanEntry 2 }

rbridgeVlanDisableLearning OBJECT-TYPE

SYNTAX TruthValue
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"Disable learning of MAC addresses seen in this VLAN.
One application of this may be to restrict learning to
ESADI. To disable learning, the value of this object
should be set to true. The default is false.

The value of this object MUST be retained across
reinitializations of the management system."
REFERENCE
"[RFC 6325 section 4.8](#)"
DEFVAL { false }
::= { rbridgeVlanEntry 3 }

rbridgeVlanSnooping OBJECT-TYPE

SYNTAX INTEGER {
notSupported(1),
ipv4(2),
ipv6(3),
ipv4v6(4)
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"IP Multicast Snooping on this VLAN. For RBridges

performing both IPv4 and IPv6 IP Multicast Snooping, the value returned is ipv4v6(3)."

REFERENCE

["RFC 6325 section 4.7"](#)

::= { rbridgeVlanEntry 4 }

-- The RBridge VLAN Port Table

rbridgeVlanPortTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeVlanPortEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about VLANs on an RBridge port."

::= { rbridgeVlan 2 }

rbridgeVlanPortEntry OBJECT-TYPE

SYNTAX RbridgeVlanPortEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A list of information about VLANs on the RBridge port."

INDEX { rbridgeBasePort, rbridgeVlanIndex }

::= { rbridgeVlanPortTable 1 }

RbridgeVlanPortEntry ::=

SEQUENCE {

rbridgeVlanPortInhibited

TruthValue,

rbridgeVlanPortForwarder

TruthValue,

rbridgeVlanPortAnnouncing

TruthValue,

rbridgeVlanPortDetectedVlanMapping

TruthValue

}

rbridgeVlanPortInhibited OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This VLAN has been inhibited by the RBridge due to conflicting Forwarder information received from another RBridge, when the value of this object is 'true'."

REFERENCE

["RFC 6325 section 4.2.4.3"](#)
::= { rbridgeVlanPortEntry 1 }

rbridgeVlanPortForwarder OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This RBridge is an Appointed Forwarder for this VLAN
on this port, when the value of this object is 'true'."

REFERENCE

["RFC 6325 section 4.2.4.3"](#)
::= { rbridgeVlanPortEntry 2 }

rbridgeVlanPortAnnouncing OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"TRILL-Hellos tagged with this VLAN can be sent by this
RBridge on this port, when the value of this object
is 'true'."

The value of this object MUST be retained across
reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.4.3"](#)
DEFVAL { true }
::= { rbridgeVlanPortEntry 3 }

rbridgeVlanPortDetectedVlanMapping OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"VLAN mapping has been detected on the link attached
to this port, when the value of this object is 'true'."

REFERENCE

["RFC 6325 section 4.4.5"](#)
::= { rbridgeVlanPortEntry 4 }

-- -----
-- The RBridge Port Counter Table
--
-- These counters supplement counters in the Bridge MIB.
--


```
-- For example, total frames received by a bridge port and total
-- frames transmitted by a bridge port are reported in the
-- Port In Frames and Ports Out Frames counters of the Bridge MIB.
-- These total bridge frames counters include native as well as
-- encapsulated frames.
--
-- As another example, frames discarded due to excessive frame
-- size are reported in the port counter MTU Exceeded Discards
-- in the Bridge MIB.
-- -----
```

```
rbridgePortCounterTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF RbridgePortCounterEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "A table contains per-port counters for this RBridge."
    ::= { rbridgeCounter 1 }
```

```
rbridgePortCounterEntry OBJECT-TYPE
    SYNTAX      RbridgePortCounterEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Counters for a port on this RBridge."
    INDEX      { rbridgeBasePort }
    ::= { rbridgePortCounterTable 1 }
```

```
RbridgePortCounterEntry ::=
    SEQUENCE {
        rbridgePortRpfCheckFails
            Counter32,
        rbridgePortHopCountExceeds
            Counter32,
        rbridgePortOptionDrops
            Counter32,
        rbridgePortTrillInFrames
            Counter64,
        rbridgePortTrillOutFrames
            Counter64
    }
```

```
rbridgePortRpfCheckFails OBJECT-TYPE
    SYNTAX      Counter32
    UNITS       "frames"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
```


"The number of times a multidestination frame was dropped on this port because the RPF check failed.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

["RFC 6325 section 4.5.2"](#)

::= { rbridgePortCounterEntry 1 }

rbridgePortHopCountExceeds OBJECT-TYPE

SYNTAX Counter32

UNITS "frames"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times a frame was dropped on this port because its hop count was zero.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

["RFC 6325 section 3.6"](#)

::= { rbridgePortCounterEntry 2 }

rbridgePortOptionDrops OBJECT-TYPE

SYNTAX Counter32

UNITS "frames"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times a frame was dropped on this port because it contained unsupported options.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

["RFC 6325 section 3.5"](#)

::= { rbridgePortCounterEntry 3 }

rbridgePortTrillInFrames OBJECT-TYPE

SYNTAX Counter64

UNITS "frames"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of TRILL-encapsulated frames that have been received by this port from its attached link, including management frames.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

["RFC 6325 section 2.3"](#)

::= { rbridgePortCounterEntry 4 }

rbridgePortTrillOutFrames OBJECT-TYPE

SYNTAX Counter64

UNITS "frames"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of TRILL-encapsulated frames that have been transmitted by this port to its attached link, including management frames.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

["RFC 6325 section 2.3"](#)

::= { rbridgePortCounterEntry 5 }

-- -----
-- The RBridge VLAN ESADI Table
-- -----

rbridgeEsadiTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeEsadiEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about ESADI instances on


```
        VLANs, if available."
REFERENCE
    "RFC 6325 section 4.2.5"
::= { rbridgeEsadi 1 }

rbridgeEsadiEntry OBJECT-TYPE
    SYNTAX      RbridgeEsadiEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Information about an ESADI instance on a VLAN."
    INDEX       { rbridgeVlanIndex }
    ::= { rbridgeEsadiTable 1 }

RbridgeEsadiEntry ::=
    SEQUENCE {
        rbridgeEsadiEnable
            TruthValue,
        rbridgeEsadiConfidence
            Unsigned32,
        rbridgeEsadiDrbPriority
            Unsigned32,
        rbridgeEsadiDrb
            RbridgeAddress,
        rbridgeEsadiDrbHoldingTime
            Unsigned32,
        rbridgeEsadiRowStatus
            RowStatus
    }

rbridgeEsadiEnable OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "If the RBridge is participating in an ESADI instance for
        this VLAN, the value of this object is 'true'. To disable
        participation, set it to 'false'."

        The value of this object MUST be retained across
        reinitializations of the management system."
    REFERENCE
        "RFC 6325 section 4.2.5"
    DEFVAL      { true }
    ::= { rbridgeEsadiEntry 1 }

rbridgeEsadiConfidence OBJECT-TYPE
    SYNTAX      Unsigned32 (0..255)
```


MAX-ACCESS read-create
STATUS current
DESCRIPTION
"Confidence level of address entries sent by this
ESADI. The default is 16.

The value of this object MUST be retained across
reinitializations of the management system."

REFERENCE
"[RFC 6325 section 4.2.5](#)"
DEFVAL { 16 }
::= { rbridgeEsadiEntry 2 }

rbridgeEsadiDrbPriority OBJECT-TYPE
SYNTAX Unsigned32 (0..127)
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"The priority of this RBridge for being selected as
DRB for this ESADI instance.

The value of this object MUST be retained across
reinitializations of the management system."

REFERENCE
"[RFC 6325 section 4.2.5](#)"
::= { rbridgeEsadiEntry 3 }

rbridgeEsadiDrb OBJECT-TYPE
SYNTAX RbridgeAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The DRB on this ESADI instance's virtual link."
REFERENCE
"[RFC 6325 section 4.2.5](#)"
::= { rbridgeEsadiEntry 4 }

rbridgeEsadiDrbHoldingTime OBJECT-TYPE
SYNTAX Unsigned32 (0..127)
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"The holding time for this ESADI instance.

The value of this object MUST be retained across
reinitializations of the management system."
REFERENCE
"[RFC 6325 section 4.2.5](#)"


```
::= { rbridgeEsadiEntry 5 }
```

```
rbridgeEsadiRowStatus OBJECT-TYPE
```

```
SYNTAX      RowStatus
```

```
MAX-ACCESS  read-create
```

```
STATUS      current
```

```
DESCRIPTION
```

```
    "This object indicates the status of the entry."
```

```
::= { rbridgeEsadiEntry 6 }
```

```
-- -----  
-- The RBridge IP Multicast Snooping Port Table  
-- -----
```

```
rbridgeSnoopingPortTable OBJECT-TYPE
```

```
SYNTAX      SEQUENCE OF RbridgeSnoopingPortEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

```
    "For Rbridges implementing IP Multicast Snooping,  
    information about ports on which the presence of IPv4  
    or IPv6 Multicast Routers has been detected."
```

```
REFERENCE
```

```
    "RFC 6325 section 4.7"
```

```
::= { rbridgeSnooping 1 }
```

```
rbridgeSnoopingPortEntry OBJECT-TYPE
```

```
SYNTAX      RbridgeSnoopingPortEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

```
    "Information about ports on which the presence of IPv4  
    or IPv6 Multicast Routers has been detected for a  
    VLAN."
```

```
INDEX      { rbridgeBasePort, rbridgeVlanIndex }
```

```
::= { rbridgeSnoopingPortTable 1 }
```

```
RbridgeSnoopingPortEntry ::=
```

```
    SEQUENCE {
```

```
        rbridgeSnoopingPortAddrType
```

```
        INTEGER
```

```
    }
```

```
rbridgeSnoopingPortAddrType OBJECT-TYPE
```

```
SYNTAX      INTEGER {  
                ipv4(1),  
                ipv6(2),
```



```

        ipv4v6(3)
    }
    MAX-ACCESS    read-only
    STATUS        current
    DESCRIPTION
        "The IP address type of an IP multicast router detected
        on this port and VLAN. If only IPv4 router(s)
        are detected, the value returned is 'ipv4'. If only
        IPv6 routers are detected, the value returned is
        'ipv6'. If both IPv4 and IPv6 routers are detected on
        this port and VLAN, the value returned is 'ipv4v6'."
    REFERENCE
        "RFC 6325 section 4.7"
    ::= { rbridgeSnoopingPortEntry 1 }

-- -----
-- The RBridge IP Multicast Snooping Address Table
-- -----

rbridgeSnoopingAddrTable OBJECT-TYPE
    SYNTAX        SEQUENCE OF RbridgeSnoopingAddrEntry
    MAX-ACCESS    not-accessible
    STATUS        current
    DESCRIPTION
        "For RBridges implementing IP Multicast Snooping,
        information about IP Multicast addresses being
        snooped."
    REFERENCE
        "RFC 6325 section 4.8"
    ::= { rbridgeSnooping 2 }

rbridgeSnoopingAddrEntry OBJECT-TYPE
    SYNTAX        RbridgeSnoopingAddrEntry
    MAX-ACCESS    not-accessible
    STATUS        current
    DESCRIPTION
        "Information about IP Multicast addresses being
        snooped."
    INDEX { rbridgeVlanIndex, rbridgeSnoopingAddrType,
            rbridgeSnoopingAddr }
    ::= { rbridgeSnoopingAddrTable 1 }

RbridgeSnoopingAddrEntry ::=
    SEQUENCE {
        rbridgeSnoopingAddrType
            InetAddressType,
        rbridgeSnoopingAddr
            InetAddress,
```



```
        rbridgeSnoopingAddrPorts
            PortList
    }

rbridgeSnoopingAddrType OBJECT-TYPE
    SYNTAX      InetAddressType
    MAX-ACCESS   not-accessible
    STATUS       current
    DESCRIPTION
        "The IP multicast address type for which a listener has been
        detected by this RBridge. This MIB requires support for only
        IPv4 and IPv6 address types."
    REFERENCE
        "RFC 6325 section 4.7"
    ::= { rbridgeSnoopingAddrEntry 1 }

rbridgeSnoopingAddr OBJECT-TYPE
    SYNTAX      InetAddress
    MAX-ACCESS   not-accessible
    STATUS       current
    DESCRIPTION
        "The IP multicast address for which a listener has been
        detected by this RBridge. The address type of this object
        is specified in rbridgeSnoopingAddrType. This MIB requires
        support for only global IPv4 and IPv6 addresses, so the
        length of the object can be either 4 or 16 bytes. Hence
        the index will not exceed the OID size limit."
    REFERENCE
        "RFC 6325 section 4.7"
    ::= { rbridgeSnoopingAddrEntry 2 }

rbridgeSnoopingAddrPorts OBJECT-TYPE
    SYNTAX      PortList
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "The set of ports on which a listener has been detected
        for this IP multicast address."
    REFERENCE
        "RFC 6325 section 4.7"
    ::= { rbridgeSnoopingAddrEntry 3 }

-- -----
-- Distribution Trees
-- -----

rbridgeDtreePriority OBJECT-TYPE
```


SYNTAX Unsigned32 (1..65535)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The Distribution tree root priority for this Rbridge.
The default value of this object is 32768.

The value of this object MUST be retained across
reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.5"](#)

::= { rbridgeDtree 1 }

rbridgeDtreeActiveTrees OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of trees being computed by all Rbridges
in the campus."

REFERENCE

["RFC 6325 section 4.5"](#)

::= { rbridgeDtree 2 }

rbridgeDtreeMaxTrees OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The maximum number of trees this Rbridge can compute."

REFERENCE

["RFC 6325 section 4.5"](#)

::= { rbridgeDtree 3 }

rbridgeDtreeDesiredUseTrees OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The maximum number of trees this Rbridge would like to
use for transmission of ingress multi-destination frames."

REFERENCE

["RFC 6325 section 4.5"](#)

::= { rbridgeDtree 4 }

rbridgeDtreeTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeDtreeEntry

MAX-ACCESS not-accessible

STATUS current
DESCRIPTION
"Information about Distribution Trees being computed
by this Rbridge."
REFERENCE
["RFC 6325 section 4.5"](#)
::= { rbridgeDtree 5 }

rbridgeDtreeEntry OBJECT-TYPE
SYNTAX RbridgeDtreeEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"List of information about Distribution Trees being computed
by this Rbridge."
INDEX { rbridgeDtreeNumber }
::= { rbridgeDtreeTable 1 }

RbridgeDtreeEntry ::=

```
SEQUENCE {  
    rbridgeDtreeNumber  
        Unsigned32,  
    rbridgeDtreeNickname  
        RbridgeNickname,  
    rbridgeDtreeIngress  
        TruthValue  
}
```

rbridgeDtreeNumber OBJECT-TYPE
SYNTAX Unsigned32 (0..65535)
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"The tree number of a distribution tree being computed by
this RBridge."
REFERENCE
["RFC 6325 section 4.5"](#)
::= { rbridgeDtreeEntry 1 }

rbridgeDtreeNickname OBJECT-TYPE
SYNTAX RbridgeNickname
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The nickname of the distribution tree."
REFERENCE
["RFC 6325 section 4.5"](#)
::= { rbridgeDtreeEntry 2 }

rbridgeDtreeIngress OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this RBridge might choose this distribution tree to ingress a multi-destination frame."

REFERENCE

["RFC 6325 section 4.5"](#)

::= { rbridgeDtreeEntry 3 }

-- -----
-- TRILL neighbor list
-- -----

rbridgeTrillMinMtuDesired OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The desired minimum acceptable inter-RBridge link MTU for the campus, that is, originatingLSPBufferSize."

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.3"](#)

::= { rbridgeTrill 1 }

rbridgeTrillSz OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The minimum acceptable inter-Rbridge link size for the campus for the proper operation of TRILL IS-IS."

REFERENCE

["RFC 6325 section 4.3"](#)

::= { rbridgeTrill 2 }

rbridgeTrillMaxMtuProbes OBJECT-TYPE

SYNTAX Unsigned32 (1..255)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The number of failed MTU-probes before the RBridge concludes that a particular MTU is not supported by

a neighbor.

The value of this object MUST be retained across reinitializations of the management system."

REFERENCE

["RFC 6325 section 4.3"](#)

::= { rbridgeTrill 3 }

rbridgeTrillNbrTable OBJECT-TYPE

SYNTAX SEQUENCE OF RbridgeTrillNbrEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Information about this Rbridge's TRILL neighbors."

REFERENCE

["RFC 6325 section 4.4.2.1"](#)

::= { rbridgeTrill 4 }

rbridgeTrillNbrEntry OBJECT-TYPE

SYNTAX RbridgeTrillNbrEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"List of information about this Rbridge's TRILL neighbors."

INDEX { rbridgeTrillNbrMacAddr }

::= { rbridgeTrillNbrTable 1 }

RbridgeTrillNbrEntry ::=

SEQUENCE {

rbridgeTrillNbrMacAddr

MacAddress,

rbridgeTrillNbrMtu

Unsigned32,

rbridgeTrillNbrFailedMtuTest

TruthValue

}

rbridgeTrillNbrMacAddr OBJECT-TYPE

SYNTAX MacAddress

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The MAC address of a neighbor of this RBridge."

REFERENCE

["RFC 6325 section 4.4.2.1"](#)

::= { rbridgeTrillNbrEntry 1 }

rbridgeTrillNbrMtu OBJECT-TYPE

SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "MTU size for this neighbor for IS-IS communication
 purposes."
REFERENCE
 "[RFC 6325 section 4.3.2](#)"
::= { rbridgeTrillNbrEntry 2 }

rbridgeTrillNbrFailedMtuTest OBJECT-TYPE

SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "If true, indicates that the neighbor's tested MTU is less
 than the minimum acceptable inter-bridge link MTU for the
 campus (1470)."
REFERENCE
 "[RFC 6325 section 4.3.1](#)"
::= { rbridgeTrillNbrEntry 3 }

-- -----
-- Notifications for use by RBridges
-- -----

rbridgeBaseNewDrb NOTIFICATION-TYPE

-- OBJECTS { }
STATUS current
DESCRIPTION
 "The RBridgeBaseNewDrb notification indicates that the
 sending agent has become the new Designated RBridge; the
 notification is sent by an RBridge soon after its election
 as the new DRB root, e.g., upon expiration of the Topology
 Change Timer, immediately subsequent to its election."
::= { rbridgeNotifications 1 }

rbridgeBaseTopologyChange NOTIFICATION-TYPE

-- OBJECTS { }
STATUS current
DESCRIPTION
 "The RBridgeBaseTopologyChange notification is sent by an
 RBridge when any of its configured ports transitions to/from
 Vlan-x designated forwarder. The notification is not sent
 if a rbridgeBaseNewDrb notification is sent for the same
 transition."
::= { rbridgeNotifications 2 }

-- Compliance and Group sections

rbridgeCompliances OBJECT IDENTIFIER ::= { rbridgeConformance 1 }

rbridgeGroup OBJECT IDENTIFIER ::= { rbridgeConformance 2 }

-- -----
-- Units of Conformance
-- -----

rbridgeBaseGroup OBJECT-GROUP

OBJECTS {

 rbridgeBaseTrillVersion,
 rbridgeBaseNumPorts,
 rbridgeBaseForwardDelay,
 rbridgeBaseUniMultipathEnable,
 rbridgeBaseMultiMultipathEnable,
 rbridgeBaseAcceptEncapNonadj,
 rbridgeBaseNicknameNumber

}

STATUS current

DESCRIPTION

 "A collection of objects providing basic control
 and status information for the RBridge."

::= { rbridgeGroup 1 }

rbridgeBaseNicknameGroup OBJECT-GROUP

OBJECTS {

 rbridgeBaseNicknamePriority,
 rbridgeBaseNicknameDtrPriority,
 rbridgeBaseNicknameType,
 rbridgeBaseNicknameRowStatus

}

STATUS current

DESCRIPTION

 "A collection of objects providing basic control
 and status information for RBridge nicknames."

::= { rbridgeGroup 2 }

rbridgeBasePortGroup OBJECT-GROUP

OBJECTS {

 rbridgeBasePortIfIndex,
 rbridgeBasePortDisable,
 rbridgeBasePortTrunkPort,
 rbridgeBasePortAccessPort,
 rbridgeBasePortP2pHellos,
 rbridgeBasePortState,


```
    rbridgeBasePortDesiredDesigVlan,
    rbridgeBasePortDesigVlan,
    rbridgeBasePortInhibitionTime,
    rbridgeBasePortDisableLearning,
    rbridgeBasePortStpRoot,
    rbridgeBasePortStpRootChanges,
    rbridgeBasePortStpWiringCloset
}
STATUS      current
DESCRIPTION
    "A collection of objects providing basic control
    and status information for RBridge ports."
::= { rbridgeGroup 3 }

rbridgeFdbGroup OBJECT-GROUP
OBJECTS {
    rbridgeConfidenceNative,
    rbridgeConfidenceDecap,
    rbridgeConfidenceStatic,
    rbridgeUniFdbPort,
    rbridgeUniFdbNickname,
    rbridgeUniFdbConfidence,
    rbridgeUniFdbStatus
}
STATUS      current
DESCRIPTION
    "A collection of objects providing information
    about the Unicast Address Database."
::= { rbridgeGroup 4 }

rbridgeFibGroup OBJECT-GROUP
OBJECTS {
    rbridgeUniFibHopCount,
    rbridgeMultiFibPorts
}
STATUS      current
DESCRIPTION
    "A collection of objects providing information
    about the Unicast and Multicast FIBs."
::= { rbridgeGroup 5 }

rbridgeVlanGroup OBJECT-GROUP
OBJECTS {
    rbridgeVlanForwarderLosses,
    rbridgeVlanDisableLearning,
    rbridgeVlanSnooping,
    rbridgeVlanPortInhibited,
    rbridgeVlanPortForwarder,
```



```
        rbridgeVlanPortAnnouncing,
        rbridgeVlanPortDetectedVlanMapping
    }
    STATUS          current
    DESCRIPTION
        "A collection of objects providing information
        about VLANs on the RBridge."
    ::= { rbridgeGroup 6 }

rbridgePortCounterGroup OBJECT-GROUP
    OBJECTS {
        rbridgePortRpfCheckFails,
        rbridgePortHopCountExceeds,
        rbridgePortOptionDrops,
        rbridgePortTrillInFrames,
        rbridgePortTrillOutFrames
    }
    STATUS          current
    DESCRIPTION
        "A collection of objects providing per-port
        counters for the RBridge."
    ::= { rbridgeGroup 7 }

rbridgeEsadiGroup OBJECT-GROUP
    OBJECTS {
        rbridgeEsadiEnable,
        rbridgeEsadiConfidence,
        rbridgeEsadiDrbPriority,
        rbridgeEsadiDrb,
        rbridgeEsadiDrbHoldingTime,
        rbridgeEsadiRowStatus
    }
    STATUS          current
    DESCRIPTION
        "A collection of objects providing information
        about ESADI instances on the RBridge."
    ::= { rbridgeGroup 8 }

rbridgeSnoopingGroup OBJECT-GROUP
    OBJECTS {
        rbridgeSnoopingPortAddrType,
        rbridgeSnoopingAddrPorts
    }
    STATUS          current
    DESCRIPTION
        "A collection of objects providing information
        about IP Multicast Snooping. This MIB requires
        support for only global IPv4 and IPv6 address
```



```
types in rbridgeSnoopingPortAddrType and
rbridgeSnoopingAddrType, so the length of
rbridgeSnoopingAddr can be either 4 or 16
bytes."
 ::= { rbridgeGroup 9 }

rbridgeDtreeGroup OBJECT-GROUP
  OBJECTS {
    rbridgeDtreePriority,
    rbridgeDtreeActiveTrees,
    rbridgeDtreeMaxTrees,
    rbridgeDtreeDesiredUseTrees,
    rbridgeDtreeNickname,
    rbridgeDtreeIngress
  }
  STATUS      current
  DESCRIPTION
    "A collection of objects providing information
    about Distribution Trees."
  ::= { rbridgeGroup 10 }

rbridgeTrillGroup OBJECT-GROUP
  OBJECTS {
    rbridgeTrillMinMtuDesired,
    rbridgeTrillSz,
    rbridgeTrillMaxMtuProbes,
    rbridgeTrillNbrMtu,
    rbridgeTrillNbrFailedMtuTest
  }
  STATUS      current
  DESCRIPTION
    "A collection of objects providing information
    about TRILL neighbors."
  ::= { rbridgeGroup 11 }

rbridgeNotificationGroup NOTIFICATION-GROUP
  NOTIFICATIONS {
    rbridgeBaseNewDrb,
    rbridgeBaseTopologyChange
  }
  STATUS      current
  DESCRIPTION
    "A collection of objects describing notifications (traps)."
```

```
-- Compliance Statement
```

```
-- -----
```

```
rbridgeCompliance MODULE-COMPLIANCE
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "The compliance statement for support of RBridge
        services."
```

```
    MODULE
```

```
        MANDATORY-GROUPS {
```

```
            rbridgeBaseGroup,
            rbridgeBaseNicknameGroup,
            rbridgeBasePortGroup,
            rbridgeFdbGroup,
            rbridgeFibGroup,
            rbridgeVlanGroup,
            rbridgeDtreeGroup,
            rbridgeTrillGroup,
            rbridgeNotificationGroup
        }
```

```
    GROUP      rbridgePortCounterGroup
```

```
    DESCRIPTION
```

```
        "Implementation of this group is optional."
```

```
    GROUP      rbridgeEsadiGroup
```

```
    DESCRIPTION
```

```
        "Implementation of this group is optional."
```

```
    GROUP      rbridgeSnoopingGroup
```

```
    DESCRIPTION
```

```
        "Implementation of this group is optional."
```

```
 ::= { rbridgeCompliances 1 }
```

```
rbridgeReadOnlyCompliance MODULE-COMPLIANCE
```

```
    STATUS      current
```

```
    DESCRIPTION
```

```
        "When this MIB is implemented in read-only mode, then
        the implementation can claim read-only compliance. In
        that case, RBridge objects can be monitored but cannot
        be configured with this implementation."
```

```
    MODULE
```

```
        MANDATORY-GROUPS {
```

```
            rbridgeBaseGroup,
            rbridgeBaseNicknameGroup,
```



```
        rbridgeBasePortGroup,  
        rbridgeFdbGroup,  
        rbridgeFibGroup,  
        rbridgeVlanGroup,  
        rbridgeDtreeGroup,  
        rbridgeTrillGroup,  
        rbridgeNotificationGroup  
    }
```

```
OBJECT  rbridgeBaseForwardDelay  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseUniMultipathEnable  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseMultiMultipathEnable  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseAcceptEncapNonadj  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseNicknameNumber  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseNicknamePriority  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseNicknameDtrPriority  
MIN-ACCESS  read-only  
DESCRIPTION  
    "Write access is not required."
```

```
OBJECT  rbridgeBaseNicknameRowStatus  
SYNTAX  INTEGER { active(1) }  
MIN-ACCESS  read-only  
DESCRIPTION
```


"Write access is not required, and 'active' is the only status that needs to be supported."

OBJECT rbridgeBasePortDisable
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortTrunkPort
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortAccessPort
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortP2pHellos
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortInhibitionTime
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortDisableLearning
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortDesiredDesigVlan
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeBasePortStpWiringCloset
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeConfidenceNative
MIN-ACCESS read-only
DESCRIPTION
"Write access is not required."

OBJECT rbridgeConfidenceDecap
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeConfidenceStatic
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeVlanDisableLearning
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeVlanPortAnnouncing
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeEsadiEnable
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeEsadiConfidence
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeEsadiDrbPriority
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeEsadiDrbHoldingTime
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required."

OBJECT rbridgeEsadiRowStatus
SYNTAX INTEGER { active(1) }
MIN-ACCESS read-only
DESCRIPTION
 "Write access is not required, and 'active' is the only
 status that needs to be supported."


```
OBJECT rbridgeDtreePriority
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."

OBJECT rbridgeTrillMinMtuDesired
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."

OBJECT rbridgeTrillMaxMtuProbes
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."

GROUP rbridgePortCounterGroup
DESCRIPTION
    "Implementation of this group is optional."

GROUP rbridgeEsadiGroup
DESCRIPTION
    "Implementation of this group is optional."

GROUP rbridgeSnoopingGroup
DESCRIPTION
    "Implementation of this group is optional."

 ::= { rbridgeCompliances 2 }
```

END

8. Security Considerations

This MIB relates to a system which will provide network connectivity and packet forwarding services. As such, improper manipulation of the objects represented by this MIB may result in denial of service to a large number of end-users.

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These tables and objects and their sensitivity/vulnerability are described below.

The following tables and objects in the RBRIDGE-MIB can be manipulated to interfere with the operation of RBridges:

- o rbridgeBaseUniMultipathEnable affects the ability of the RBridge to multipath unicast traffic, and rbridgeBaseMultiMultipathEnable affects the ability of the Rbridge to multipath multi-destination traffic.

- o rbridgeBasePortTable contains a number of objects that may affect network connectivity. Actions that may be triggered by manipulating objects in this table include disabling of an RBridge port; discarding of native packets; disabling learning and others.

- o rbridgeEsadiTable contains objects that affect the operation of the ESADI protocol used for learning, and manipulation of the objects contained therein can be used to confuse the learning ability of RBridges.

- o rbridgeDtreePriority can affect computation of distribution trees within an Rbridge campus, thereby affecting forwarding of multi-destination traffic.

- o rbridgeTrillMinMtuDesired can affect the size of packets being used to exchange information between RBridges.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over the network via SNMP. For example, access to network topology and Rbridge attributes can reveal information that should not be available to all users of the network.

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPsec), there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [\[RFC3410\]](#), [section 8](#)), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator

responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

For other RBridge security considerations see [[RFC6325](#)].

9. IANA Considerations

The MIB module in this document uses the following IANA-assigned OBJECT IDENTIFIER value recorded in the SMI Numbers registry:

Descriptor OBJECT IDENTIFIER value

rbridgeMIB { mib-2 xxx }

Editor's Note (to be removed prior to publication): the IANA is requested to assign a value for "xxx" under the 'mib-2' subtree and to record the assignment in the SMI Numbers registry. When the assignment has been made, the RFC Editor is asked to replace "XXX" (here and in the MIB module) with the assigned value and to remove this note.

10. Contributors

The authors would like to acknowledge the contributions of Donald Eastlake, Radia Perlman, Anoop Ghanwani, Dan Romascanu, Mahesh Akula, Sue Hares and Joan Cucchiara.

11. References

11.1 Normative References

- [RFC6325] Perlman, R., Eastlake, D., Dutt, D., Gai, S., and A. Ghanwani, "Routing Bridges (RBridges): Base Protocol Specification", [RFC 6325](#), July 2011.
- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", [BCP 14](#), [RFC 2119](#), March 1997.
- [RFC2578] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Structure of Management Information Version 2 (SMIv2)", STD 58, [RFC 2578](#),

April 1999.

- [RFC2579] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Textual Conventions for SMIV2", STD 58, [RFC 2579](#), April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", [RFC 2863](#), June 2000.
- [RFC4188] Norseth, K. and E. Bell, "Definitions of Managed Objects for Bridges", [RFC 4188](#), September 2005.
- [RFC4363] Levi, D. and D. Harrington, "Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions", [RFC 4363](#), January 2006.
- [RFC2580] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIV2", STD 58, [RFC 2580](#), April 1999.
- [RFC4444] Parker, J., "Management Information Base for Intermediate System to Intermediate System (IS-IS)", [RFC 4444](#), April 2006.
- [RFC4001] Daniele, M., Haberman, B. and J. Schoenwaelder, "Textual Conventions for Internet Network Addresses", [RFC 4001](#), February 2005.
- [802.1Q-2005] Institute of Electrical and Electronics Engineers, "Local and Metropolitan Area Networks: Virtual Bridged Local Area Networks", IEEE 802.1Q, May 2006.

11.2 Informative References

- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", [RFC 3410](#), December 2002.
- [RFC5556] Touch, J. and R. Perlman, "Transparent Interconnection of Lots of Links (TRILL): Problem and Applicability Statement", [RFC 5556](#), May 2009.
- [RFC4663] Harrington, D., "Transferring MIB Work from IETF Bridge MIB WG to IEEE 802.1 WG", [RFC 4663](#), September 2006.

Authors' Addresses

Anil Rijhsinghani
Hewlett-Packard Networking
153 Taylor St
Littleton, MA
USA

Phone: +1 508 323 1251
EMail: anil@charter.net

Kate Zebrose
H.W. Embedded
26 Josephine Ave
Somerville, MA
USA

Phone: +1 617 840 9673
EMail: zebrose@alum.mit.edu

Copyright and License Notice

Copyright (c) 2012 IETF Trust and the persons identified as the document authors. All rights reserved.

This document is subject to [BCP 78](http://trustee.ietf.org/bcp78) and the IETF Trust's Legal Provisions Relating to IETF Documents (<http://trustee.ietf.org/license-info>) in effect on the date of publication of this document. Please review these documents carefully, as they describe your rights and restrictions with respect to this document. Code Components extracted from this document must include Simplified BSD License text as described in Section 4.e of the Trust Legal Provisions and are provided without warranty as described in the Simplified BSD License.

