Network Working Group Request for Comments: 4070 Category: Standards Track M. Dodge
ECI Telecom
B. Ray
PESA Switching Systems
May 2005

Definitions of Managed Object Extensions for Very High Speed Digital Subscriber Lines (VDSL) Using Multiple Carrier Modulation (MCM) Line Coding

Status of This Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2005).

Abstract

This document defines a portion of the Management Information Base (MIB) module for use with network management protocols in the Internet community. In particular, it describes objects used for managing the Line Code Specific parameters of Very High Speed Digital Subscriber Line (VDSL) interfaces using Multiple Carrier Modulation (MCM) Line Coding. It is an optional extension to the VDSL-LINE-MIB, RFC 3728, which handles line code independent objects.

Dodge & Ray Standards Track [Page 1]

Table of Contents

2
les
3
3
<u>19</u>
<u>19</u>
<u>21</u>
<u>21</u>
<u>21</u>
23

1. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIv2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

2. Overview

This document describes an SNMP MIB module for managing the Line Code Dependent, Physical Medium Dependent (PMD), Layer of MCM VDSL Lines. These definitions are based upon the specifications for VDSL as defined in T1E1, European Telecommunications Standards Institute (ETSI), and International Telecommunication Union (ITU) documentation [T1E1311, T1E1011, T1E1013, ETSI2701, ETSI2702, ITU9931, ITU9971]. Additionally the protocol-dependent (and line-code dependent) management framework for VDSL lines specified by the Digital Subscriber Line Forum (DSLF) has been taken into consideration DSLFTR57

The MIB module is located in the MIB tree under MIB-2 transmission.

The key words "MUST", "MUST NOT", "RECOMMENDED", and "SHOULD" in this document are to be interpreted as described in [RFC2119].

2.1. Relationship of this MIB Module to other MIB Modules

The relationship of the VDSL Line MIB module to other MIB modules and in particular to the IF-MIB, as presented in $\frac{RFC\ 2863}{RFC2863}$, is discussed in the VDSL-LINE-MIB, $\frac{RFC\ 3728}{RFC3728}$. This section outlines the relationship of this VDSL Line Extension MIB to the VDSL-LINE-MIB, $\frac{RFC\ 3728}{RFC3728}$.

2.2. Conventions used in the MIB Module

2.2.1. Naming Conventions

- A. Vtuc -- (VTUC) transceiver at near (Central) end of line
- B. Vtur -- (VTUR) transceiver at Remote end of line
- C. Vtu -- One of either Vtuc or Vtur
- D. Curr -- Current
- E. LCS -- Line Code Specific
- F. Max -- Maximum
- G. PSD -- Power Spectral Density
- H. Rx -- Receive
- I. Tx -- Transmit

2.3. Structure

The MCM VDSL Line Extension MIB contains the following MIB group:

o vdslMCMGroup:

This group supports MIB objects for defining configuration profiles and for monitoring individual bands of Multiple Carrier Modulation (MCM) VDSL modems. It contains the following tables:

- vdslLineMCMConfProfileTable
- vdslLineMCMConfProfileTxBandTable
- vdslLineMCMConfProfileRxBandTable
- vdslLineMCMConfProfileTxPSDTable
- vdslLineMCMConfProfileMaxTxPSDTable
- vdslLineMCMConfProfileMaxRxPSDTable

If the MCM VDSL Line Extension MIB is implemented then all of the objects in this group MUST be implemented.

Figure 1, below, displays the relationship of the tables in the vdslMCMGroup to the vdslGroup and to the ifEntry:

Figure 1: Table Relationships

When the object vdslLineCoding is set to MCM, vdslLineConfProfileName is used as the index to each of the six vdslLineMCMConfProfile Tables. The existence of an entry in any of the tables of the vdslMCMGroup is optional.

2.4. Persistence

All read-create objects defined in this MIB module SHOULD be stored persistently. Following is an exhaustive list of these persistent objects:

```
vdslMCMConfProfileTxWindowLength
vdslMCMConfProfileRowStatus
vdslMCMConfProfileTxBandNumber
vdslMCMConfProfileTxBandStart
vdslMCMConfProfileTxBandStop
vdslMCMConfProfileTxBandRowStatus
vdslMCMConfProfileRxBandStart
vdslMCMConfProfileRxBandStop
vdslMCMConfProfileRxBandRowStatus
vdslMCMConfProfileTxPSDTone
vdslMCMConfProfileTxPSDPSD
vdslMCMConfProfileTxPSDRowStatus
vdslMCMConfProfileMaxTxPSDTone
vdslMCMConfProfileMaxTxPSDPSD
vdslMCMConfProfileMaxTxPSDRowStatus
vdslMCMConfProfileMaxRxPSDTone
vdslMCMConfProfileMaxRxPSDPSD
vds1MCMConfProfileMaxRxPSDRowStatus
```

Note also that the interface indices in this MIB are maintained persistently. View-based Access Control Model (VACM) data relating to these SHOULD be stored persistently as well [RFC3415].

3. Conformance and Compliance

An MCM based VDSL agent does not have to implement this MIB to be compliant with RFC 3728 [RFC3728]. If the MCM VDSL Line Extension MIB is implemented then the following group is mandatory:

vdslMCMGroup

4. Definitions

VDSL-LINE-EXT-MCM-MIB DEFINITIONS ::= BEGIN

IMPORTS

MODULE-IDENTITY,

OBJECT-TYPE,

transmission,

FROM SNMPv2-SMI Unsigned32 -- [<u>RFC2578</u>]

RowStatus FROM SNMPv2-TC -- [RFC2579]

MODULE-COMPLIANCE,

OBJECT-GROUP FROM SNMPv2-CONF -- [RFC2580] FROM VDSL-LINE-MIB; -- [<u>RFC3728</u>]

vdslLineConfProfileName

vdslextMCMMIB MODULE-IDENTITY

LAST-UPDATED "200504280000Z" --April 28, 2005

ORGANIZATION "ADSLMIB Working Group"

CONTACT-INFO "WG-email: adslmib@ietf.org

Info: https://www1.ietf.org/mailman/listinfo/adslmib

Chair: Mike Sneed

Sand Channel Systems

Postal: P.O. Box 37324

Raleigh NC 27627-732

Email: sneedmike@hotmail.com

Phone: +1 206 600 7022

Co-Chair/Co-editor:

Bob Ray

PESA Switching Systems, Inc.

330-A Wynn Drive Postal:

Huntsville, AL 35805

USA

Email: rray@pesa.com

Phone: +1 256 726 9200 ext. 142 Co-editor: Menachem Dodge

ECI Telecom Ltd.

Postal: 30 hasivim St.

Petach Tikva 49517,

Israel.

mbdodge@ieee.org Email: +972 3 926 8421 Phone:

DESCRIPTION

"The VDSL-LINE-MIB found in RFC 3728 defines objects for the management of a pair of VDSL transceivers at each end of the VDSL line. The VDSL-LINE-MIB configures and monitors the line code independent parameters (TC layer) of the VDSL line. This MIB module is an optional extension of the VDSL-LINE-MIB and defines objects for configuration and monitoring of the line code specific (LCS) elements (PMD layer) for VDSL lines using MCM coding. The objects in this extension MIB MUST NOT be used for VDSL lines using Single Carrier Modulation (SCM) line coding. If an object in this extension MIB is referenced by a line which does not use MCM, it has no effect on the operation of that line.

Naming Conventions:

::= { transmission 229 }

```
Vtuc -- (VTUC) transceiver at near (Central) end of line
   Vtur -- (VTUR) transceiver at Remote end of line
   Vtu -- One of either Vtuc or Vtur
    Curr -- Current
    LCS -- Line Code Specific
    Max -- Maximum
    PSD -- Power Spectral Density
    Rx -- Receive
    Tx -- Transmit
Copyright (C) The Internet Society (2005). This version
of this MIB module is part of RFC 4070: see the RFC
itself for full legal notices."
    REVISION "200504280000Z" --
                                April 28, 2005
```

vdslLineExtMCMMib OBJECT IDENTIFIER ::= { vdslExtMCMMIB 1 } vdslLineExtMCMMibObjects OBJECT IDENTIFIER ::= {vdslLineExtMCMMib 1}

DESCRIPTION "Initial version, published as RFC 4070."

-- Multiple carrier modulation (MCM) configuration profile tables

```
vdslLineMCMConfProfileTable OBJECT-TYPE
   SYNTAX
                SEQUENCE OF VdslLineMCMConfProfileEntry
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
        "This table contains additional information on multiple
        carrier VDSL lines. One entry in this table reflects a
        profile defined by a manager which can be used to
        configure the VDSL line.
        If an entry in this table is referenced by a line which
        does not use MCM, it has no effect on the operation of that
        line.
        All read-create-objects defined in this table SHOULD be
        stored persistently."
    ::= { vdslLineExtMCMMibObjects 1 }
vdslLineMCMConfProfileEntry OBJECT-TYPE
   SYNTAX
               VdslLineMCMConfProfileEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Each entry consists of a list of parameters that
        represents the configuration of a multiple carrier
       modulation VDSL modem."
    INDEX { vdslLineConfProfileName }
    ::= { vdslLineMCMConfProfileTable 1 }
VdslLineMCMConfProfileEntry ::=
    SEQUENCE
       vdslLineMCMConfProfileTxWindowLength
                                                  Unsigned32,
       vdslLineMCMConfProfileRowStatus
                                                  RowStatus
vdslLineMCMConfProfileTxWindowLength OBJECT-TYPE
   SYNTAX Unsigned32 (1..255)
   UNITS
                "samples"
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "Specifies the length of the transmit window, counted
        in samples at the sampling rate corresponding to the
        negotiated value of N."
                "T1E1.4/2000-013R4" -- Part 3, MCM
   REFERENCE
    ::= { vdslLineMCMConfProfileEntry 1 }
```

```
vdslLineMCMConfProfileRowStatus OBJECT-TYPE
```

SYNTAX RowStatus
MAX-ACCESS read-create
STATUS current

DESCRIPTION

"This object is used to create a new row or modify or delete an existing row in this table.

A profile is activated by setting this object to `active'. When `active' is set, the system will validate the profile.

None of the columns in this row may be modified while the row is in the 'active' state.

Before a profile can be deleted or taken out of
 service, (by setting this object to `destroy' or
 `notInService') it must first be unreferenced
 from all associated lines."
::= { vdslLineMCMConfProfileEntry 2 }

vdslLineMCMConfProfileTxBandTable OBJECT-TYPE

SYNTAX SEQUENCE OF VdslLineMCMConfProfileTxBandEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains transmit band descriptor configuration information for a VDSL line. Each entry in this table reflects the configuration for one of possibly many bands with a multiple carrier modulation (MCM) VDSL line. These entries are defined by a manager and can be used to configure the VDSL line.

If an entry in this table is referenced by a line which does not use MCM, it has no effect on the operation of that line.

::= { vdslLineExtMCMMibObjects 2 }

vdslLineMCMConfProfileTxBandEntry OBJECT-TYPE

SYNTAX VdslLineMCMConfProfileTxBandEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Each entry consists of a transmit band descriptor, which
is defined by a start and a stop tone index."
INDEX { vdslLineConfProfileName,

```
vdslLineMCMConfProfileTxBandNumber }
    ::= { vdslLineMCMConfProfileTxBandTable 1 }
VdslLineMCMConfProfileTxBandEntry ::=
    SEQUENCE
        {
        vdslLineMCMConfProfileTxBandNumber
                                                    Unsigned32,
        vdslLineMCMConfProfileTxBandStart
                                                    Unsigned32,
        vdslLineMCMConfProfileTxBandStop
                                                    Unsigned32,
       vdslLineMCMConfProfileTxBandRowStatus
                                                    RowStatus
vdslLineMCMConfProfileTxBandNumber OBJECT-TYPE
   SYNTAX
                Unsigned32 (1..4096)
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
        "The index for this band descriptor entry."
    ::= { vdslLineMCMConfProfileTxBandEntry 1 }
vdslLineMCMConfProfileTxBandStart OBJECT-TYPE
   SYNTAX
                Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "Start tone index for this band."
               "T1E1.4/2000-013R4"
   REFERENCE
                                       -- Part 3, MCM
    ::= { vdslLineMCMConfProfileTxBandEntry 2 }
vdslLineMCMConfProfileTxBandStop OBJECT-TYPE
   SYNTAX
                Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
             current
   DESCRIPTION
       "Stop tone index for this band."
                "T1E1.4/2000-013R4"
                                     -- Part 3, MCM
    ::= { vdslLineMCMConfProfileTxBandEntry 3 }
vdslLineMCMConfProfileTxBandRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
             current
   DESCRIPTION
        "This object is used to create a new row or modify or
        delete an existing row in this table.
        A profile is activated by setting this object to `active'.
       When `active' is set, the system will validate the profile.
```

Each entry must be internally consistent, the Stop Tone must be greater than the Start Tone. Each entry must also be externally consistent, all entries indexed by a specific profile must not overlap. Validation of the profile will check both internal and external consistency.

None of the columns in this row may be modified while the row is in the 'active' state.

Before a profile can be deleted or taken out of
 service, (by setting this object to `destroy' or
 `notInService') it must be first unreferenced
 from all associated lines."
::= { vdslLineMCMConfProfileTxBandEntry 4 }

vdslLineMCMConfProfileRxBandTable OBJECT-TYPE

SYNTAX SEQUENCE OF VdslLineMCMConfProfileRxBandEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains receive band descriptor configuration information for a VDSL line. Each entry in this table reflects the configuration for one of possibly many bands with a multiple carrier modulation (MCM) VDSL line. These entries are defined by a manager and can be used to configure the VDSL line.

If an entry in this table is referenced by a line which does not use MCM, it has no effect on the operation of that line.

::= { vdslLineExtMCMMibObjects 3 }

vdslLineMCMConfProfileRxBandEntry OBJECT-TYPE

SYNTAX VdslLineMCMConfProfileRxBandEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Each entry consists of a transmit band descriptor, which is defined by a start and a stop tone index."

VdslLineMCMConfProfileRxBandEntry ::=

```
SEQUENCE
       {
       vdslLineMCMConfProfileRxBandNumber
                                                    Unsigned32,
       vdslLineMCMConfProfileRxBandStart
                                                    Unsigned32,
       vdslLineMCMConfProfileRxBandStop
                                                    Unsigned32,
       vdslLineMCMConfProfileRxBandRowStatus
                                                    RowStatus
vdslLineMCMConfProfileRxBandNumber OBJECT-TYPE
                Unsigned32 (1..4096)
   SYNTAX
   MAX-ACCESS not-accessible
                current
   STATUS
   DESCRIPTION
        "The index for this band descriptor entry."
    ::= { vdslLineMCMConfProfileRxBandEntry 1 }
vdslLineMCMConfProfileRxBandStart OBJECT-TYPE
   SYNTAX
                Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
       "Start tone index for this band."
   REFERENCE "T1E1.4/2000-013R4"
                                      -- Part 3, MCM
    ::= { vdslLineMCMConfProfileRxBandEntry 2 }
vdslLineMCMConfProfileRxBandStop OBJECT-TYPE
   SYNTAX
               Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
       "Stop tone index for this band."
   REFERENCE "T1E1.4/2000-013R4"
                                    -- Part 3, MCM
    ::= { vdslLineMCMConfProfileRxBandEntry 3 }
vdslLineMCMConfProfileRxBandRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "This object is used to create a new row or modify or
       delete an existing row in this table.
       A profile is activated by setting this object to `active'.
       When `active' is set, the system will validate the profile.
       Each entry must be internally consistent, the Stop Tone must
       be greater than the Start Tone. Each entry must also be
       externally consistent, all entries indexed by a specific
```

```
profile must not overlap. Validation of the profile will
        check both internal and external consistency.
        None of the columns in this row may be modified while the
        row is in the 'active' state.
        Before a profile can be deleted or taken out of
        service, (by setting this object to `destroy' or
        `notInService') it must be first unreferenced
        from all associated lines."
    ::= { vdslLineMCMConfProfileRxBandEntry 4 }
vdslLineMCMConfProfileTxPSDTable OBJECT-TYPE
    SYNTAX
                SEQUENCE OF VdslLineMCMConfProfileTxPSDEntry
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
        "This table contains transmit PSD mask descriptor
        configuration information for a VDSL line. Each entry in
        this table reflects the configuration for one tone within
        a multiple carrier modulation (MCM) VDSL line. These
        entries are defined by a manager and can be used to
        configure the VDSL line.
        If an entry in this table is referenced by a line which
        does not use MCM, it has no effect on the operation of that
        line.
        All read-create-objects defined in this table SHOULD be
        stored persistently."
    ::= { vdslLineExtMCMMibObjects 4 }
vdslLineMCMConfProfileTxPSDEntry OBJECT-TYPE
    SYNTAX VdslLineMCMConfProfileTxPSDEntry
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
        "Each entry consists of a transmit PSD mask descriptor,
        which defines the power spectral density (PSD) for a tone."
    INDEX { vdslLineConfProfileName,
            vdslLineMCMConfProfileTxPSDNumber }
    ::= { vdslLineMCMConfProfileTxPSDTable 1 }
VdslLineMCMConfProfileTxPSDEntry ::=
    SEQUENCE
        {
        vdslLineMCMConfProfileTxPSDNumber
                                                     Unsigned32,
```

```
vdslLineMCMConfProfileTxPSDTone
                                                   Unsigned32,
       vdslLineMCMConfProfileTxPSDPSD
                                                   Unsigned32,
       vdslLineMCMConfProfileTxPSDRowStatus
                                                   RowStatus
vdslLineMCMConfProfileTxPSDNumber OBJECT-TYPE
   SYNTAX Unsigned32 (1..4096)
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The index for this mask descriptor entry."
   ::= { vdslLineMCMConfProfileTxPSDEntry 1 }
vdslLineMCMConfProfileTxPSDTone OBJECT-TYPE
   SYNTAX Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
       "The tone index for which the PSD is being specified."
   REFERENCE
               "T1E1.4/2000-013R4" -- Part 3, MCM
   ::= { vdslLineMCMConfProfileTxPSDEntry 2 }
vdslLineMCMConfProfileTxPSDPSD OBJECT-TYPE
   SYNTAX
                Unsigned32
   UNITS
              "0.5dBm/Hz"
   MAX-ACCESS read-create
               current
   STATUS
   DESCRIPTION
       "Power Spectral Density level in steps of 0.5dBm/Hz with
       an offset of -140dBm/Hz."
   REFERENCE "T1E1.4/2000-013R4"
                                     -- Part 3, MCM
   ::= { vdslLineMCMConfProfileTxPSDEntry 3 }
   vdslLineMCMConfProfileTxPSDRowStatus OBJECT-TYPE
       SYNTAX
                    RowStatus
       MAX-ACCESS
                    read-create
       STATUS
                    current
       DESCRIPTION
           "This object is used to create a new row or modify or
       delete an existing row in this table.
       A profile is activated by setting this object to `active'.
       When `active' is set, the system will validate the profile.
       None of the columns in this row may be modified while the
       row is in the 'active' state.
       Before a profile can be deleted or taken out of
```

```
service, (by setting this object to `destroy' or
        `notInService') it must be first unreferenced
        from all associated lines."
    ::= { vdslLineMCMConfProfileTxPSDEntry 4 }
vdslLineMCMConfProfileMaxTxPSDTable OBJECT-TYPE
               SEQUENCE OF VdslLineMCMConfProfileMaxTxPSDEntry
    SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
        "This table contains transmit maximum PSD mask descriptor
        configuration information for a VDSL line. Each entry in
        this table reflects the configuration for one tone within
        a multiple carrier modulation (MCM) VDSL modem. These
        entries are defined by a manager and can be used to
        configure the VDSL line.
        If an entry in this table is referenced by a line which
        does not use MCM, it has no effect on the operation of that
        line.
       All read-create-objects defined in this table SHOULD be
        stored persistently."
    ::= { vdslLineExtMCMMibObjects 5 }
vdslLineMCMConfProfileMaxTxPSDEntry OBJECT-TYPE
   SYNTAX VdslLineMCMConfProfileMaxTxPSDEntry
   MAX-ACCESS not-accessible
   STATUS
             current
   DESCRIPTION
        "Each entry consists of a transmit PSD mask descriptor,
       which defines the maximum power spectral density (PSD)
        for a tone."
    INDEX { vdslLineConfProfileName,
            vdslLineMCMConfProfileMaxTxPSDNumber }
    ::= { vdslLineMCMConfProfileMaxTxPSDTable 1 }
VdslLineMCMConfProfileMaxTxPSDEntry ::=
    SEQUENCE
        {
        vdslLineMCMConfProfileMaxTxPSDNumber
                                                        Unsigned32,
        vdslLineMCMConfProfileMaxTxPSDTone
                                                        Unsigned32,
        vdslLineMCMConfProfileMaxTxPSDPSD
                                                        Unsigned32,
        vdslLineMCMConfProfileMaxTxPSDRowStatus
                                                        RowStatus
        }
vdslLineMCMConfProfileMaxTxPSDNumber OBJECT-TYPE
   SYNTAX
                Unsigned32 (1..4096)
```

```
MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "The index for this band descriptor entry."
    ::= { vdslLineMCMConfProfileMaxTxPSDEntry 1 }
vdslLineMCMConfProfileMaxTxPSDTone OBJECT-TYPE
    SYNTAX
                Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "The tone index for which the PSD is being specified.
        There must not be multiple rows defined, for a particular
        profile, with the same value for this field."
               "T1E1.4/2000-013R4" -- Part 3, MCM
   REFERENCE
    ::= { vdslLineMCMConfProfileMaxTxPSDEntry 2 }
vdslLineMCMConfProfileMaxTxPSDPSD OBJECT-TYPE
   SYNTAX
                Unsigned32
                "0.5dBm/Hz"
   UNITS
   MAX-ACCESS read-create
               current
   STATUS
   DESCRIPTION
        "Power Spectral Density level in steps of 0.5dBm/Hz with
        an offset of -140dBm/Hz."
   REFERENCE "T1E1.4/2000-013R4"
                                       -- Part 3, MCM
    ::= { vdslLineMCMConfProfileMaxTxPSDEntry 3 }
vdslLineMCMConfProfileMaxTxPSDRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
               current
    DESCRIPTION
        "This object is used to create a new row or modify or
        delete an existing row in this table.
        A profile is activated by setting this object to `active'.
       When `active' is set, the system will validate the profile.
        There must be only one entry in this table for each tone
        associated with a specific profile. This will be checked
        during the validation process.
        None of the columns in this row may be modified while the
        row is in the 'active' state.
        Before a profile can be deleted or taken out of
        service, (by setting this object to `destroy' or
        `notInService') it must be first unreferenced
        from all associated lines."
```

```
::= { vdslLineMCMConfProfileMaxTxPSDEntry 4 }
vdslLineMCMConfProfileMaxRxPSDTable OBJECT-TYPE
    SYNTAX
                SEQUENCE OF VdslLineMCMConfProfileMaxRxPSDEntry
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
        "This table contains maximum receive PSD mask descriptor
        configuration information for a VDSL line. Each entry in
        this table reflects the configuration for one tone within
        a multiple carrier modulation (MCM) VDSL modem. These
        entries are defined by a manager and can be used to
        configure the VDSL line.
        If an entry in this table is referenced by a line which
        does not use MCM, it has no effect on the operation of that
        line.
       All read-create-objects defined in this table SHOULD be
        stored persistently."
    ::= { vdslLineExtMCMMibObjects 6 }
vdslLineMCMConfProfileMaxRxPSDEntry OBJECT-TYPE
    SYNTAX VdslLineMCMConfProfileMaxRxPSDEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Each entry consists of a transmit PSD mask descriptor,
        which defines the power spectral density (PSD) for a
        tone."
    INDEX { vdslLineConfProfileName,
           vdslLineMCMConfProfileMaxRxPSDNumber }
    ::= { vdslLineMCMConfProfileMaxRxPSDTable 1 }
VdslLineMCMConfProfileMaxRxPSDEntry ::=
    SEQUENCE
        vdslLineMCMConfProfileMaxRxPSDNumber
                                                        Unsigned32,
        vdslLineMCMConfProfileMaxRxPSDTone
                                                        Unsigned32,
        vdslLineMCMConfProfileMaxRxPSDPSD
                                                       Unsigned32,
        vdslLineMCMConfProfileMaxRxPSDRowStatus
                                                       RowStatus
        }
vdslLineMCMConfProfileMaxRxPSDNumber OBJECT-TYPE
                Unsigned32 (1..4096)
    SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
```

```
DESCRIPTION
        "The index for this band descriptor entry."
    ::= { vdslLineMCMConfProfileMaxRxPSDEntry 1 }
vdslLineMCMConfProfileMaxRxPSDTone OBJECT-TYPE
                Unsigned32 (1..4096)
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "The tone index for which the PSD is being specified.
        There must not be multiple rows defined, for a particular
        profile, with the same value for this field."
   REFERENCE
                 "T1E1.4/2000-013R4"
                                        -- Part 3, MCM
    ::= { vdslLineMCMConfProfileMaxRxPSDEntry 2 }
vdslLineMCMConfProfileMaxRxPSDPSD OBJECT-TYPE
   SYNTAX
                Unsigned32
   UNITS
                "0.5dBm/Hz"
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "Power Spectral Density level in steps of 0.5dBm/Hz with
        an offset of -140dBm/Hz."
                "T1E1.4/2000-013R4"
   REFERENCE
                                        -- Part 3, MCM
    ::= { vdslLineMCMConfProfileMaxRxPSDEntry 3 }
vdslLineMCMConfProfileMaxRxPSDRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
        "This object is used to create a new row or modify or
        delete an existing row in this table.
        A profile is activated by setting this object to `active'.
       When `active' is set, the system will validate the profile.
        There must be only one entry in this table for each tone
        associated with a specific profile. This will be checked
        during the validation process.
        None of the columns in this row may be modified while the
        row is in the 'active' state.
        Before a profile can be deleted or taken out of
        service, (by setting this object to `destroy' or
        `notInService') it must be first unreferenced
        from all associated lines."
    ::= { vdslLineMCMConfProfileMaxRxPSDEntry 4 }
```

```
-- conformance information
vdslLineExtMCMConformance OBJECT IDENTIFIER ::=
                 { vdslLineExtMCMMib 2 }
vdslLineExtMCMGroups OBJECT IDENTIFIER ::=
                 { vdslLineExtMCMConformance 1 }
vdslLineExtMCMCompliances OBJECT IDENTIFIER ::=
                 { vdslLineExtMCMConformance 2 }
vdslLineExtMCMMibCompliance MODULE-COMPLIANCE
    STATUS current
   DESCRIPTION
        "The compliance statement for SNMP entities which
        manage VDSL interfaces."
   MODULE -- this module
   MANDATORY-GROUPS
       vdslLineExtMCMGroup
   }
    ::= { vdslLineExtMCMCompliances 1 }
-- units of conformance
   vdslLineExtMCMGroup OBJECT-GROUP
        OBJECTS
            {
            vdslLineMCMConfProfileTxWindowLength,
            vdslLineMCMConfProfileRowStatus,
            vdslLineMCMConfProfileTxBandStart,
            vdslLineMCMConfProfileTxBandStop,
            vdslLineMCMConfProfileTxBandRowStatus,
            vdslLineMCMConfProfileRxBandStart,
            vdslLineMCMConfProfileRxBandStop,
            vdslLineMCMConfProfileRxBandRowStatus,
            vdslLineMCMConfProfileTxPSDTone,
            vdslLineMCMConfProfileTxPSDPSD,
            vdslLineMCMConfProfileTxPSDRowStatus,
            vdslLineMCMConfProfileMaxTxPSDTone,
            vdslLineMCMConfProfileMaxTxPSDPSD,
            vdslLineMCMConfProfileMaxTxPSDRowStatus,
            vdslLineMCMConfProfileMaxRxPSDTone,
            vdslLineMCMConfProfileMaxRxPSDPSD,
            vdslLineMCMConfProfileMaxRxPSDRowStatus
         STATUS
                    current
         DESCRIPTION
             "A collection of objects providing configuration
```

```
information for a VDSL line based upon multiple
    carrier modulation modem."
::= { vdslLineExtMCMGroups 1 }
```

END

5. Acknowledgments

This document contains many definitions taken from an early version of the VDSL MIB [RFC3728]. As such any credit for the text found within should be fully attributed to the authors of that document.

6. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

vdslLineMCMConfProfileTable, vdslLineMCMConfProfileTxWindowLength, vdslLineMCMConfProfileRowStatus, vdslLineMCMConfProfileTxBandTable, vdslLineMCMConfProfileTxBandStart, vdslLineMCMConfProfileTxBandStop, vdslLineMCMConfProfileTxBandRowStatus, vdslLineMCMConfProfileRxBandTable, vdslLineMCMConfProfileRxBandStart, vdslLineMCMConfProfileRxBandStop, vdslLineMCMConfProfileRxBandRowStatus, vdslLineMCMConfProfileTxPSDTable, vdslLineMCMConfProfileTxPSDTone, vdslLineMCMConfProfileTxPSDPSD, vdslLineMCMConfProfileTxPSDRowStatus, vdslLineMCMConfProfileMaxTxPSDTable vdslLineMCMConfProfileMaxTxPSDTone, vdslLineMCMConfProfileMaxTxPSDPSD, vdslLineMCMConfProfileMaxTxPSDRowStatus, vdslLineMCMConfProfileMaxRxPSDTable vdslLineMCMConfProfileMaxRxPSDTone, vdslLineMCMConfProfileMaxRxPSDPSD, vdslLineMCMConfProfileMaxRxPSDRowStatus

VDSL layer connectivity from the Vtur will permit the subscriber to manipulate both the VDSL link directly and the VDSL embedded operations channel (EOC) for their own loop. For example, unchecked or unfiltered fluctuations initiated by the subscriber could generate sufficient notifications to potentially overwhelm either the management interface to the network or the element manager.

Additionally, allowing write access to configuration data may allow an end-user to increase their service levels or affect other end-users in either a positive or negative manner. For this reason, the tables and objects listed above should be considered to contain sensitive information.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over the network via SNMP. These are the tables and objects and their sensitivity/vulnerability:

vdslLineMCMConfProfileTable, vdslLineMCMConfProfileTxWindowLength, vdslLineMCMConfProfileRowStatus, vdslLineMCMConfProfileTxBandTable, vdslLineMCMConfProfileTxBandStart, vdslLineMCMConfProfileTxBandStop, vdslLineMCMConfProfileTxBandRowStatus, vdslLineMCMConfProfileRxBandTable, vdslLineMCMConfProfileRxBandStart, vdslLineMCMConfProfileRxBandStop, vdslLineMCMConfProfileRxBandRowStatus, vdslLineMCMConfProfileTxPSDTable, vdslLineMCMConfProfileTxPSDTone, vdslLineMCMConfProfileTxPSDPSD, vdslLineMCMConfProfileTxPSDRowStatus, vdslLineMCMConfProfileMaxTxPSDTable vdslLineMCMConfProfileMaxTxPSDTone, vdslLineMCMConfProfileMaxTxPSDPSD, vdslLineMCMConfProfileMaxTxPSDRowStatus, vdslLineMCMConfProfileMaxRxPSDTable vdslLineMCMConfProfileMaxRxPSDTone, vdslLineMCMConfProfileMaxRxPSDPSD, vdslLineMCMConfProfileMaxRxPSDRowStatus

Read access of the physical band parameters may provide knowledge to an end-user that would allow malicious behavior, for example the application of an intentional interference on one or all of the physical bands in use.

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [RFC3410], section 8), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of a MIB module which utilizes the textual conventions defined in this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

7. IANA Considerations

The IANA has assigned the transmission value 229 to VDSL-LINE-EXT-MCM-MIB.

8. References

8.1. Normative References

- [DSLFTR57] DSL Forum TR-057, "VDSL Network Element Management", February 2003.
- [ETSI2701] ETSI TS 101 270-1 V1.2.1, "Transmission and Multiplexing (TM); Access transmission systems on metallic access cables; Very high speed Digital Subscriber Line (VDSL); Part 1: Functional requirements", October 1999.
- [ETSI2702] ETSI TS 101 270-2 V1.1.1, "Transmission and Multiplexing (TM); Access transmission systems on metallic access cables; Very high speed Digital Subscriber Line (VDSL); Part 1: Transceiver specification", February 2001.

- [ITU9931] ITU-T G.993.1, "Very-high-speed digital subscriber line foundation", November 2001.
- [ITU9971] ITU-T G.997.1, "Physical layer management for Digital Subscriber Line (DSL) Transceivers", July 1999.
- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [RFC2579] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.
- [RFC3728] Ray, B. and R. Abbi, "Definitions of Managed Objects for Very High Speed Digital Subscriber Lines (VDSL)", RFC 3728, February 2004.
- [T1E1311] ANSI T1E1.4/2001-311, "Very-high-bit-rate Digital Subscriber Line (VDSL) Metallic Interface, Part 1: Functional Requirements and Common Specification", February 2001.
- [T1E1011] ANSI T1E1.4/2001-011R3, "VDSL Metallic Interface, Part 2: Technical Specification for a Single-Carrier Modulation (SCM) Transceiver", November 2001.
- [T1E1013] ANSI T1E1.4/2001-013R4, "VDSL Metallic Interface, Part 3: Technical Specification for a Multi-Carrier Modulation (MCM) Transceiver", November 2000.

8.2. Informative References

[RFC3415] Wijnen, B., Presuhn, R., and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", STD 62, RFC 3415, December 2002.

[RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart,
"Introduction and Applicability Statements for InternetStandard Management Framework", RFC 3410, December 2002.

Authors' Addresses

Menachem Dodge ECI Telecom Ltd. 30 Hasivim St. Petach Tikva 49517, Israel

Phone: +972 3 926 8421 Fax: +972 3 928 7342 EMail: mbdodge@ieee.org

Bob Ray PESA Switching Systems, Inc. 330-A Wynn Drive Huntsville, AL 35805 USA

Phone: +1 256 726 9200 ext. 142

Fax: +1 256 726 9271 EMail: rray@pesa.com

Full Copyright Statement

Copyright (C) The Internet Society (2005).

This document is subject to the rights, licenses and restrictions contained in $\underline{\mathsf{BCP}}$ 78, and except as set forth therein, the authors retain all their rights.

This document and the information contained herein are provided on an "AS IS" basis and THE CONTRIBUTOR, THE ORGANIZATION HE/SHE REPRESENTS OR IS SPONSORED BY (IF ANY), THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Intellectual Property

The IETF takes no position regarding the validity or scope of any Intellectual Property Rights or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; nor does it represent that it has made any independent effort to identify any such rights. Information on the procedures with respect to rights in RFC documents can be found in BCP 78 and BCP 79.

Copies of IPR disclosures made to the IETF Secretariat and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this specification can be obtained from the IETF on-line IPR repository at http://www.ietf.org/ipr.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights that may cover technology that may be required to implement this standard. Please address the information to the IETF at ietf-ipr@ietf.org.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.